









SV680N-INT Series Servo Drive Safety Guide







Intelligent Elevator



New Energy



ndustrial



Rail



Preface

Introduction

This manual describes integrated STO and expansion safety functions.

The SV680N-INT drive comes with Integrated STO as a standard feature.


The safety drive enables a range of safety functions including SS1, SS2, SOS, SDI, SSM, SBC, STO, and SLS. These safety functions can be triggered through connection to external terminals (hereinafter "locally triggered safety functions") or through EtherCAT communication with the host controller (hereinafter "bus triggered safety functions"). The bus (namely, FSoE) triggered safety functions are only applicable to the SV680N-INT functional safety servo drive.

The safety functions can protect the operator from the danger of moving parts of the machine, improving the personnel safety.

This manual provides information concerning product safety, mechanical and electrical installation, commissioning and maintenance, and safety parameters. Please read this manual carefully before use.

More documents

The documents related to the drive are shown in the following figure and table.



| No. | Name | Data Code | Description |
|-----|---|------------|---|
| 1) | SV680-INT series flagship servo drive | 19120347 | Provides instructions on product selection, including the list of supporting components, technical data on the drive, and the selection guide of cables. |
| 2 | SV680-INT Series Servo Drive Installation and Commissioning Quick Guide | PS00015536 | Describes the model number, installation, terminals and quick commissioning and operation of the drive. |
| 3 | SV680-INT Series Servo Drive Hardware Guide | PS00015494 | Describes technical data, installation, terminals, required certificates and standards and solutions to common EMC problems of the drive. |
| 4 | SV680-INT Series Servo Drive Function Guide | PS00015554 | Introduces the functions and faults of the drive, including function overview, adjustment, basic servo functions and fault handling. |
| (5) | SV680-INT Series Servo Drive Communication Guide | PS00015535 | Introduces the communication of the drive, including configuration of Modbus, CANopen, and EtherCAT communication. |
| (G) | SV680P-INT Series Servo Drive Safety Guide | PS00009740 | Describes the safety function and related certifications and standards, wiring, commissioning |
| • | SV680N-INT Series Servo Drive Safety Guide | PS00009768 | process, troubleshooting and parameters of the drive. |
| 7 | SV680-INT Series Servo Drive Parameter Guide | PS00015555 | Introduces the parameters of the drive, including a parameter list and description of parameters. |
| | MS1-R Series Servo Motor Selection Guide | PS00004605 | Introduces the product information, general specifications, motor selection, cable selection, and required certificates and standards of the servo motor. |
| 8 | MS1-R Series Servo Motor Installation Guide | PS00005407 | Describes installation of the motor, including an installation flowchart, unpacking and transportation, mechanical installation, and electrical installation. |
| | Direct drive motor module platform and drive | 19120011 | Introduces the product information, general specifications, motor selection, cable selection, and required standards of the motor. |

Revision History

| Date | Version | Description | |
|---------|---------|--------------------|--|
| 2024-05 | A02 | Minor corrections. | |
| 2024-03 | A01 | Minor corrections. | |
| 2023-08 | A00 | First release. | |

Access to the Guide

This guide is not delivered with the product. You can obtain the PDF version in the following way:

• Visit http://www.inovance.com, go to Support > Download, search by keyword, and then download the PDF file.

- Scan the QR code on the product with your mobile phone.
- Scan the QR code below to install the app, where you can search for and download manuals.



Warranty

Inovance provides warranty service within the warranty period (as specified in your order) for any fault or damage that is not caused by improper operation of the user. You will be charged for any repair work after the warranty period expires.

Within the warranty period, maintenance fee will be charged for the following damage:

- Damage caused by operations not following the instructions in the user guide
- Damage caused by fire, flood, or abnormal voltage
- Damage caused by unintended use of the product
- Damage caused by use beyond the specified scope of application of the product
- Damage or secondary damage caused by force majeure (natural disaster, earthquake, and lightning strike)

The maintenance fee is charged according to the latest Price List of Inovance. If otherwise agreed upon, the terms and conditions in the agreement shall prevail. For details, see the Product Warranty Card.

Table of Contents

| Preface | 1 |
|--|----|
| Fundamental Safety Instructions | 8 |
| 1 General | 15 |
| 1.1 List of Safety Functions | 15 |
| 1.2 Terms and Abbreviations | 16 |
| 1.3 Safety Standards | 17 |
| 1.4 Precautions for Use | 19 |
| 2 Product Information | 25 |
| 2.1 Drive Model and Nameplate | 25 |
| 2.2 Motor Model and Nameplate | 26 |
| 2.3 Description of the Encoder Model | 27 |
| 2.4 Cable Models | 29 |
| 2.5 Components | |
| 2.5.1 Servo Drives in Size A and Size C (Rated Power 0.2 kW to 1.5 kW) | |
| 2.5.2 Servo Drives in Size D (Rated Power 1.5 kW to 3.0 kW) | |
| 2.6 List of Compatible Models | |
| 2.6.1 Selection of Functional Safety Drives and Motors | 40 |
| 2.6.2 Selection of Standard Drives and Motors | |
| 3 Operating Panel | |
| 3.1 Components | |
| 3.2 Display | 51 |
| 4 Installation | |
| 4.1 Unpacking and Handling | 53 |
| 4.2 Installation Environment | 56 |
| 4.3 Installation Clearance | 57 |
| 4.4 Installation Dimensions | 59 |
| 4.5 Installation Precautions | 61 |
| 5 Wiring | |
| 5.1 Wiring Precautions | 62 |
| 5.2 Terminal Pin Layout of the Drive | 64 |
| 5.3 FSoE Connection and Effective Mode | |
| 5.3.1 FSoE Network Connection and Setting | |
| 5.3.2 Knob Operating Method | 66 |

| 5.4 CN6 STO Safety Terminal | . 66 |
|---|-----------------------|
| 5.5 CN7 Encoder Terminal 5.5.1 Terminal Layout 5.5.2 Wiring Examples 5.5.2.1 Communication with the First Encoder 5.5.2.2 Communication with the Second Encoder | . 69 . 70 |
| 5.6 Description of Brake and PTC Input Terminal (CN8) 5.6.1 Terminal Layout 5.6.2 Wiring Examples 5.6.2.1 PTC Wiring Example. 5.6.2.2 Brake Wiring Examples | . 74 . 74 74 |
| 5.7 Expansion Safety Function Terminals CN9 and CN10 | . 76 |
| 5.8 24 V Terminal (CN11) | |
| 6 Expansion Safety Function | |
| 6.1 General | |
| 6.2 Software Parameter Configuration | . 88 |
| 6.3 Safety DI/DO Function. 6.3.1 Safety DI Function 6.3.2 Safety DO Function. | . 91 |
| 6.4 FSoE Function | . 95 |
| 6.5 Safe Torque Off Function | . 97 . 98 . 102 |
| 6.6 Safe Brake Control (SBC) 6.6.1 Overview 6.6.2 SBC Triggered By Local Mode 6.6.3 SBC Triggered by FSoE Mode 6.6.4 Sequence Diagrams | 105 106 110 |
| 6.7 Safe Stop 1 (SS1) 6.7.1 Overview 6.7.2 SS1 Triggered By Local Mode 6.7.3 SS1 Triggered By FSoE Mode. 6.7.4 Sequence Diagrams | 113 114 118 |
| 6.8 Safe Stop 2 (SS2) 6.8.1 Overview 6.8.2 SS2 Triggered in Local Mode 6.8.3 SS2 Triggered By FSoE Mode. 6.8.4 Sequence Diagrams | 123 124 129 |

| | perating Stop (SOS) | |
|-----------------|---|-----|
| | verview | |
| | OS Triggered By Local Mode | |
| | OS Triggered by FSoE Modeequence Diagrams | |
| | -Limited Speed (SLS) | |
| | Prerview | |
| | SLS Triggered By Local Mode | |
| | SLS Triggered by FSoE Mode | |
| | Sequence Diagrams | |
| | Direction (SDI) | |
| | Overview | |
| | SDI Function Triggered by FSoE Mode | |
| | Sequence Diagrams | |
| 6.12 Safe S | Speed Monitor (SSM) | 154 |
| | Overview | |
| | SSM Triggered By the Local Mode | |
| | SSM Output in FSoE Mode | |
| | Function Response Time | |
| | Response Time for Triggering Local Mode | |
| | Response Time in FSoE Mode | |
| 6.14 Fault I | Reset | 161 |
| 7 Integrated S | TO Safety Function | 162 |
| 7.1 Overvie | ew | 162 |
| 7.2 Use of t | the STO Function | 163 |
| 7.3 Fault R | eset | 165 |
| 7.4 Safety I | Function Response Time | 166 |
| 8 Commission | ing and Operation | 167 |
| 8.1 Pre-ope | eration Inspection | 167 |
| 8.2 Trial Ru | ın | 167 |
| 8.3 Verifica | tion and Validation | 168 |
| 9 Troubleshoo | ting | 174 |
| 9.1 Fault a | nd Alarm Levels | 174 |
| 9.2 List of F | Fault and Alarm Codes | 174 |
| 9.3 Solutio | ns to Faults | 179 |
| | ns to Alarms | |
| 10 List of Para | meters | 208 |
| | | |

| 10.1 Parameter Group H02 | 208 |
|--|-----|
| 10.2 Parameter Group H0A | 208 |
| 10.3 Parameter Group H20 | 209 |
| 10.4 Parameters in Group 6000 | 216 |
| 11 Description of Parameters | 221 |
| 11.1 H02 Basic Control Parameters | 221 |
| 11.2 H0A Fault and Protection Parameters | 222 |
| 11.3 H20 Functional Safety Parameters | 223 |
| 11.4 6000h Object Dictionary | 245 |
| 12 Maintenance | 268 |
| 12.1 Routine Maintenance Items | 268 |
| 12.1.1 Routine Checklist | |
| 12.1.2 Routine Cleaning List | |
| 12.2 Regular Checklist | |
| 12.2.1 Regular Checklist | |
| 13 Certification and Standard Requirements | |
| 13.1 CE Certification. | |
| 13.1.1 Requirements for Compliance with EMC | |
| 13.1.2 Requirements for Compliance with LVD | |
| 13.2 UL/cUL Certification | 274 |
| 13.3 KC Certification | 277 |
| 13.4 EAC Certification | 279 |
| 13.5 UKCA Certification | 279 |
| 13.6 Functional Safety Certification | 279 |
| 14 Appendix | 280 |
| 14.1 Safety Module Working with Beckhoff Safety CPU Unit | 280 |
| 14.2 DIDO Function Assignment | |

Fundamental Safety Instructions

Safety Precautions

- This chapter presents essential safety instructions for a proper use of the
 equipment. Before operating the equipment, read through the guide and
 comprehend all the safety instructions. Failure to comply with the safety
 precautions may result in death, serious injury, or equipment damage.
- "CAUTION", "WARNING", and "DANGER" items in the guide only indicate some of the precautions that need to be followed; they just supplement the safety precautions.
- Use this equipment according to the designated environment requirements.

 Damage caused by improper use is not covered by warranty.
- Inovance shall take no responsibility for any personal injuries or property damage caused by improper usage.

Safety Levels and Definitions



Indicates that failure to comply with the notice will result in death or severe personal injuries.



Indicates that failure to comply with the notice may result in death or severe personal injuries.



Indicates that failure to comply with the notice may result in minor or moderate personal injuries or equipment damage.

Fundamental Safety Instructions

- Drawings in the guide are sometimes shown without covers or protective guards. Remember to install the covers or protective guards as specified first, and then perform operations in accordance with the instructions.
- The drawings in the guide are shown for illustration only and may be different from the product you purchased.
- Users must take mechanical precautions to protect personal safety and wear protective equipment, such as anti-smashing shoes, safety clothing, safety glasses, protective gloves, and protective sleeves.

Unpacking



- Do not install the equipment if you find damage, rust, or signs of use on the equipment or accessories upon unpacking.
- Do not install the equipment if you find water seepage or missing or damaged components upon unpacking.
- Do not install the equipment if you find the packing list does not conform to the equipment you received.



- Check whether the packing is intact and whether there is damage, water seepage, dampness, and deformation before unpacking.
- Unpack the package by following the unpacking sequence. Do not strike the package violently.
- Check whether there is damage, rust, or injuries on the surface of the equipment and equipment accessories before unpacking.
- Check whether the package contents are consistent with the packing list before unpacking.

Storage and Transportation



- Large-scale or heavy equipment must be transported by qualified professionals using specialized hoisting equipment. Failure to comply may result in personal injuries or equipment damage.
- Before hoisting the equipment, ensure the equipment components such as the front cover and terminal blocks are secured firmly with screws. Loosely-connected components may fall off and result in personal injuries or equipment damage.
- Never stand or stay below the equipment when the equipment is being hoisted by the hoisting equipment.
- When hoisting the equipment with a steel rope, ensure the equipment is hoisted at a
 constant speed without suffering from vibration or shock. Do not turn the equipment
 over or let the equipment stay hanging in the air. Failure to comply may result in
 personal injuries or equipment damage.



- Handle the equipment with care during transportation and mind your steps to prevent personal injuries or equipment damage.
- When carrying the equipment with bare hands, hold the equipment casing firmly with care to prevent parts from falling. Failure to comply may result in personal injuries.
- Store and transport the equipment based on the storage and transportation requirements. Failure to comply will result in equipment damage.
- Avoid storing or transporting the equipment in environments with water splash, rain, direct sunlight, strong electric field, strong magnetic field, and strong vibration.
- Avoid storing the equipment for more than three months. Long-term storage requires stricter protection and necessary inspections.
- Pack the equipment strictly before transportation. Use a sealed box for long-distance transportation.
- Never transport the equipment with other equipment or materials that may harm or have negative impacts on this equipment.

Installation



 The equipment must be operated only by professionals with electrical knowledge. Nonprofessionals are not allowed.



- Read through the guide and safety instructions before installation.
- Do not install this equipment in places with strong electric or magnetic fields.
- Before installation, check that the mechanical strength of the installation site can bear the weight of the equipment. Failure to comply will result in mechanical hazards.
- Do not wear loose clothes or accessories during installation. Failure to comply may result in an electric shock.
- When installing the equipment in a closed environment (such as a cabinet or casing), use a cooling device (such as a fan or air conditioner) to cool the environment down to the required temperature. Failure to comply may result in equipment over-temperature or a fire.
- Do not retrofit the equipment.
- Do not fiddle with the bolts used to fix equipment components or the bolts marked in red.
- When the equipment is installed in a cabinet or final assembly, a fireproof enclosure
 providing both electrical and mechanical protections must be provided. The IP rating
 must meet IEC standards and local laws and regulations.
- Before installing equipments with strong electromagnetic interference, such as a transformer, install a shielding equipment for the equipment to prevent malfunction.
- Install the equipment onto an incombustible object such as a metal. Keep the
 equipment away from combustible objects. Failure to comply will result in a fire.



- Cover the top of the equipment with a piece of cloth or paper during installation. This is
 to prevent unwanted objects such as metal chippings, oil, and water from falling into the
 equipment and causing faults. After installation, remove the cloth or paper on the top of
 the equipment to prevent over-temperature caused by poor ventilation due to blocked
 ventilation holes.
- Resonance may occur when the equipment operating at a constant speed executes variable speed operations. In this case, install the vibration-proof rubber under the motor frame or use the vibration suppression function to reduce resonance.

Wiring



DANGER

- Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals.
- Before wiring, cut off all the power supplies of the equipment. and wait for at least the
 time designated on the equipment warning label before further operations because
 residual voltage still exists after power-off. After waiting for the designated time,
 measure the DC voltage in the main circuit to ensure the DC voltage is within the safe
 voltage range. Failure to comply will result in an electric shock.
- Do not perform wiring, remove the equipment cover, or touch the circuit board with power ON. Failure to comply will result in an electric shock.
- Check that the equipment is grounded properly. Failure to comply can result in electric shock.



- Do not connect the input power supply to the output end of the equipment. Failure to comply can result in equipment damage or even a fire.
- When connecting a drive to the motor, check that the phase sequences of the drive and motor terminals are consistent to prevent reverse motor rotation.
- Cables used for wiring must meet cross sectional area and shielding requirements. The shield of the cable must be reliably grounded at one end.
- Fix the terminal screws with the tightening torque specified in the user guide. Improper tightening torque may overheat or damage the connecting part, resulting in a fire.
- After wiring is done, check that all cables are connected properly and no screws, washers or exposed cables are left inside the equipment. Failure to comply may result in an electric shock or equipment damage.



- Follow the proper electrostatic discharge (ESD) procedure and wear an anti-static wrist strap to perform wiring. Failure to comply may result in damage to the equipment or to the internal circuit of the product.
- Use shielded twisted pairs for the control circuit. Connect the shield to the grounding terminal of the equipment for grounding purpose. Failure to comply will result in equipment malfunction.

Power-on



- Before power-on, check that the equipment is installed properly with reliable wiring and the motor can be restarted.
- Check that the power supply meets equipment requirements before power-on to prevent equipment damage or a fire.
- After power-on, do not open the cabinet door or protective cover of the equipment, touch any terminal, or disassemble any unit or component of the equipment. Failure to comply will result in an electric shock.



- Perform a trial run after wiring and parameter setting to ensure the equipment operates safely. Failure to comply may result in personal injuries or equipment damage.
- Before power-on, check that the rated voltage of the equipment is consistent with that of the power supply. Failure to comply may result in a fire.
- Before power-on, check that no one is near the equipment, motor, or machine. Failure to comply may result in death or personal injuries.

Operation



- The equipment must be operated only by professionals. Failure to comply will result in death or personal injuries.
- Do not touch any connecting terminals or disassemble any unit or component of the equipment during operation. Failure to comply will result in an electric shock.



- Do not touch the equipment casing, fan, or resistor with bare hands to feel the temperature. Failure to comply may result in personal injuries.
- Prevent metal or other objects from falling into the equipment during operation. Failure to comply may result in a fire or equipment damage.

Maintenance



- Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals.
- Do not maintain the equipment with power ON. Failure to comply will result in an electric shock.
- Before maintenance, cut off all the power supplies of the equipment and wait for at least the time designated on the equipment warning label.
- In case of a permanent magnet motor, do not touch the motor terminals immediately
 after power-off because the motor terminals will generate induced voltage during
 rotation even after the equipment power supply is off. Failure to comply will result in an
 electric shock.



 Perform routine and periodic inspection and maintenance on the equipment according to maintenance requirements and keep a maintenance record.

Repair



DANGER

- Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals.
- Do not repair the equipment with power ON. Failure to comply will result in an electric
- Before inspection and repair, cut off all the power supplies of the equipment and wait for at least the time designated on the equipment warning label.



- Submit the repair request according to the warranty agreement.
- When the fuse is blown or the circuit breaker or earth leakage current breaker (ELCB) trips, wait for at least the time designated on the equipment warning label before power-on or further operations. Failure to comply may result in death, personal injuries or equipment damage.
- When the equipment is faulty or damaged, the troubleshooting and repair work must be performed by professionals that follow the repair instructions, with repair records kept properly.
- Replace quick-wear parts of the equipment according to the replacement instructions.
- Do not use damaged equipment. Failure to comply may result in death, personal injuries, or severe equipment damage.
- After the equipment is replaced, check the wiring and set parameters again.

Disposal



- Dispose of retired equipment in accordance with local regulations and standards. Failure to comply may result in property damage, personal injuries, or even death.
- Recycle retired equipment by observing industry waste disposal standards to avoid environmental pollution.

Additional Precautions

Precautions for the dynamic brake

- Dynamic braking can only be used for emergency stop in case of failure and sudden power failure. Do not trigger failure or power failure frequently.
- Ensure that the dynamic braking function has an operation interval of more than 5 minutes at high speed, otherwise the internal dynamic braking circuit may be damaged.

Dynamic braking is commonly used in rotating mechanical structures. For
example, when a motor has stopped running, it keeps rotating due to the inertia of
its load. In this case, this motor is in the regenerative state and short-circuit
current passes through the dynamic brake. If this situation continues, the drive,
and even the motor, may be burned.

Safety label

For safe equipment operation and maintenance, comply with the safety labels on the equipment. Do not damage or remove the safety labels. The following table describes the meaning of the safety labels.

| Safety label | Description | | |
|--|---|--|--|
| 危险 DANGER 高压注意 Hazardous Voltage 高温注意 High Temperature | Never fail to connect the protective earth (PE) terminal. Read through the guide and follow the safety instructions before use. Do not touch terminals within 15 minutes after disconnecting the power supply to prevent the risk of electric shock. Do not touch the heatsink with power ON to prevent the risk of burn. | | |

1 General

1.1 List of Safety Functions

Different from a standard drive, a safety-integrated drive can run without additional external components.

Function list

Safe torque off (STO)

The STO function immediately shuts off the torque or force output of the motor based on an input signal from an external device. This function complies with stop category 0 of EN 60204-1. If the motor is running when the STO function is activated, it coasts to stop.

- Safe brake control (SBC)
 The SBC function provides a safe output signal for controlling external brake.
- Safe stop 1 (SS1)

The SS1 function starts deceleration based on an input signal from an external device. After a preset period of time elapses or zero speed is achieved, the STO function will be triggered. This function complies with stop category 1 of EN 60204-1.

- SS1-t time-monitored SS1
 The motor decelerates to stop according to the input signal of the external device. Then STO is executed after the designated delay elapsed.
- SS1-r ramp-monitored SS1
 The motor decelerates to stop according to the input signal of the external device. The deceleration slope is monitored against the specified range. STO is executed when the motor speed is lower than the set limit.
- Safe stop 2 (SS2)

The SS2 function starts deceleration based on an input signal from an external device. After a preset period of time has elapsed or zero speed is achieved, the SOS function will be triggered. This function complies with stop category 2 of EN 60204-1.

- Safe operating stop (SOS)
 - The SOS function monitors whether the motor stops within the prescribed range for the stop position. The drive is in the closed-loop control mode, and can therefore withstand external forces.
- Safely-limited speed (SLS)

 The SLS function monitors whether the motor speed exceeds a preset speed limit.

 When the speed is over the limit, torque of the motor will be shut off immediately.

- Safe direction (SDI)
 - The SDI function prevents the motor shaft from moving in an unintended direction. If the motor rotates in an impermissible direction, the drive stops the motor as quickly as possible.
- Safe speed monitor (SSM)
 The SSM function provides a safe output signal to indicate whether the motor speed is below a prescribed limit to identify, for example, a standstill. The servo provides a safe output signal for further processing.

Safety function characteristics

- The expansion safety functions are controlled by an external device through DI or a safety bus.
 - The combination of safety module, SV680 series servo drives, and safety motor supports safety functions (SS1-r/SS2/SOS/SLS/SDI/SSM) in compliance with PL e/Cat.3 and SIL3. The SBC/SS1/SS2/SOS/SLS/SDI/SSM features are not available when the safety motor is not used.
- Integrated STO can be triggered by the CN6 terminal on the panel of the drive.
- Controlling safety functions using a safety bus reduces wiring.



Safety functions SS1-r/SS2/SOS/SLS/SDI/SSM require the use of safety motor, while safety functions STO/SBC/SS1-t do not.

1.2 Terms and Abbreviations

| Terms and Abbreviations | Description | | |
|-------------------------|--|--|--|
| Cat. | Safety category It includes B, 1, 2, 3, and 4. | | |
| CCF | Common cause failure | | |
| DCavg | Average diagnostic coverage (%) | | |
| DTI | Diagnostic test interval time | | |
| SFF | Safe failure fraction | | |
| HFT | Hardware fault tolerance | | |
| PFH _D | Probability of a dangerous Failure per Hour | | |
| PL | Performance Level | | |
| SC | Systematic capability | | |
| SIL | Safety integrity level | | |

| Terms and Abbreviations | Description | | |
|--|--------------------------------|--|--|
| T ₁ | Test interval | | |
| DI | Digital input | | |
| DO | Digital output | | |
| PCB | Printed circuit board | | |
| MCU | Micro computer unit | | |
| FPGA | Field programmable gate array | | |
| MTTFd | Mean time to dangerous failure | | |
| The safe torque off (STO) function brings the machine safely into torque state and prevents it from unexpected start. If the motor running when STO function is activated, it coasts to 0 RPM. | | | |

1.3 Safety Standards

Standards compliance

• EU directives and standards Low Voltage Directive 2014/35/EU, EN 61800-5-1

EMC Directive 2014/30/ EU, EN 61800-3 2018

Machinery Directive 2006/42/EC (Function Safety), IEC 61800-5-2

• Safety standard

| Safety standard | Reference | |
|--|--|--|
| Functional safety | IEC 61508: 2010 ISO 13849-1: 2015 ISO 13849-2: 2012 IEC 62061: 2021 EN 61508: 2010 EN ISO 13849-1: 2015 EN ISO 13849-2: 2012 EN IEC 62061: 2021 IEC 60204-1: 2016 (in extracts) EN 60204-1: 2018 (in extracts) | |
| Electromagnetic compatibility (EMC) | IEC 61800-5-2: 2016 IEC 61800-3: 2017 IEC 61326-3-1: 2017 IEC 61000-6-7: 2014 EN 61800-5-2: 2017 EN IEC 61800-3: 2018 EN 61326-3-1: 2017 EN 6100067:2015 | |
| LVD | IEC 6180051:2007/AMD1:2016 EN 6180051:2007/A1:2017 | |

• Safety parameters

| Item | Safety parameters | | |
|---|--|--|--|
| SIL | SIL3, IEC61508 Maximum SIL3, EN IEC62061 | | |
| PFH D | PFH D \leq 1.1×10 ⁻⁹ [1/h] (1.1% of SIL3) | | |
| Cat. | 3, EN ISO 13849–1 | | |
| PL E, EN ISO 13849–1 | | | |
| MTTFd 904 years (high) | | | |
| DCavg ≥ 90% (medium) | | | |
| Т1 | 20 years | | |
| HFT | 1 | | |
| SC | SC3 | | |
| λ_{S} 2.2×10 ⁻⁷ /h | | | |
| λ_{DD} | 1.3×10 ⁻⁷ /h | | |
| λου | 2.7×10 ⁻⁹ /h | | |
| MTTR | 0 hour | | |
| MRT | 0 hour | | |
| Application mode High demand or continuous mode | | | |
| Device type Type B | | | |
| Safe speed accuracy | 2197.98 rpm | | |

 λ_{S} means the failure rate of safe failure which brings the system into safe state.

 λ_{DD} indicates the dangerous fault rate that can be diagnosed by the sub-system.

 $\lambda_{\,DU}$ indicates the failure rate of dangerous failure that can't be diagnosed by the diagnosis subsystem.

Note

- See ISO13849-2: 2012 for failure modes of devices.
- Failure sharing of different failure modes of each device.
- See SN29500 for failure rate of each device.

1.4 Precautions for Use

Safety Instructions

The chapter contains the warning symbols used in this manual and the safety instructions which you must obey when you install or connect an option module to a drive or inverter. If you ignore the safety instructions, injury, death or damage can occur. Read this chapter before you start the installation.

Any illustrations, photographs, or examples used in this manual are provided as examples only and may not apply to all products to which this manual is applicable.

The products and specifications described in this manual or the content and presentation of the manual may be changed without notice to improve the product and/or the manual.

| Table 1-1 Wallings, Cautions and Notes | | | |
|---|-------------|-------------|---|
| Symbol | Signal word | Description | Consequences in case of disregard |
| Example: | DANGER | DANGER | Indicates that failure to comply with the notice will result in death or severe personal injuries |
| DANGER | WARNING | Warning | Indicates that failure to comply with the notice may result in death or severe personal injuries |
| Hazardous voltage e.g. electric shock | CAUTION | Caution | Indicates that failure to comply with the notice may result in minor or moderate personal injuries or equipment damage |
| | STOP | Stop | Indicates that failure to comply with the notice will result in equipment or environmental damage |

Table 1–1 Warnings, Cautions and Notes



- High attention is required for electrical installation and at the system design to avoid hazards either in normal operation or in the event of equipment malfunction.
- System design, installation, commissioning and maintenance must be carried out by personnel who have the necessary training and experience. They must read the operating instruction and this safety information.

It is the responsibility of the machine builder/OEM/system integrator to make sure that the essential health and safety function requirements specified in the Machinery Directive are met. Risk analysis and risk assessment is needed before using a product. Make sure that adequate measures are taken to eliminate/reduce the relating risks and components chosen must meet the safety requirements.

This section describes the information that needs to be noted before starting operation. Read the following safety precautions, risk assessment information, and limitations before starting operation.

Safety function: Use the safety function after properly understanding all of these information. Incorrect use of safety functions or use of safety functions that are not sufficient to meet the safety requirements of the site may result in personal injury.

Safety Precautions

Carefully read and observe the following important precautions when using security features:

- STO function is not intended as a replacement for the emergency stop function (Estop). If only the STO function is triggered, with no extra measures taken, the power supply cannot be cut off in emergencies and high-current parts of the motor and drive are still energized, incurring the risk of electric shock or other risks result in electric energy. Therefore maintenance work on electrical parts of the drive or motor can only be carried out after isolating the drive system from the main supply.
- Depending on the standards and requirements for a particular application, it may
 be possible to use STO as an integral part of an E-stop system. However, its main
 purpose is for use in a dedicated safety control arrangement whose purpose is to
 prevent any hazard from occurring, without the use of an E-stop.
- An E-stop is often provided in a machine to allow for unexpected situations where an operator sees a hazard and can take action to prevent an accident.
- The design requirement for an E-stop differs from that of a safety interlock.
 Generally, the E-stop is required to be independent from any complex or "intelligent" control. It may use purely electromechanical devices to either

disconnect the power or initiate a controlled rapid stop using other means such as dynamic or regenerative braking.

Note

- The design of safety-related systems requires specialist knowledge. To ensure that
 a complete control system is safe, it is necessary for the whole system to be
 designed according to recognized safety principles. The use of individual subsystems such as drives with STO function, which are intended for safety-related
 applications, does not in itself ensure that the complete system is safe.
- The STO function can be used to stop the drive in emergency stop situations.
- In processes without personnel protection, it is recommended not to stop the
 drive by using the STO function. If a drive running is stopped by using STO, the
 drive performs a coast-to-stop. If this is not acceptable, the system should be
 stopped using the correct mode instead of the STO function.
- This publication is a guide to the application of Inovance SV660 series safety functions, and also on the design of safety-related systems for machinery control.
- It is the responsibility of the designer of the end product or application to ensure that it is safe and in compliance with the relevant regulations.

Risk Assessment

- When using the safety functions, perform risk assessment on the servo system in advance. Make sure that the safety integrity level of the standards is met.
- The following residual risks can be present even when the safety functions operate. Therefore, safety must always be given consideration during risk assessment.
- If external forces (such as gravitational force with a vertical axis) are applied when
 the safety functions are operating, the motor will rotate due to the action of these
 external forces. Therefore, you must use a separate mechanical brake to secure
 the motor.

Note

- In the case of failure of multiple IGBTs, regardless of whether the STO function is enabled, the servo drive can generate an alignment torque. This torque can cause the motor shaft to rotate within a range of up to 180÷p (for a synchronous reluctance motor, the range is 180÷2p).
- p: Number of motor pole pairs.

To ensure safety, users should decide all the risk assessments and residual risks in the entire machine equipment. A company and individual who constructed the safety related system must take full responsibility for installation and commissioning of the

system. Additionally, when complying with a European machinery directive, the system must acquire safety standards certification as a whole.

Perform all risk assessments and safe level certification to the machine or the system as a whole. It is recommended that a Certification Body final safety certification of the system be used.

The following shows residual risks concerning the safety function of this product.

Common residual risks

- At the shipment to end-users, check the settings of safety related components
 with programming tools and monitored/displayed contents on display and record
 and save the setting data concerning the safety observation function and the
 programming tools you used. Perform them using a check sheet, etc.
- The safety will not be ensured such as in assembling machine until installing, wiring, and adjustment are completed properly. Install, wire, and adjust your system referring to installation guide for each unit.
- Only qualified personnel are authorized to install, start-up, repair or adjust the
 machines in which these components are installed. Only trained engineers should
 install and operate the equipment.
- Separate the wiring for safety observation function from other signal wiring.
- Protect the cables with appropriate ways (routing them in a cabinet, using a cable guard, etc.).
- We recommend using a switch, relay, sensor, etc. which comply with safety standards. When using a switch, relay, sensor, etc. which do not comply with safety standards, perform a safety confirmation.
- Keep the required clearance/creepage distance depending on voltage you use.

Residual risks in each function

Safe torque off (STO)

This function only cuts off the torque of the motor, and does not cut off the power supply of the servo/inverter. Before servicing the servo/inverter, cut off the power supply and ensure that the servo/inverter are not energized.

You must conduct STO diagnosis every three month by powering off and powering on the drive once, or running the STO function once.

Note

There are two ways to perform STO diagnosis:

- Power off and restart;
- Trigger and then cancel STO.

You can use either of them.

• Safe brake control (SBC)

This function guarantees only that power to mechanic break is properly supplied and abrasion of the brake cannot be detected. Check this function regularly that the mechanic brake can operate. Evaluate whether the holding force of the mechanical brake meets the application requirements. Incorrect use may result in abrasion of brake and personal injury.

Safely-limited speed (SLS)

- Speed monitoring function guarantees the servo motor speed, but it does not guarantee the actual machine safety speed. Set parameters so that the safe speed of the machine is the same as the safety speed of the specified motor.
- Check if the speed of the monitored servo axis is the same as the actual speed by using a tachometer, etc. considering the speed includes an error caused by the command and encoder resolution.
- The defect of the mechanical section such as slid of shaft and wanting of a timing belt, etc. is not covered. Be sure to eliminate the risk of mechanical section before operation.
- After speed is over the limit, safety observation error (shut-off signal off) does not occur during the speed error detection time set by the parameter. Make sure that safety can be ensured during this period.
- Adjust the speed limit considering the risk of speed acceleration from an acceptable safe speed to an unacceptable speed due to the system response time.

Safe operating stop (SOS)

This function is used in applications with external force loads such as vertical axis applications. Servo drive failure can cause axis position hold failure. Evaluate the impact on the system and take hazard reduction or control measures such as mechanical braking.

Safe speed monitor (SSM)

- Speed monitoring function guarantees the servo motor speed, but it does not guarantee the actual machine safety speed. Set parameters so that the safe speed of the machine is the same as the safety speed of the specified motor.
- Check if the speed of the monitored servo axis is the same as the actual speed by using a tachometer, etc. considering the speed includes an error caused by the command and encoder resolution.
- The defect of the mechanical section such as slid of shaft and wanting of a timing belt, etc. is not covered. Be sure to eliminate the risk of mechanical section before operation.
- After speed is over the limit, safety observation error (shut-off signal off) does not occur during the speed error detection time set by the parameter. Make sure that safety can be ensured during this period.

 Adjust the speed limit considering the risk of speed acceleration from an acceptable safe speed to an unacceptable speed due to the system response time.

2 Product Information

2.1 Drive Model and Nameplate

Model description



| ① Product series SV680: SV680 general-purpose servo drive | Rated out | tput current | Model configurationI: Standard typeS: Functional safety type |
|---|-----------|--|--|
| ② Product type N: EtherCAT communication type P: Pulse type + CANopen communication type | S: 200 V | 1R6: 1.6 A 2R8: 2.8 A 5R5: 5.5 A 7R6: 7.6 A 012: 12.0 A 018: 18.0 A 022: 22.0 A 027: 27.0 A | © Model configuration GINT: General (global version) PINT: Backup power supply type (global version) |
| ③ Voltage class S: 200 V T: 400 V | T: 400 V | 3R5: 3.5 A 5R4: 5.4 A 8R4: 8.4 A 012: 12.0 A 017: 17.0 A 021: 21.0 A 026: 26.0 A | |

Nameplate



Figure 2-1 Nameplate

Encryption of the production serial number

$$\frac{01050202}{\tiny{\textcircled{1}}}~\frac{4}{\tiny{\textcircled{2}}}~\frac{P}{\tiny{\textcircled{3}}}~\frac{7}{\tiny{\textcircled{4}}}~\frac{00001}{\tiny{\textcircled{5}}}$$

| ① Internal code Article material code | ③ Year 9: 2009 A: 2010 P: 2022 Note: I/L/O/Q is not used. | ⑤ Lot number 00001: 1st in current month 00002: 2nd in current month 00003: 3rd in current month |
|---|--|--|
| ② Manufacturer code 4: Suzhou Inovance | Month 1: January 2: February A: October B: November C: December | Range: 00001 to 99999 |

Example: The S/N 010502024P700001 indicates the drive is manufactured in July, 2022.

2.2 Motor Model and Nameplate

Model description

| ① MS1 series servo motor | 4 Rated speed (rpm) One letter and two digits B: x 10 C: x 100 Example: 30C: 3,000 rpm | That Connection Mode 3: Solid shaft, with key and threaded hole |
|--|--|---|
| ② Inertia and Capacity H1: low inertia, small capacity H2: low inertia, medium capacity H3: medium inertia, medium capacity H4: medium inertia, small capacity | (S) Voltage Class (V) B: 220 D: 380 | Brake, Reducer and Oil Seal^[1] No oil seal and brake With oil seal but no brake No oil seal but with brake With oil seal and brake |

3 Rated Power (W) **6** Encoder Type Series One letter and one digit One letter and two digits R: R series B: x 10 A6: 26-bit multi-turn (10) Cable Connection and C: x 100 absolute encoder Cooling S6: 26-bit multi-turn Example: 75B: 750W _: connector type, natural absolute encoder of cooling functional safety type -S^[2]: flying leads type, A3: 23-bit multi-turn natural cooling absolute encoder -F: Air cooling T3: 18-bit multi-turn absolute encoder

Note

- [1]: The standard configuration of the motor in flange size 40 does not include the oil seal. Motors of other models carry the oil seal as standard.
- [2]: Motors (-S) with flying leads are only available in flange sizes 40/60/80.




Figure 2-2 Model and Nameplate

2.3 Description of the Encoder Model

Model description



| ① Sensor | ⑤ Shaft diameter, hole diameter, magnet diameter or gear modulus | Operating voltage (VDC)5: 530: 10 to 30 |
|----------|---|--|
| | 5: Ø5 | |
| | 62: Ø62 | |
| | 0.4: 0.4M | |

2 Product type

I: Incremental encoder
A: Low inertia, medium
capacity
MI: Incremental magnetic
encoder
MA: Absolute magnetic

6 Resolution

1024: 50–25000P/r B20: The single-turn resolution is 20. B20 M16: The single-turn resolution is 20 and multiturn resolution is 16. B26 M16: The single-turn

resolution is 26 and multiturn resolution is 16.

10 Sealing

Y: With sealing ring
N: Without sealing ring
E: Oil seal

3 Enclosure dimensions

35: Ø35 100: Ø100

encoder

7 Output signal

B: A, B C: A, B, Z D: A, ¬A^[1], B, ¬B E: A, ¬A, B, ¬B, Z, ¬Z *P: Magnetic pole *T: Weton protocol *A: CANopen protocol *V: DeviceNet protocol *M: Modbus protocol *ML: EtherCAT protocol *J: EtherNet/IP protocol *L: Powerlink protocol *N: Profinet protocol *O: Profisafe protocol *Q: Profibus DP protocol *S: SSI protocol *I: BISS protocol Note: * represents the number of pole pairs, including 2, 3, 4, 6, 8, 10, 12, 16, and 24; if the * is missing, it indicates that

11 Lead type

1: Side, rectangular receptacle
2: Rear, rectangular receptacle
3: Side, cable
4: Rear, cable

5: Customized

(4) Shaft structure

R: Universal joint

S: Solid H: Hollow M: Semi-hollow N: None C: Outer cone semi-hollow M: Inner cone semi-hollow

® Circuit output mode

the data is unavailable.

A: Operational amplifier
R: Complementary
C: Open-collector
V: Voltage
3D: Drive 26C31
5D: Drive 3487
6D: Drive 7272
7D: Drive WX
H: Drive WX
P: Drive Profibus data interface
S: Drive RS422

② Operating temperature (°C)

/T: -10°C to +110°C

12 Encoder type

_: General
S: Wiring-saving
Z: Single-turn incremental
No.: 2, 3, ..., N++1
FS: Functional safety type
Special vendor

Q: Qunma photocell
X: Photocell with slit
D: Photocell customized
J: High precision
correction

N: Drive CAN

E: Drive Ethernet

Note

- Only the following three types of encoders have been evaluated and certified: EA33H6-B26M16-TH5N1T; EA45H8-B26M16-TH5N1T; and EA79R8-B26M16-TH5Y3-FS.
- ¬A represents non-A, ¬B represents non-B, and ¬Z represents non-Z.

2.4 Cable Models

Power cable model

$$\frac{S6\text{-L-M}}{\tiny{\begin{subarray}{c} 0 \ 0 \ 1 \ \hline \begin{subarray}{c} 3.0 \\ \hline \begin{subarray}{c} 5 \ \hline \begin{subarray}{c} \hline \begin{subarray}{c} 5 \ \hline \begin{subarray}{c} 6 \ \hline \begin{subarray}{c} 5 \ \hline \begin{subarray}{c} 6 \ \hline \end{subarray} \end{array}} - \frac{INT}{\tiny{\begin{subarray}{c} 6 \ \hline \end{subarray}}}$$

| ① Cable type S6-L-B/M: motion control power cable B: with brake M: without brake | 3 Cable Size (mm²) 0: Flange sizes 25/40/60/80 1: frame sizes 100/130/180 (drive rated current < 13 A) 2: frame size 180 (drive rated current > 13 A) | (5) Cable Length (m) 3.0: 3 5.0: 5 10.0: 10 |
|---|---|--|
| ② Connector type at drive side0: U-shaped cable lug1: Needle-shaped cable lug | side 1: 9-core aviation | © Special requirements INT: Global version ^[1] |

Note

[1]: The material of the global version cables complies with CE and UL certification.

Encoder cable model

$$\underbrace{\begin{array}{c} \underline{\text{S6-L-P}} \ \underline{1} \ \underline{2} \ \underline{1}}_{\boxed{0}} - \underbrace{\begin{array}{c} \underline{3.0}}_{\boxed{6}} - \underbrace{\begin{array}{c} \underline{\text{INT}}}_{\boxed{6}} \end{array}$$

| ① Cable type S6-L-P: Motion control encoder cable | ③ Encoder2: Multi-turn absolute encoder | (5) Cable length (m) 3.0: 3 5.0: 5 10.0: 10 |
|---|---|---|
| ② Connector type at drive side 1: USB | 4 Connector type at motor side 1: 9-core aviation connector 4: SDC-06T series aviation connector (front outlet) | © Special requirements INT: Global version ^[1] |

Note

[1]: The material of the global version cables complies with CE and UL certification.

Communication cable model

$$\frac{\text{S6N-L-T}}{\tiny{\scriptsize{\scriptsize{\scriptsize{\scriptsize{1}}}}}}} \; \frac{00}{\tiny{\scriptsize{\scriptsize{\scriptsize{\scriptsize{\scriptsize{0}}}}}}} \; - \; \frac{3.0}{\tiny{\scriptsize{\scriptsize{\scriptsize{\scriptsize{\scriptsize{3}}}}}}}}$$

| Cable type S6-L-T: Motion control communication cable S6N-L-T: IS620F motion control encoder cable (only for servo drive to PC communication cable) | ② Cable connection type 00: Servo drive to PC communication cable 01: Servo drive network communication cable (CAN&485) 02: Servo drive to PLC communication cable 03: Servo drive communication termination resistor cable (CAN&485) 04: Servo drive network communication cable (EtherCAT) | ③ Cable length (m) 3.0: 3 5.0: 5 10.0: 10 |
|---|---|--|
|---|---|--|

2.5 Components

2.5.1 Servo Drives in Size A and Size C (Rated Power 0.2 kW to 1.5 kW)




Figure 2-3 Components of servo drive in size A and size C

Table 2–1 Description of components of servo drive in size A and size C

| No. | Name | Description |
|-----|--|---|
| 1 | CHARGE (bus voltage indicator) | When the indicator turns on, residual voltage may still be present in the internal capacitor of the servo unit, even if the power supply of the main circuit has been switched off. To prevent electric shock, do not touch the power supply terminals when this indicator lights up. |
| 2 | L1C, L2C (control circuit power input terminals) | Input the control circuit power supply according to the rated voltage class on the nameplate. |

| No. | Name | Description |
|------|--|--|
| 3 | L1, L2, L3 (main circuit power input terminals) ^[1] | Input the main circuit power supply according to the rated voltage class on the nameplate. |
| 4 | P⊕, D, C (terminals for connecting external braking resistor) | Remove the jumper bar between terminals P⊕ and D before connecting an external braking resistor between terminals P⊕ and C. |
| | P⊕, N⊖ (servo bus terminals) | Used by the common DC bus for multiple servo drives. |
| (5) | U, V, W (terminals for connecting the servo motor) | Connected to U, V, and W phases of the servo motor. |
| 6 | PE (grounding) terminal | Connected to the grounding terminal of the motor for grounding purpose. |
| 7 | CN8 (brake and PTC input terminal) | Used for wiring of the brake and motor temperature feedback. |
| 8 | Servo drive grounding terminal | Connected to the grounding terminal of the power supply for grounding purpose. |
| 9 | CN6 (STO safety function terminal) | Connected to external functional safety signal for functional safety purpose. For the description and function introduction of this terminal, see the corresponding function guide and hardware guide. |
| 10 | CN11 (24 V backup power input terminal) | When power failure occurs, the backup power supply can be connected for commissioning. |
| 11) | LED display | The 5-digit 8-segment LED display is used to show servo system's running state and parameter setting. |
| (1) | Power supply indicator of the safety module | Power: When the safety module is connected and the power supply is normal, the indicator is on. LINK: Safety communication status indicator Steady ON: FSoE is ready; flashing: communication is normal; OFF: FSoE is closed. |
| (13) | Keys | M: Switches parameters in sequence. ▲: Increases the value of the blinking bit. ▲: Decreases the value of the blinking bit. ◄: Shifts the blinking bit leftwards (Hold down: Turning to the next page when the displayed number exceeds five digits). S: Saves modifications and enters the next menu. |

| No. | Name | Description |
|------|--|---|
| 14) | CN5 communication terminal | Supports online upgrade and commissioning with the software tool when the drive is powered on. In USB mode, the terminal only supports download and upload of parameters, and drive firmware update; The terminal uses USB power supply. If there is a fault that cannot be completely reset, disconnect the USB power supply and control circuit power supply, and then power on again. |
| (15) | FSoE ID address setting knob | Sets ID address of the slave drive for FSoE communication. Address setting method: The number of the upper knob*16 + the number of the lower knob. |
| 16) | CN3, CN4 (EtherCAT communication terminals) | CN4 (IN): Connected to the master or the last slave device CN3 (OUT): Connected to the next slave device |
| 17 | Control terminal A of CN9 safety module | Control terminal A of the safety module |
| 18 | CN1 (control terminal) | Used by reference input signals and other I/O signals. |
| 19 | Control terminal B of CN10 safety module | Command input and output terminal B of the safety module |
| 20 | CN7 (encoder feedback terminal) | Supports communication-type encoders and pulse-type encoders. Supports gantry synchronization. |
| 21) | CN2 (encoder feedback terminal) | Supports communication-type encoders. Supports gantry synchronization. |

Note

- The built-in braking resistor or jumper bar is not available in models S1R6 and S2R8. If an external braking resistor is needed for these models, connect it between terminals P⊕ and C.
- [1] When the main circuit power input terminals of drives with a voltage class of 200 V to 240 V are L1, L2, L3 (or any two among L1, L2, and L3 in case of single-phase power supplies). The main circuit power input terminals of drives with a voltage class of 380 V to 480 V are R, S, and T.

2.5.2 Servo Drives in Size D (Rated Power 1.5 kW to 3.0 kW)




Figure 2-4 Components of servo drive in size D

Table 2–2 Description of components of servo drive in size D


| No. | Name | Description |
|-----|--|---|
| 1) | CHARGE (bus voltage indicator) | When the indicator turns on, residual voltage may still be present in the internal capacitor of the servo unit, even if the power supply of the main circuit has been switched off. To prevent electric shock, do not touch the power supply terminals when this indicator lights up. |
| 2 | L1C, L2C (control circuit power input terminals) | Input the control circuit power supply according to the rated voltage class on the nameplate. |
| 3 | L1, L2, L3 (main circuit power input terminals) ^[1] | Input the main circuit power supply according to the rated voltage class on the nameplate. |

| No. | Name | Description |
|------|--|--|
| 4 | P⊕, D, C (terminals for connecting external braking resistor) | Remove the jumper bar between terminals P⊕ and D before connecting an external braking resistor between terminals P⊕ and C. |
| | P⊕, N⊖ (servo bus terminals) | Used by the common DC bus for multiple servo drives. |
| (5) | U, V, W (terminals for connecting the servo motor) | Connected to U, V, and W phases of the servo motor. |
| 6 | PE (grounding) terminal | Connected to the grounding terminal of the motor for grounding purpose. |
| 7 | CN8 (brake and PTC input terminal) | Used for wiring of the brake and motor temperature feedback. |
| 8 | Servo drive grounding terminal | Connected to the grounding terminal of the power supply for grounding purpose. |
| 9 | CN6 (STO safety function terminal) | Connected to external functional safety signal for functional safety purpose. For the description and function introduction of this terminal, see the corresponding function guide and hardware guide. |
| (10) | CN11 (24 V backup power input terminal) | When power failure occurs, the backup power supply can be connected for commissioning. |
| (1) | LED display | The 5-digit 8-segment LED display is used to show servo system's running state and parameter setting. |
| 12 | Power supply indicator of the safety module | Power: When the safety module is connected and the power supply is normal, the indicator is on. LINK: Safety communication status indicator Steady ON: FSoE is ready; flashing: communication is normal; OFF: FSoE is closed. |
| (3) | Keys | M: Switches parameters in sequence. ▲: Increases the value of the blinking bit. ▲: Decreases the value of the blinking bit. ◄ : Shifts the blinking bit leftwards (Hold down: Turning to the next page when the displayed number exceeds five digits). S: Saves modifications and enters the next menu. |
| (4) | CN5 communication terminal | Supports online upgrade and commissioning with the software tool when the drive is powered on. In USB mode, the terminal only supports download and upload of parameters, and drive firmware update; The terminal uses USB power supply. If there is a fault that cannot be completely reset, disconnect the USB power supply and control circuit power supply, and then power on again. |

| No. | Name | Description |
|------|--|--|
| (15) | FSoE ID address setting knob | Sets ID address of the slave drive for FSoE communication. Address setting method: The number of the upper knob*16 + the number of the lower knob. |
| 16) | CN3, CN4 (EtherCAT communication terminals) | CN4 (IN): Connected to the master or the last slave device CN3 (OUT): Connected to the next slave device |
| 17) | Control terminal A of CN9 safety module | Control terminal A of the safety module |
| 18 | CN1 (control terminal) | Used by reference input signals and other I/O signals. |
| (19) | Control terminal B of CN10 safety module | Command input and output terminal B of the safety module |
| 20) | CN7 (encoder feedback terminal) | Supports communication-type encoders and pulse-type encoders. Supports gantry synchronization. |
| 21) | CN2 (encoder feedback terminal) | Supports communication-type encoders. Supports gantry synchronization. |

Note

- The built-in braking resistor or jumper bar is not available in models S1R6 and S2R8. If an external braking resistor is needed for these models, connect it between terminals P⊕ and C.
- [1] When the main circuit power input terminals of drives with a voltage class of 200 V to 240 V are L1, L2, L3 (or any two among L1, L2, and L3 in case of single-phase power supplies). The main circuit power input terminals of drives with a voltage class of 380 V to 480 V are R, S, and T.



2.5.3 Servo Drives in Size E (Rated Power 2.0 kW to 7.5 kW)

Figure 2-5 Components of servo drive in size E

Table 2–3 Description of components

| No. | Name | Description |
|-----|--|---|
| 1 | CHARGE (bus voltage indicator) | When the indicator turns on, residual voltage may still be present in the internal capacitor of the servo unit, even if the power supply of the main circuit has been switched off. To prevent electric shock, do not touch the power supply terminals when this indicator lights up. |
| 2 | L1C, L2C (control circuit power input terminals) | Input the control circuit power supply according to the rated voltage class on the nameplate. |
| 3 | L1, L2, L3 (main circuit power input terminals) ^[1] | Input the main circuit power supply according to the rated voltage class on the nameplate. |

| No. | Name | Description |
|------|--|--|
| 4 | U, V, W (terminals for connecting the servo motor) | Connected to U, V, and W phases of the servo motor. |
| (5) | N2, N1 (terminals for connecting external reactor) | Terminals N1 and N2 are jumpered by default. To suppress harmonics in the power supply, remove the jumper bar between terminals N1 and N2 first and connect an external DC reactor between terminals N1 and N2. |
| 6 | P⊕, D, C (terminals for connecting external braking resistor) | Remove the jumper bar between terminals P⊕ and D before connecting an external braking resistor between terminals P⊕ and C. |
| 7 | CN8 (brake and PTC input terminal) | Used for wiring of the brake and motor temperature feedback. |
| 8 | Servo drive grounding terminal | Connected to the grounding terminal of the power supply for grounding purpose. |
| 9 | CN6 (STO safety function terminal) | Connected to external functional safety signal for functional safety purpose. For the description and function introduction of this terminal, see the corresponding function guide and hardware guide. |
| 10 | CN11 (24 V backup power input terminal) | When power failure occurs, the backup power supply can be connected for commissioning. |
| (11) | LED display | The 5-digit 8-segment LED display is used to show servo system's running state and parameter setting. |
| 12 | Power supply indicator of the safety module | Power: When the safety module is connected and the power supply is normal, the indicator is on. LINK: Safety communication status indicator Steady ON: FSoE is ready; flashing: communication is normal; OFF: FSoE is closed. |
| 13 | Keys | M: Switches parameters in sequence. ▲: Increases the value of the blinking bit. ▲: Decreases the value of the blinking bit. ◄ : Shifts the blinking bit leftwards (Hold down: Turning to the next page when the displayed number exceeds five digits). S: Saves modifications and enters the next menu. |
| 14 | CN5 communication terminal | Supports online upgrade and commissioning with the software tool when the drive is powered on. In USB mode, the terminal only supports download and upload of parameters, and drive firmware update; The terminal uses USB power supply. If there is a fault that cannot be completely reset, disconnect the USB power supply and control circuit power supply, and then power on again. |

| No. | Name | Description |
|------|--|--|
| (15) | FSoE ID address setting knob | Sets ID address of the slave drive for FSoE communication. Address setting method: The number of the upper knob*16 + the number of the lower knob. |
| 16 | CN3, CN4 (EtherCAT communication terminals) | CN4 (IN): Connected to the master or the last slave device CN3 (OUT): Connected to the next slave device |
| 17 | Control terminal A of CN9 safety module | Control terminal A of the safety module |
| 18 | CN1 (control terminal) | Used by reference input signals and other I/O signals. |
| (19) | Control terminal B of CN10 safety module | Command input and output terminal B of the safety module |
| 20 | CN7 (encoder feedback terminal) | Supports communication-type encoders and pulse-type encoders. Supports gantry synchronization. |
| 21) | CN2 (encoder feedback terminal) | Supports communication-type encoders. Supports gantry synchronization. |

Note

- The built-in braking resistor or jumper bar is not available in models S1R6 and S2R8. If an external braking resistor is needed for these models, connect it between terminals P⊕ and C.
- [1] When the main circuit power input terminals of drives with a voltage class of 200 V to 240 V are L1, L2, L3 (or any two among L1, L2, and L3 in case of single-phase power supplies). The main circuit power input terminals of drives with a voltage class of 380 V to 480 V are R, S, and T.

2.6 List of Compatible Models

2.6.1 Selection of Functional Safety Drives and Motors

Table 2–4 Functional safety drives and compatible functional safety motors

| | Safet | y drive | | | Safety motor | | | | | |
|--|---|-----------------------------------|-----------|-----------------------------------|---------------------------------|----------------|------------------|------------------------------|--|--|
| Voltage class (V) | Size | Recom mended drive model | H01.10 | Brake-less motor model | Brake motor model | Flange size | Capacity (kW) | Safety encoder model | | |
| | Ratings of MS1H1 (n_N =3000 rpm, n_{max} =7000 rpm) motors | | | | | | | | | |
| 6: 1 | | | | MS1H1-05B30CB- S630Z-INT | MS1H1-05B30CB- S632Z-INT | 40 | 0.05 | EA33H6- B26M16- TH5N1T | | |
| Single- phase/ Three- phase 220 V | | S1R6 | 00002 | MS1H1-10B30CB- S630Z-INT | MS1H1-10B30CB- S632Z-INT | 40 | 0.1 | EA33H6- B26M16- TH5N1T | | |
| рпаѕе 220 v | Α | A | | MS1H1-20B30CB- S630R-INT | MS1H1-20B30CB- S632R-INT | 60 | 0.2 | EA45H8- B26M16- TH5N1T | | |
| Single- phase/ Three- phase 220 V | ase/ iree- | S2R8 | 00003 | MS1H1-40B30CB- S630R-INT | MS1H1-40B30CB- S632R-INT | 60 | 0.4 | EA45H8- B26M16- TH5N1T | | |
| Single- phase/ Three- phase 220 V | | S5R5 | 00005 | MS1H1-55B30CB- S630R-INT | MS1H1-55B30CB- S632R-INT | 80 | 0.55 | EA45H8- B26M16- TH5N1T | | |
| Single- phase/ Three- phase 220 V | C | C S5R5 | 00005 | MS1H1-75B30CB- S630R-INT | MS1H1-75B30CB- S632R-INT | 80 | 0.75 | EA45H8- B26M16- TH5N1T | | |
| Single- phase/ Three- phase 220 V | С | S7R6 | 00006 | MS1H1-10C30CB- S630R-INT | MS1H1-10C30CB- S632R-INT | 80 | 1.0 | EA45H8- B26M16- TH5N1T | | |
| | | ŀ | Ratings o | of MS1H2 (n _N =3000 r | rpm, n _{max} =6000 rpm |) motors | | | | |

| | Safet | y drive | | | Safety encoder | | | |
|--|-------|-----------------------------------|--------|-----------------------------|-----------------------------|----------------|------------------|--------------------------------|
| Voltage class (V) | Size | Recom mended drive model | H01.10 | Brake-less motor model | Brake motor model | Flange size | Capacity (kW) | Safety encoder model |
| Single- phase/ Three- phase 220 V | С | S7R6 | 00006 | MS1H2-10C30CB- S631R-INT | MS1H2-10C30CB- S634R-INT | 100 | 1.0 | EA79R8- B26M16-TH5Y3- FS |
| Three- phase 380 V | | T3R5 | 10001 | MS1H2-10C30CD- S631R-INT | MS1H2-10C30CD- S634R-INT | 100 | 1.0 | EA79R8- B26M16-TH5Y3- FS |
| Single- phase/ Three- phase 220 V | D | S012 | 00007 | MS1H2-15C30CB- S631R-INT | MS1H2-15C30CB- S634R-INT | 100 | 1.5 | EA79R8- B26M16-TH5Y3- FS |
| Three- phase 380 V | С | T5R4 | 10002 | MS1H2-15C30CD- S631R-INT | MS1H2-15C30CD- S634R-INT | 100 | 1.5 | EA79R8- B26M16-TH5Y3- FS |
| Three- phase 220 V | E | S018 | 00008 | MS1H2-20C30CB- S631R-INT | MS1H2-20C30CB- S634R-INT | 100 | 2.0 | EA79R8- B26M16-TH5Y3- FS |
| Three- phase 380 V | D | T8R4 | 10003 | MS1H2-20C30CD- S631R-INT | MS1H2-20C30CD- S634R-INT | 100 | 2.0 | EA79R8- B26M16-TH5Y3- FS |
| Three- phase 220 V | E | S022 | 00009 | MS1H2-25C30CB- S631R-INT | MS1H2-25C30CB- S634R-INT | 100 | 2.5 | EA79R8- B26M16-TH5Y3- FS |
| Three- phase 380 V | D | T8R4 | 10003 | MS1H2-25C30CD- S631R-INT | MS1H2-25C30CD- S634R-INT | 100 | 2.5 | EA79R8- B26M16-TH5Y3- FS |
| Three- phase 220 V | E | S022 | 00009 | MS1H2-30C30CB- S631R-INT | MS1H2-30C30CB- S634R-INT | 130 | 3.0 | EA79R8- B26M16-TH5Y3- FS |
| Three- phase 380 V | D | T012 | 10004 | MS1H2-30C30CD- S631R-INT | MS1H2-30C30CD- S634R-INT | 130 | 3.0 | EA79R8- B26M16-TH5Y3- FS |
| Three- phase 220 V | | S027 | 00010 | MS1H2-40C30CB- S631R-INT | MS1H2-40C30CB- S634R-INT | 130 | 4.0 | EA79R8- B26M16-TH5Y3- FS |
| Three- phase 380 V | _ | T017 | 10005 | MS1H2-40C30CD- S631R-INT | MS1H2-40C30CD- S634R-INT | 130 | 4.0 | EA79R8- B26M16-TH5Y3- FS |
| Three- phase 220 V | E | S027 | 00010 | MS1H2-50C30CB- S631R-INT | MS1H2-50C30CB- S634R-INT | 130 | 5.0 | EA79R8- B26M16-TH5Y3- FS |
| Three- phase 380 V | | T021 | 10006 | MS1H2-50C30CD- S631R-INT | MS1H2-50C30CD- S634R-INT | 130 | 5.0 | EA79R8- B26M16-TH5Y3- FS |

| | Safet | y drive | | | Safety encoder | | | | |
|--|------------|-----------------------------------|-----------|-----------------------------------|---------------------------------|----------------|------------------|--------------------------------|--|
| Voltage class (V) | Size | Recom mended drive model | H01.10 | Brake-less motor model | Brake motor model | Flange size | Capacity (kW) | Safety encoder model | |
| Ratings of MS1H3 (n _N =1500 rpm, n _{max} =4500 rpm) series motors | | | | | | | | | |
| Single- phase/ Three- phase 220 V | С | S7R6 | 00006 | MS1H3-85B15CB- S631R-INT | MS1H3-85B15CB- S634R-INT | 130 | 0.85 | EA79R8- B26M16-TH5Y3- FS | |
| Three- phase 380 V | | T3R5 | 10001 | MS1H3-85B15CD- S631R-INT | MS1H3-85B15CD- S634R-INT | 130 | 0.85 | EA79R8- B26M16-TH5Y3- FS | |
| Single- phase/ Three- phase 220 V | D | S012 | 00007 | MS1H3-13C15CB- S631R-INT | MS1H3-13C15CB- S634R-INT | 130 | 1.3 | EA79R8- B26M16-TH5Y3- FS | |
| Three- phase 380 V | С | T5R4 | 10002 | MS1H3-13C15CD- S631R-INT | MS1H3-13C15CD- S634R-INT | 130 | 1.3 | EA79R8- B26M16-TH5Y3- FS | |
| Three- phase 220 V | D | S018 | 00008 | MS1H3-18C15CB- S631R-INT | MS1H3-18C15CB- S634R-INT | 130 | 1.8 | EA79R8- B26M16-TH5Y3- FS | |
| Three- phase 380 V | D | T8R4 | 10003 | MS1H3-18C15CD- S631R-INT | MS1H3-18C15CD- S634R-INT | 130 | 1.8 | EA79R8- B26M16-TH5Y3- FS | |
| Three- phase 220 V | S022 00009 | | 00009 | MS1H3-29C15CB- S631R-INT | MS1H3-29C15CB- S634R-INT | 180 | 2.9 | EA79R8- B26M16-TH5Y3- FS | |
| Three- phase 380 V | E | T012 | 10004 | MS1H3-29C15CD- S631R-INT | MS1H3-29C15CD- S634R-INT | 180 | 2.9 | EA79R8- B26M16-TH5Y3- FS | |
| Three- phase 220 V | E | S027 | 00010 | MS1H3-44C15CB- S631R-INT | MS1H3-44C15CB- S634R-INT | 180 | 4.4 | EA79R8- B26M16-TH5Y3- FS | |
| Three- phase 380 V | | T017 | 10005 | MS1H3-44C15CD- S631R-INT | MS1H3-44C15CD- S634R-INT | 180 | 4.4 | EA79R8- B26M16-TH5Y3- FS | |
| Three- phase 380 V | E | T021 | 10006 | MS1H3-55C15CD- S631R-INT | MS1H3-55C15CD- S634R-INT | 180 | 5.5 | EA79R8- B26M16-TH5Y3- FS | |
| Three- phase 380 V | | T026 | 10007 | MS1H3-75C15CD- S631R-INT | MS1H3-75C15CD- S634R-INT | 180 | 7.5 | EA79R8- B26M16-TH5Y3- FS | |
| | | - | Ratings c | of MS1H4 (n _N =3000 r | rpm, n _{max} =7000 rpm |) motors | | | |

| | Safet | y drive | | | Safety motor | | | Safety encoder |
|--|-------|-----------------------------------|--------|-----------------------------|-----------------------------|----------------|------------------|------------------------------|
| Voltage class (V) | Size | Recom mended drive model | H01.10 | Brake-less motor model | Brake motor model | Flange size | Capacity (kW) | Safety encoder model |
| Single- phase/ | | CIDE | 00002 | MS1H4-10B30CB- S630Z-INT | MS1H4-10B30CB- S632Z-INT | 40 | 0.1 | EA33H6- B26M16- TH5N1T |
| Three- phase 220 V | А | S1R6 | 00002 | MS1H4-20B30CB- S631R-INT | MS1H4-20B30CB- S634R-INT | 60 | 0.2 | EA45H8- B26M16- TH5N1T |
| Single- phase/ Three- phase 220 V | | S2R8 | 00003 | MS1H4-40B30CB- S631R-INT | MS1H4-40B30CB- S634R-INT | 60 | 0.4 | EA45H8- B26M16- TH5N1T |
| Single- phase/ Three- phase 220 V | C | S5R5 | 00005 | MS1H4-55B30CB- S631R-INT | MS1H4-55B30CB- S634R-INT | 80 | 0.55 | EA45H8- B26M16- TH5N1T |
| Single- phase/ Three- phase 220 V | | S5R5 | 00005 | MS1H4-75B30CB- S631R-INT | MS1H4-75B30CB- S634R-INT | 80 | 0.75 | EA45H8- B26M16- TH5N1T |
| Single- phase/ Three- phase 220 V | С | S7R6 | 00006 | MS1H4-10C30CB- S631R-INT | MS1H4-10C30CB- S634R-INT | 80 | 1.0 | EA45H8- B26M16- TH5N1T |

Table 2–5 Functional safety drives and compatible servo motors

| | Safety | y drive | | | Servo motor | | | | |
|---------------------------------------|---|-----------------------------------|--------|-----------------------------|-----------------------------|----------------|------------------|--|--|
| Voltage class (V) | Size | Recom mended drive model | H01.10 | Brake-less motor model | Brake motor model | Flange size | Capacity (kW) | | |
| | Ratings of MS1H1 (n _N =3000 rpm, n _{max} =7000 rpm) motors | | | | | | | | |
| Cinala abasa/ | | | | MS1H1-05B30CB-A630Z- INT | MS1H1-05B30CB-A632Z- INT | 40 | 0.05 | | |
| Single-phase/ Three-phase 220 V | | S1R6 | 00002 | MS1H1-10B30CB-A630Z- INT | MS1H1-10B30CB-A632Z- INT | 40 | 0.1 | | |
| 220 V | Α | | | MS1H1-20B30CB-A630R- INT | MS1H1-20B30CB-A632R- INT | 60 | 0.2 | | |
| Single-phase/ Three-phase 220 V | | S2R8 | 00003 | MS1H1-40B30CB-A630R- INT | MS1H1-40B30CB-A632R- INT | 60 | 0.4 | | |

| | Safety | / drive | | | Servo motor | | | | |
|---------------------------------------|--------|-----------------------------------|-------------|--|------------------------------|----------------|------------------|--|--|
| Voltage class (V) | Size | Recom mended drive model | H01.10 | Brake-less motor model | Brake motor model | Flange size | Capacity (kW) | | |
| Single-phase/ Three-phase 220 V | С | S5R5 | 00005 | MS1H1-55B30CB- A630R- INT | MS1H1-55B30CB- A632R- INT | 80 | 0.55 | | |
| Single-phase/ Three-phase 220 V | C | S5R5 | 00005 | MS1H1-75B30CB- A630R- INT | MS1H1-75B30CB- A632R- INT | 80 | 0.75 | | |
| Single-phase/ Three-phase 220 V | С | S7R6 | 00006 | MS1H1-10C30CB- A630R- INT | MS1H1-10C30CB- A632R- INT | 80 | 1.0 | | |
| | | Ratin | gs of MS1H | H2 (n _N =3000 rpm, n _{max} = | 6000 rpm) motors | | | | |
| Single-phase/ Three-phase 220 V | С | S7R6 | 00006 | MS1H2-10C30CB-A631R- INT | MS1H2-10C30CB-A634R- INT | 100 | 1.0 | | |
| Three-phase 380 V | | T3R5 | 10001 | MS1H2-10C30CD-A631R-INT | MS1H2-10C30CD-A634R- INT | 100 | 1.0 | | |
| Single-phase/ Three-phase 220 V | D | S012 | 00007 | MS1H2-15C30CB-A631R- INT | MS1H2-15C30CB-A634R- INT | 100 | 1.5 | | |
| Three-phase 380 V | С | T5R4 | 10002 | MS1H2-15C30CD-A631R- INT | MS1H2-15C30CD-A634R- INT | 100 | 1.5 | | |
| Three-phase 220 V | Е | S018 | 80000 | MS1H2-20C30CB-A631R- INT | MS1H2-20C30CB-A634R- INT | 100 | 2.0 | | |
| Three-phase 380 V | D | T8R4 | 10003 | MS1H2-20C30CD-A631R- INT | MS1H2-20C30CD-A634R- INT | 100 | 2.0 | | |
| Three-phase 220 V | E | S022 | 00009 | MS1H2-25C30CB-A631R- INT | MS1H2-25C30CB-A634R- INT | 100 | 2.5 | | |
| Three-phase 380 V | D | T8R4 | 10003 | MS1H2-25C30CD-A631R- INT | MS1H2-25C30CD-A634R- INT | 100 | 2.5 | | |
| Three-phase 220 V | E | S022 | 00009 | MS1H2-30C30CB-A631R- INT | MS1H2-30C30CB-A634R- INT | 130 | 3.0 | | |
| Three-phase 380 V | D | T012 | 10004 | MS1H2-30C30CD-A631R- INT | MS1H2-30C30CD-A634R- INT | 130 | 3.0 | | |
| Three-phase 220 V | | S027 | 00010 | MS1H2-40C30CB-A631R- INT | MS1H2-40C30CB-A634R- INT | 130 | 4.0 | | |
| Three-phase 380 V | Е | T017 | 10005 | MS1H2-40C30CD-A631R- INT | MS1H2-40C30CD-A634R- INT | 130 | 4.0 | | |
| Three-phase 220 V | | S027 | 00010 | MS1H2-50C30CB-A631R- INT | MS1H2-50C30CB-A634R- INT | 130 | 5.0 | | |
| Three-phase 380 V | | T021 | 10006 | MS1H2-50C30CD-A631R- INT | MS1H2-50C30CD-A634R- INT | 130 | 5.0 | | |
| | | Rating | gs of MS1H3 | (n _N =1500 rpm, n _{max} =4500 | rpm) series motors | | | | |

| | Safety | y drive | | | Servo motor | | |
|---------------------------------------|--------|-----------------------------------|------------|--|-----------------------------|----------------|------------------|
| Voltage class (V) | Size | Recom mended drive model | H01.10 | Brake-less motor model | Brake motor model | Flange size | Capacity (kW) |
| Single-phase/ Three-phase 220 V | С | S7R6 | 00006 | MS1H3-85B15CB-A631R- INT | MS1H3-85B15CB-A634R- INT | 130 | 0.85 |
| Three-phase 380 V | | T3R5 | 10001 | MS1H3-85B15CD-A631R- INT | MS1H3-85B15CD-A634R- INT | 130 | 0.85 |
| Single-phase/ Three-phase 220 V | D | S012 | 00007 | MS1H3-13C15CB-A631R- INT | MS1H3-13C15CB-A634R- INT | 130 | 1.3 |
| Three-phase 380 V | С | T5R4 | 10002 | MS1H3-13C15CD-A631R- INT | MS1H3-13C15CD-A634R- INT | 130 | 1.3 |
| Three-phase 220 V | D | S018 | 00008 | MS1H3-18C15CB-A631R- INT | MS1H3-18C15CB-A634R- INT | 130 | 1.8 |
| Three-phase 380 V | D | T8R4 | 10003 | MS1H3-18C15CD-A631R- INT | MS1H3-18C15CD-A634R- INT | 130 | 1.8 |
| Three-phase 220 V | _ | S022 | 00009 | MS1H3-29C15CB-A631R- INT | MS1H3-29C15CB-A634R- INT | 180 | 2.9 |
| Three-phase 380 V | E | T012 | 10004 | MS1H3-29C15CD-A631R- INT | MS1H3-29C15CD-A634R- INT | 180 | 2.9 |
| Three-phase 220 V | Е | S027 | 00010 | MS1H3-44C15CB-A631R- INT | MS1H3-44C15CB-A634R- INT | 180 | 4.4 |
| Three-phase 380 V | | T017 | 10005 | MS1H3-44C15CD-A631R- INT | MS1H3-44C15CD-A634R- INT | 180 | 4.4 |
| Three-phase 380 V | E | T021 | 10006 | MS1H3-55C15CD-A631R- INT | MS1H3-55C15CD-A634R- INT | 180 | 5.5 |
| Three-phase 380 V | | T026 | 10007 | MS1H3-75C15CD-A631R- INT | MS1H3-75C15CD-A634R- INT | 180 | 7.5 |
| | | Ratin | gs of MS1H | 4 (n _N =3000 rpm, n _{max} = | 7000 rpm) motors | | |
| Single-phase/ | | CIDC | 00002 | MS1H4-10B30CB-A630Z- INT | MS1H4-10B30CB-A632Z- INT | 40 | 0.1 |
| Three-phase 220 V | А | S1R6 | 00002 | MS1H4-20B30CB-A631R- INT | MS1H4-20B30CB-A634R- INT | 60 | 0.2 |
| Single-phase/ Three-phase 220 V | | S2R8 | 00003 | MS1H4-40B30CB-A631R- INT | MS1H4-40B30CB-A634R- INT | 60 | 0.4 |
| Single-phase/ Three-phase 220 V | С | S5R5 | 00005 | MS1H4-55B30CB-A631R- INT | MS1H4-55B30CB-A634R- INT | 80 | 0.55 |
| Single-phase/ Three-phase 220 V | C | S5R5 | 00005 | MS1H4-75B30CB-A631R- INT | MS1H4-75B30CB-A634R- INT | 80 | 0.75 |

| | Safety | / drive | | Servo motor | | | |
|---------------------------------------|--------|-----------------------------------|--------|-----------------------------|-----------------------------|----------------|------------------|
| Voltage class (V) | Size | Recom mended drive model | H01.10 | Brake-less motor model | Brake motor model | Flange size | Capacity (kW) |
| Single-phase/ Three-phase 220 V | С | S7R6 | 00006 | MS1H4-10C30CB-A631R- INT | MS1H4-10C30CB-A634R- INT | 80 | 1.0 |

Note

The asterisk (*) indicates the encoder type, which can be S6 (26-bit multi-turn absolute encoder of functional safety type) or A6 (26-bit multi-turn absolute encoder).

Safety functions SS1-r/SLS/SSM/SOS/SS2/SDI require the use of safety motor, while safety functions SS1-t/STO/SBC do not.

2.6.2 Selection of Standard Drives and Motors

| Servo motor | | | Servo drive SV680-INT series | | | | |
|-----------------------------------|-----------------------------------|-------------------------|---------------------------------|---------------------------------------|-------|--------------------------------|-------|
| Models without brake | Models with Brake | Flange size (mm) | Capacity (kW) | Voltage class (V) | Size | Recommend ed drive model | Code |
| | Ratings of MS1H1 (| n _N =3000 rp | om, n _{max} = | 7000 rpm) m | otors | | |
| MS1H1-05B30CB-A3/A6/ S630Z-INT | MS1H1-05B30CB-A3/A6/ S632Z-INT | 40 | 0.05 | Single-phase/ Three-phase 200 V | | | 00002 |
| MS1H1-10B30CB-A3/A6/ S630Z-INT | MS1H1-10B30CB-A3/A6/ S632Z-INT | 40 | 0.1 | Single-phase/ Three-phase 200 V | | S1R6 | |
| MS1H1-20B30CB-A3/A6/ S630R-INT | MS1H1-20B30CB-A3/A6/ S632R-INT | 60 | 0.2 | Single-phase/ Three-phase 200 V | | | |
| MS1H1-40B30CB-A3/A6/ S630R-INT | MS1H1-40B30CB-A3/A6/ S632R-INT | 60 | 0.4 | Single-phase/ Three-phase 200 V | | S2R8 | 00003 |
| MS1H1-55B30CB-A3/A6/ S630R-INT | - | 80 | 0.55 | Single-phase/ Three-phase 200 V | C | S5R5 | 00005 |
| MS1H1-75B30CB-A3/A6/ S630R-INT | MS1H1-75B30CB-A3/A6/ S632R-INT | 80 | 0.75 | Single-phase/ Three-phase 200 V | | S5R5 | 00005 |

| Servo motor | | | Servo drive SV680-INT series | | | | |
|--|-----------------------------------|-------------------------|---------------------------------|---------------------------------------|-------|--------------------------------|-------|
| Models without brake | Models with Brake | Flange size (mm) | Capacity (kW) | Voltage class (V) | Size | Recommend ed drive model | Code |
| MS1H1-10C30CB-A3/A6/ S630R-INT | MS1H1-10C30CB-A3/A6/ S632R-INT | 80 | 1.0 | Single-phase/ Three-phase 200 V | С | S7R6 | 00006 |
| | Ratings of MS1H2 (| n _N =3000 rp | m, n _{max} = | 6000 rpm) m | otors | | |
| MS1H2-10C30CB-A3/A6/ S631R-INT | MS1H2-10C30CB-A3/A6/ S634R-INT | 100 | 1.0 | Single-phase/ Three-phase 200 V | С | S7R6 | 00006 |
| MS1H2-10C30CD-A3/A6/ S631R-INT | MS1H2-10C30CD-A3/A6/ S634R-INT | 100 | 1.0 | Three-phase 400 V | | T3R5 | 10001 |
| MS1H2-15C30CB-A3/A6/ S631R-INT | MS1H2-15C30CB-A3/A6/ S634R-INT | 100 | 1.5 | Single-phase/ Three-phase 200 V | D | S012 | 00007 |
| MS1H2-15C30CD-A3/A6/ S631R-INT | MS1H2-15C30CD-A3/A6/ S634R-INT | 100 | 1.5 | Three-phase 400 V | С | T5R4 | 10002 |
| MS1H2-20C30CB-A3/A6/ S631R-INT | MS1H2-20C30CB-A3/A6/ S634R-INT | 100 | 2.0 | Three-phase 200 V | E | S018 | 80000 |
| MS1H2-20C30CD-A3/A6/ S631R-INT | MS1H2-20C30CD-A3/A6/ S634R-INT | 100 | 2.0 | Three-phase 400 V | D | T8R4 | 10003 |
| MS1H2-25C30CB-A3/A6/ S631R-INT | MS1H2-25C30CB-A3/A6/ S634R-INT | 100 | 2.5 | Three-phase 200 V | E | S022 | 00009 |
| MS1H2-25C30CD-A3/A6/ S631R-INT | MS1H2-25C30CD-A3/A6/ S634R-INT | 100 | 2.5 | Three-phase 400 V | D | T8R4 | 10003 |
| MS1H2-30C30CB-A3/A6/ S631R-INT | MS1H2-30C30CB-A3/A6/ S634R-INT | 130 | 3.0 | Three-phase 200 V | E | S022 | 00009 |
| MS1H2-30C30CD-A3/A6/ S631R-INT | MS1H2-30C30CD-A3/A6/ S634R-INT | 130 | 3.0 | Three-phase 400 V | D | T012 | 10004 |
| MS1H2-40C30CB-A3/A6/ S631R-INT | MS1H2-40C30CB-A3/A6/ S634R-INT | 130 | 4.0 | Three-phase 200 V | | S027 | 00010 |
| MS1H2-40C30CD-A3/A6/ S631R-INT | MS1H2-40C30CD-A3/A6/ S634R-INT | 130 | 4.0 | Three-phase 400 V | - | T017 | 10005 |
| MS1H2-50C30CB-A3/A6/ S631R-INT | MS1H2-50C30CB-A3/A6/ S634R-INT | 130 | 5.0 | Three-phase 200 V | E | S027 | 00010 |
| MS1H2-50C30CD-A3/A6/ S631R-INT | MS1H2-50C30CD-A3/A6/ S634R-INT | 130 | 5.0 | Three-phase 400 V | | T021 | 10006 |
| Ratings of MS1H3 (n _N =1500 rpm, n _{max} =4500 rpm) series motors | | | | | | | |
| MS1H3-85B15CB-A3/A6/ S631R-INT | MS1H3-85B15CB-A3/A6/ S634R-INT | 130 | 0.85 | Single-phase/ Three-phase 200 V | С | S7R6 | 00006 |
| MS1H3-85B15CD-A3/A6/ S631R-INT | MS1H3-85B15CD-A3/A6/ S634R-INT | 130 | 0.85 | Three-phase 400 V | | T3R5 | 10001 |

| Servo motor | | | Servo drive SV680-INT series | | | | |
|-----------------------------------|-----------------------------------|-------------------------|---------------------------------|---------------------------------------|-------|--------------------------------|-------|
| Models without brake | Models with Brake | Flange size (mm) | Capacity (kW) | Voltage class (V) | Size | Recommend ed drive model | Code |
| MS1H3-13C15CB-A3/A6/ S631R-INT | MS1H3-13C15CB-A3/A6/ S634R-INT | 130 | 1.3 | Single-phase/ Three-phase 200 V | D | S012 | 00007 |
| MS1H3-13C15CD-A3/A6/ S631R-INT | MS1H3-13C15CD-A3/A6/ S634R-INT | 130 | 1.3 | Three-phase 400 V | С | T5R4 | 10002 |
| MS1H3-18C15CB-A3/A6/ S631R-INT | MS1H3-18C15CB-A3/A6/ S634R-INT | 130 | 1.8 | Three-phase 200 V | E | S018 | 80000 |
| MS1H3-18C15CD-A3/A6/ S631R-INT | MS1H3-18C15CD-A3/A6/ S634R-INT | 130 | 1.8 | Three-phase 400 V | D | T8R4 | 10003 |
| MS1H3-29C15CB-A3/A6/ S631R-INT | MS1H3-29C15CB-A3/A6/ S634R-INT | 180 | 2.9 | Three-phase 200 V | Е | S022 | 00009 |
| MS1H3-29C15CD-A3/A6/ S631R-INT | MS1H3-29C15CD-A3/A6/ S634R-INT | 180 | 2.9 | Three-phase 400 V | D | T012 | 10004 |
| MS1H3-44C15CB-A3/A6/ S631R-INT | MS1H3-44C15CB-A3/A6/ S634R-INT | 180 | 4.4 | Three-phase 200 V | E | S027 | 00010 |
| MS1H3-44C15CD-A3/A6/ S631R-INT | MS1H3-44C15CD-A3/A6/ S634R-INT | 180 | 4.4 | Three-phase 400 V | | T017 | 10005 |
| MS1H3-55C15CD-A3/A6/ S631R-INT | MS1H3-55C15CD-A3/A6/ S634R-INT | 180 | 5.5 | Three-phase 400 V | Е | T021 | 10006 |
| MS1H3-75C15CD-A3/A6/ S631R-INT | MS1H3-75C15CD-A3/A6/ S634R-INT | 180 | 7.5 | Three-phase 400 V | | T026 | 10007 |
| | Ratings of MS1H4 (| n _N =3000 rp | om, n _{max} = | 7000 rpm) m | otors | | |
| MS1H4-10B30CB-A3/A6/ S630Z-INT | MS1H4-10B30CB-A3/A6/ S632Z-INT | 40 | 0.1 | Single-phase/ Three-phase 200 V | | S1R6 | 00002 |
| MS1H4-20B30CB-A3/A6/ S631R-INT | MS1H4-20B30CB-A3/A6/ S634R-INT | 60 | 0.2 | Single-phase/ Three-phase 200 V | А | S1R6 | 00002 |
| MS1H4-40B30CB-A3/A6/ S631R-INT | MS1H4-40B30CB-A3/A6/ S634R-INT | 60 | 0.4 | Single-phase/ Three-phase 200 V | | S2R8 | 00003 |
| MS1H4-55B30CB-A3/A6/ S631R-INT | - | 80 | 0.55 | Single-phase/ Three-phase 200 V | С | S5R5 | 00005 |
| MS1H4-75B30CB-A3/A6/ S631R-INT | MS1H4-75B30CB-A3/A6/ S634R-INT | 80 | 0.75 | Single-phase/ Three-phase 200 V | C | S5R5 | 00005 |
| MS1H4-10C30CB-A3/A6/ S631R-INT | MS1H4-10C30CB-A3/A6/ S634R-INT | 80 | 1.0 | Single-phase/ Three-phase 200 V | С | S7R6 | 00006 |

3 Operating Panel

3.1 Components




Figure 3-1 Appearance of the keypad

The keypad of the SV680-INT series servo drive consists of a 5-digit, 8-segment LED screen, 5 keys and 4 status indicators. The keypad is used for value display, parameter setting, user password setting and general function execution.

Keys

The following table takes parameter setting as an example to describe the general functions of the keys.

Description **Appearance** Name Switches among different modes. MODE Returns to the previous menu. Increases the value of the blinking digit for the UP LED. Decreases the value of the blinking digit for the DOWN LED. Shifts the blinking digit for the LED. You can view the high digits of the number SHIFT consisting of more than 5 digits. Switches to the lower-level menu. Executes commands such as saving parameter SET setpoints.

Table 3–1 Descriptions of keys

Indicators

Note

The description of Indicators is only available for model N.




Figure 3-2 Description of indicator status

Table 3–2 Description of indicator status

| Indicator | Status | Status indication |
|-----------|---|-----------------------------|
| | OFF | INIT state |
| | Flashing (ON for 200 ms/OFF for 200 ms) | Pre-operational |
| RUN | Single flashing (ON for 200 ms/OFF for 1000 ms) | Safe-operational |
| | ON | Operational state |
| | OFF | No network error |
| | Flashing (ON for 200 ms/OFF for 200 ms) | Communication setting error |
| ERR | Single flashing (ON for 200 ms/OFF for 1000 ms) | Sync event error |
| | Double flashing (ON for 200 ms, OFF for 200 ms, ON for 200 ms, and OFF for 1000 ms) | Watchdog timeout |

| Indicator | Status | Status indication | | |
|--|---|--|--|--|
| | OFF | Link is not established. | | |
| L/A IN indicator ^[1] L/A OUT indicator | Flickering (ON for 50 ms/OFF for 50 ms) | Link is established. A data transceiving signal is present. | | |
| L/A OOT IIIdicator | ON | Link is established. No data transceiving signal is present. | | |

Note

- [1]: L/A IN and L/A OUT indicate the LINK state and action state of the physical layer of each port.
- The ERR indicator lights up red and the other three indicators light up green.

3.2 Display

The keypad can display the parameters and faults of the servo drive.

- Parameter display: Displays parameters and their setpoints.
- Fault display: Displays faults and alarms that occurred on the servo drive.

Parameter Display

| Display | Name | Description |
|---------|-----------|---|
| HXX.YY | Parameter | XX: Parameter group No. (decimal) YY: Offset within the parameter group (hexadecimal) |

For example, "H02.00" is displayed as follows.

| Display | Name | Description | | |
|---------|--------|---|--|--|
| H02.00 | H02 00 | 02: Parameter group No. 00: Offset within the parameter group | | |

Fault Display

- The keypad can be used to display present or previous fault and alarm codes. For analysis and solutions to the faults and alarms, see Chapter "Troubleshooting".
- When a fault or alarm occurs, the keypad displays the corresponding fault or alarm code immediately. When multiple faults or alarms occur, the keypad displays the fault code of the highest fault level.
- You can select the previous fault/alarm to be viewed through H0b.33 and view the code of the selected fault/alarm in H0b.34.

• You can clear the latest 20 faults or alarms saved in the servo drive by setting H02.31 to "2".

For example, E941.0 is displayed as follows.

| Display | Name | Description |
|-----------|----------------------|--|
| E 9 4 1.0 | E941.0 Alarm code | E: A fault or alarm occurs on the servo drive. 941.0: Alarm code |

4 Installation

Read through the safety instructions in Chapter "Fundamental Safety Instructions". Failure to comply may result in serious consequence.



- Observe the installation direction described in this chapter. Failure to comply may result in equipment fault or damage.
- Do not install or operate damaged or defective equipment. Failure to comply can result in personal injury.
- Do not install the equipment in environments exposed to water splashes or corrosive gases. Failure to comply can result in equipment fault.
- Do not install the equipment near inflammable gases or combustible objects. Failure to comply can result in a fire or electric shock.
- Install the equipment inside a fire-proof cabinet that provides electrical protection. Failure to comply may result in a fire.
- Ensure the specified clearance is reserved among the servo drive, the interior surface of the control cabinet, and other machines. Failure to comply can result in a fire or equipment fault.
- Do not put heavy objects on the equipment. Failure to comply may result in personal injury or equipment damage.
- Do not subject the equipment to strong shock. Failure to comply may result in equipment damage.
- Do not block the air inlet/outlet of the equipment or allow unwanted objects to fall into the equipment. Failure to comply may result in a fire or equipment fault.

4.1 Unpacking and Handling

Check the following items upon unpacking.

| Item | Description |
|--|---|
| Check whether the delivered product is consistent with your order. | Check whether the servo drive model and specifications comply with your order. See the dimensions of the packing box in "Table 4-1" on page 54. The deliverables include the product, cushion, carton box, and screw bag, as shown in "Figure 4-1" on page 54. |
| Check whether the product is intact. | Check whether the product delivered is in good condition. If there is any missing or damage, contact Inovance or your supplier immediately. |

Table 4–1 Dimensions of the outer packing box

| | | Outer | Outer | Outer | Weight |
|------|------------------------------------|-------|--------|-------|--------|
| Size | Model | Width | Height | Depth | Ö |
| | | (mm) | (mm) | (mm) | (kg) |
| А | S1R6, S2R8 | 250.0 | 110.0 | 200.0 | 1.28 |
| С | S5R5, S7R6, T3R5, T5R4 | 235.0 | 125.0 | 215.0 | 1.65 |
| D | S012, T8R4, T012 | 235.0 | 150.0 | 225.0 | 2.15 |
| Е | S018, S022, S027, T017, T021, T026 | 320.0 | 170.0 | 280.0 | 4.05 |




Figure 4-1 Contents inside the packing box

| No. | Name |
|-----|------------------------|
| 1) | Product |
| 2 | Terminal accessory kit |
| 3 | Cushion |
| 4 | Carton box |

Table 4–2 Contents of the terminal accessory kit

| Material Code | Name | Quantity |
|---------------|--|----------|
| 1504CK54 | Cable set - Servo drive S6 - C74-DB26 connector kit (RoHS) | 1 |
| 15210577 | Pluggable terminal block - Connector - Spring clamp- type wiring - 9P - Black - With safety lock | 1 |
| 15210648 | Pluggable terminal block - Connector - Spring clamp wiring - 2x2P - Black-printing on both sides | 1 |
| 15210695 | Pluggable terminal block - Connector - Spring clamp- type wiring - 4P - Black | 1 |
| 15211052 | Pluggable terminal block - Connector - Spring clamp wiring-/3.5 mm - 2x3P - Black - 180° - Screen printed - RoHS | 1 |
| 15220274 | Jumper bar - 16A - Pluggable bridge | 1 |
| 19024735 | Labels - Labels for servo drive terminals | 1 |
| 2120021 | Plastic parts - Connector wiring key - For use with servo drive power connector | 1 |
| 15212326 | Pluggable terminal block - Connector - Spring clamp- type wiring -/-3.5 mm - 1x2P - Orange - 180° - RoHS | 1 |
| 15212114 | Pluggable terminal block - Connector - Spring clamp wiring-/-3.5 mm - 2x7P - Black - 180° - Push rod at both sides - RoHS | 1 |
| 15212115 | Pluggable terminal block - Connector - Spring clamp wiring - NA - 3.5 mm - 2x7P - Black - 180°-push rod at both sides - RoHS | 1 |

Note

Note that the terminal accessories package list of SV680 is slightly different from that of SV680N.

If you need to purchase the terminal accessory kit separately, contact Inovance. For the material code of the accessory kit for each model, see "Table 4–3" on page 55.

Table 4–3 Material code of the accessory kit for each model

| Material Code | Name |
|---------------|---|
| 98050843 | Accessories (sale) - S6-C158-1- Terminal accessory kit for SV680N drives in size A (functional safety) |
| 98050842 | Accessories (sale) - S6-C159-1 - Terminal accessory kit for SV680N drives in size C/D (functional safety) |
| 98050841 | Accessories (sale)- S6-C160-1 - Terminal accessory kit for SV680N drives in size E (functional safety) |

4.2 Installation Environment

Table 4–4 Environmental requirements

| Item | Description | | | |
|------------------------------------|---|---|--|--|
| Ambient/Storage temperature | 0°C to 55°C/-20°C to +70°C | | | |
| Ambient/Storage humidity | Below 90% RH (without condensation) | | | |
| | | | | |
| | Item | Test Condition | | |
| | Test reference | IEC 60068-2-6 4.6 | | |
| | Condition | EUT is powered on and works normally. | | |
| | Motion mode | Sinusoidal | | |
| | Vibration amplitude/ Acceleration rate | - | | |
| Vibration | 10 Hz \leq f \leq 57 Hz | 0.075 mm vibration amplitude | | |
| | 57 Hz < f ≤ 150 Hz | 1 g | | |
| | Vibration duration | 10 times on each of the three mutually perpendicular axes | | |
| | Axis | X, Y, Z | | |
| | Installation | According to the manufacturer's specifications | | |
| | | | | |
| | Item | Test Condition | | |
| | Test reference | IEC 60068-2-27 2008 Table 17 | | |
| | Condition | EUT is powered on and works normally. | | |
| | Motion mode | Half-sine pulse | | |
| Shock resistance | Shock amplitude/ Time | 50 m/s ² (5 g) for 30 ms | | |
| | Number of shocks | 3 per axis on each of three mutually perpendicular axes | | |
| | Axis | $\pm X, \pm Y, \pm Z$ | | |
| | Installation | According to the manufacturer's specifications | | |
| IP rating/Pollution degree (PD) | IP20; PD2: free of corrosive or explosive gases; free of exposure to water, oil or chemicals; free of dust, salts or iron dust | | | |
| Altitude | 2000 m or below | | | |
| Cooling method | Dry clean air (natural c | convection) | | |
| Others | Free of static electricity, strong electromagnetic fields, magnetic fields, or exposure to radioactivity | | | |




Figure 4-2 Environment requirements

4.3 Installation Clearance

Servo drives in different specifications require different installation clearances. It is recommended to reserve a clearance of at least 20 mm (0.39 in.) at both sides and a clearance of at least 80 mm (3.15 in.) above and below the drive for heat dissipation. Take the installation tolerance into account and reserve a clearance of at least 1 mm (0.04 in.) between every two servo drives.




Figure 4-3 Clearance for side-by-side installation

Servo drives in size A support compact installation, in which a clearance of at least 1 mm (0.04 in.) must be reserved between every two drives.




Figure 4-4 Clearance for compact installation

Servo drives in sizes C and D support close installation without derating.




Figure 4-5 Close installation

4.4 Installation Dimensions

Servo Drives in Size A (Rated Power: 0.2 kW to 0.4 kW)




Figure 4-6 Dimension drawing of servo drives in size A

Fixing screw: 2 × M4; recommended tightening torque: 1.2 N·m

Weigh: 1.11 kg

Servo Drives in Size C (Rated Power: 0.75 kW to 1.5 kW)




Figure 4-7 Dimension drawing of servo drives in size C

Fixing screw: 2 × M4; recommended tightening torque: 1.2 N·m

Weigh: 1.45 kg

Servo Drives in Size D (Rated Power: 1.5 kW to 3.0 kW)




Figure 4-8 Dimension drawing of servo drives in size D

Fixing screw: $3 \times M4$; recommended tightening torque: $1.2 \text{ N} \cdot \text{m}$

Weigh: 1.95 kg

Servo Drives in Size E (Rated Power: 2.0 kW to 7.5 kW)




Figure 4-9 Dimension drawing of servo drives in size E

Fixing screw: 4 × M4; recommended tightening torque: 1.2 N·m

Weigh: 3.75 kg

4.5 Installation Precautions

Table 4–5 Installation precautions

| Item | Description | | |
|---------------------|---|--|--|
| Method | Install the servo drive vertically and upward to facilitate heat dissipation. For installation of multiple servo drives inside the cabinet, install them side by side. For dual-row installation, install an air guide plate. Make sure the servo drive is installed vertically to the wall. Cool the servo drive down with natural convection or a cooling fan. Secure the servo drive to the mounting surface through two to four mounting holes (the number of mounting holes depends on the capacity of the servo drive). Install the servo drive vertically to the wall, with its front (actual mounting face) facing the operator. The mounting bracket (if needed) must be made of incombustible materials. | | |
| Cooling | Reserve sufficient space around the servo drive to ensure a good heat dissipation through the cooling fan or natural convection. Take the heat dissipated by other devices inside the cabinet int consideration. Install a cooling fan to the upper part of the serv drive to avoid excessive temperature rise in a certain area, keeping an even temperature inside the control cabinet. | | |
| Grounding | Ground the grounding terminal properly. Failure to comply may result in electric shock or malfunction due to interference. | | |
| Wiring requirements | As shown in the figure below, route the servo drive cables downwards to prevent liquid from flowing into the servo drive along the cables. Route the cable in the direction of the arrow | | |

5 Wiring

5.1 Wiring Precautions



Read through the safety instructions in Chapter "Fundamental Safety Instructions". Failure to comply may result in serious consequence.

- Do not use the power from IT system for the drive. Use the power from TN/TT system for the drive. Failure to comply may result in electric shock.
- Connect an electromagnetic contactor between the input power supply and the main circuit power supply (R/S/T) of the drive to form a structure which allows independent power cutoff on the servo drive power supply side. This is to prevent fire accident caused by continuous high current generated upon fault.
- Check that the input power supply of the drive is within the specified voltage range. Failure to comply may result in faults.
- Do not connect the output terminals U, V, and W of the drive to a three-phase power supply. Failure to comply may result in physical injury or a fire.
- Do not connect the motor terminals U, V, and W to a mains power supply. Failure to comply may result in physical injury or a fire.
- Route the main circuit cable away from the motor body to prevent the cable insulation from being damaged by an overheated motor. Failure to comply may result in personal injury or a fire.
- Use the ALM (fault) signal to cut off the main circuit power supply. A faulty braking transistor may overheat the regenerative resistor and lead to a fire.
- Connect the PE terminal of the drive to the PE terminal of the control cabinet. Failure to comply may result in electric shock.
- Ground the entire system properly. Failure to comply may result in equipment malfunction.
- After the power supply is cut off, residual voltage is still present in the internal capacitor of the drive, wait for at least 15 min before further operations. Failure to comply may result in electric shock.



- The specification and installation of external cables must comply with applicable local regulations.
- Observe the following requirements when the servo drive is used on a vertical axis.
 - Set the safety device properly to prevent the workpiece from falling upon alarm or overtravel.
 - Ensure the positive/negative polarity of the 24 V power supply is correct.
 Otherwise, the load may fall and cause personal injury or equipment damage.
- Observe the following requirements during wiring of the power supply and main circuit:
 - When the main circuit terminal is a connector, remove the connector from the drive before wiring.
 - Insert one cable into one cable terminal of the connector. Do not insert multiple cables into one cable terminal.
 - When inserting cables, take care to prevent the conductor burrs from being short-circuited to the neighboring cable.
 - Insulate the connecting part of the power supply terminals to prevent electric shock.
 - Do not connect a 220 V drive to a 380 V power supply directly.
 - Install safety devices such as a circuit breaker to prevent short circuit in external circuits. Failure to comply may result in a fire.
 - Cut off the main circuit power supply and switch off the S-ON signal after an alarm signal is detected.
 - Route the main circuit cable away from the motor body to prevent the cable insulation from being damaged by an overheated motor. Failure to comply may result in personal injury or a fire.
- Connect the drive to the motor directly. Do not use an electromagnetic contactor during wiring. Failure to comply may result in equipment fault.
- Do not put heavy objects onto the cables or pull cables with excessive force. Failure to comply may result in cable damage, leading to electric shock.
- When connecting DO terminals to relays, ensure the polarity of the flywheel diode is correct. Wrong polarity can result in equipment damage or signal output failure.
- Keep a distance of at least 30 cm between main circuit cables and I/O signal cables/encoder cables. Failure to comply may result in equipment malfunction.
- Use twisted pairs or multi-conductor shielded twisted pairs as the I/O signal cable or encoder cable. Failure to comply may result in equipment malfunction.
- The maximum wiring lengths of the I/O signal cable and the encoder cable are 3 m and 10m respectively.
- Use a power supply filter to reduce the electromagnetic interference suffered by electronic devices surrounding the drive.

- Take proper shielding measures in the following locations to prevent equipment damage:
 - Locations that generate interference due to static electricity
 - Locations that generate strong electric field or magnetic field
 - Locations that may generate radioactive rays

5.2 Terminal Pin Layout of the Drive

This section only describes function terminals of the safety module.




Figure 5-1 Terminal pin layout of the servo drive

Note

For descriptions of main circuit terminals, CN1, CN2, CN3 & CN4, CN5, CN6, CN7 and CN8, see section Wiring Terminals in the Hardware Guide. This manual describes only the components of the safety module: CN9, CN10, CN11 and FSoE ID address configuration knob.

5.3 FSoE Connection and Effective Mode

5.3.1 FSoE Network Connection and Setting

The hardware connection with Beckhoff safety master station is shown in "Figure 5–2" on page 65. Various topologies such as tree and star topologies can be achieved.




Figure 5-2 System network diagram

Note

Recommended master model: The safety drives can be used together with masters that support EL6900. All Beckhoff PLCs support the safety drives.

5.3.2 Knob Operating Method




Figure 5-3 Detail view of the knob

Effective mode: Take effect upon next power-on.

Address setting method: The number of the upper knob*16 + the number of the lower knob.

5.4 CN6 STO Safety Terminal

Terminal Layout




Table 5–1 Pin assignment

| Pin No. | Description | Description | |
|---------|-------------|---------------------------|--|
| 1 | COM- | STO reference ground | |
| 2 | 24 V | Internal 24V power supply | |
| 3 | STO1 | Control input for STO1 | |
| 4 | STO2 | Control input for STO2 | |

Two isolated inputs are configured to dual-channel inputs of the STO function: STO1/STO2.

To facilitate commissioning, additional pin with supply voltage (+24V) is integrated. The bridging of the 24 V terminal to STO1/STO2 is needed in case the safety circuit is installed but no STO function is needed.

Description

Electrical specifications and connection of the input circuit

This section describes the characteristics of the input signals assigned to the CN6 connectors.

Specifications


The servo drive operates normally only when the input states of STO1 and STO2 are both "High" ("1" or "H").

The servo drive does not operate when the input states of STO1 or STO2 are different or are both "Low" ("0" or "L").


■ Electrical characteristics of Safety Request Input Signal are as follows:

| Item | Characteristics | Description | |
|---------------------------|-----------------------|--------------------------------|--|
| Voltage range | 24 VDC (±15%) | - | |
| Input current | 3.6 mA (Typ.) | This is the value per channel. | |
| Standards of logic levels | "0" < 5 V, "1" > 15 V | - | |
| Digital input impedance | 6.6 kΩ | - | |

■ External 24 V




■ Internal 24 V



EMC requirements

- To avoid short circuit between two adjacent conductors, either use cable with shield connected to the protective bonding circuit on each separate conductor, or use flat cables with one earthed conductor between each signal conductor.
- Double-shielded or single-shielded twisted multi-pair cable is strongly recommended.
- Fix and ground the cable shield using a piece of conductive metal. Example of cable clamp:



 The maximum allowable cable length between the drive and the activation switch is 30 m.

Other requirements

- All wiring must be well protected, routed and clamped where practicable.
- It must be assured that there is no pulling or pinching on the cable when installing.
- For cabling the DI inputs of the STO, to avoid common cause failure in the cables, the two channels must be routed through two well-apart routes, or the cable must be protected with double-shielded methods.

| Cables | Description | | |
|----------------|--|--|--|
| Category | Low voltage, double-shielded or single-shielded twisted multi-pair cable | | |
| Maximum size | 0.8 mm ² (18 AWG) | | |
| Minimum size | 0.3 mm ² (28 AWG) | | |
| Maximum length | The max. distance between STO input and the operating contact is 30 m | | |

Applicable servo drives

STO applies to the following servo drives:

| Size | Power Range | Structure | W×H×D (mm³) |
|------|---------------|----------------------|------------------|
| Α | 0.4 kW | Split-type structure | 45.5 x 170 x 150 |
| С | 0.75 kW-1.5kW | Split-type structure | 55 x 170 x 173 |
| D | 1.5 kW–3kW | Split-type structure | 80 x 170 x 183 |
| E | 2 kW-7.5kW | Split-type structure | 90 x 250 x 230 |

5.5 CN7 Encoder Terminal

5.5.1 Terminal Layout

Note

- First encoder: Indicates the master encoder.
- Second encoder: Indicates the slave encoder when the fully closed loop function is used.

Terminal Layout



| Pin No. | Terminal Definition | Description | Pin No. | Terminal Definition | Description |
|---------|------------------------|--|-----------|---------------------|--|
| 1 | A+ | | 9 | GND | Power supply reference ground |
| 2 | A- | Encoder pulse phase A± | 10 | PS1-/DATA- | PS- signal of the first encoder; DATA- signal of the communication-type encoder; Gantry synchronization signal |
| 3 | B+ | Encoder pulse phase | 11 | HALL_U+ | Hall signal U |
| 4 | B- | В± | 12 | HALL_V+ | Hall signal V |
| 5 | PS1+/DATA+ | PS+ signal of the first encoder; DATA+ signal of the communication-type encoder; Gantry synchronization signal | 13 | HALL_W+ | Hall signal W |
| 6 | Z+ | | 14 | PS2+/CLK+ | 1. PS± signal of the |
| 7 | Z- | Encoder pulse phase Z± | 15 | PS2-/CLK- | second encoder; 2. CLK± signal of the communication-type encoder |
| 8 | +5 V | Encoder 5 V power supply (load current lower than 200 mA) | Enclosure | PE | Shield |


5.5.2 Wiring Examples

5.5.2.1 Communication with the First Encoder

Set H32.01 to 1 for an Inovance rotary motor or 0 for a direct drive motor or third-party motor.

Wiring of a pulse encoder


Use shielded twisted pairs to match the high input frequency.



- To reduce noise interference, connect the reference ground of the external encoder to the GND of the drive. Use shielded cables and connect the shield to the CN7 terminal enclosure.
- The input mode of the external encoder is differential input.
- The maximum pulse frequency supported by a phase A/B linear encoder is 4 Mbps.
- The pulse input terminal of a phase A/B encoder supports open circuit detection.


Wiring of Endat2.2/SSI/BISS-C encoder (first encoder)

The drive sends a clock signal to the first encoder, which exchanges data with the servo drive through a DATA signal.



Wiring of Inovance/TAMAGAWA/Nikon encoder (first encoder)

The first encoder interacts with the servo drive through PS1+ and PS1-.



Suppose the current consumed by the motor encoder is 200 mA, you can select the cable based on the following recommendations.

Cable Size Ω/km Allowable Length (m) 26AWG (0.13 mm²) 143 8.0 25 AWG (0.15 mm²) 89.4 14.0 24 AWG (0.21 mm²) 79.6 15.0 23 AWG (0.26 mm²) 68.5 18.0 22 AWG (0.32 mm²) 54.3 23.0 21 AWG (0.41 mm²) 42.7 29.0

Table 5–2 Recommended cable between the servo drive and linear motor encoder

Suppose the current consumed by the motor encoder is higher than 200 mA, you can select the cable based on the following formula.

$$L2 = \frac{\triangle U_{max}}{I_{max} \times 2R_{min}}$$

Where, $\triangle U$ is 0.5 V, I _{encoder} represents the current consumed by the encoder (see the encoder user guide for details), and R _{unit} represents the unit resistance (Ω/km) of the cable.

5.5.2.2 Communication with the Second Encoder

The second encoder is connected to the CN7 port (H0F.06 = 1) by default.

Wiring of a pulse encoder

For details, see "Wiring of a pulse encoder" on page 70.


Wiring of Endat2.2/SSI/BISS-C encoder (second encoder)

The drive communicates with the first encoder normally, that is, the first encoder exists all the time. In the case of the second encoder, the drive sends clock signals to the encoder and the encoder exchanges data with the drive through DATA signals.

For details, see "Wiring of Endat2.2/SSI/BISS-C encoder (first encoder)" on page 71.

Wiring of Inovance/TAMAGAWA/Nikon encoder (second encoder)

The drive communicates with the first encoder normally, that is, the first encoder exists all the time. In the case of the second encoder, the encoder exchanges data with the drive through PS2+ and PS2- signals.



Suppose the current consumed by the motor encoder is 200 mA, you can select the cable based on the following recommendations.

| Cable Size | Ω/km | Allowable Length (m) |
|--------------------------------|------|----------------------|
| 26AWG (0.13 mm²) | 143 | 8.0 |
| 25 AWG (0.15 mm ²) | 89.4 | 14.0 |
| 24 AWG (0.21 mm ²) | 79.6 | 15.0 |
| 23 AWG (0.26 mm ²) | 68.5 | 18.0 |
| 22 AWG (0.32 mm ²) | 54.3 | 23.0 |
| 21 AWG (0.41 mm ²) | 42.7 | 29.0 |

Table 5–3 Recommended cable between the servo drive and linear motor encoder.


Suppose the current consumed by the motor encoder is higher than 200 mA, you can select the cable based on the following formula.

$$L2 = \frac{\triangle U_{rres2}}{I_{eroso} \times 2R_{erf1}}$$

Where, $\triangle U$ is 0.5 V, I _{encoder} represents the current consumed by the encoder (see the encoder user guide for details), and R _{unit} represents the unit resistance (Ω /km) of the cable.

5.6 Description of Brake and PTC Input Terminal (CN8)

5.6.1 Terminal Layout



| Pin No. | Description | Description | Pin No. | Description | Description |
|---------|-------------|---|---------|-------------|---------------------|
| 1 | PTC | Motor temperature feedback input | 2 | COM- | Onboard 24 V COM |
| 3 | BK+ | Brake+ | 4 | BK- | Brake- |
| 5 | 24V_BK | External power supply for the brake | 6 | COM_BK | Brake 24 V COM |

5.6.2 Wiring Examples

5.6.2.1 PTC Wiring Example




Figure 5-4 PTC wiring diagram

Note

- The resistance range triggering PTC circuit overtemperature operation is 1.8 k Ω to 3.85 k Ω . When selecting PTC, note that the PTC resistance value must be less than 1.8 k Ω when the PTC does not operate, and larger than 3.85 k Ω when the PTC operates for overtemperature.
- Only switching thermistors are supported. Connect the shielded cable between the servo drive and the motor properly during wiring.

5.6.2.2 Brake Wiring Examples

The brake is used to prevent the motor shaft from moving and lock the position of the motor and the motion part when the drive is in the non-operational status.





Figure 5-5 Application of the brake



- Use the built-in brake for position-lock purpose only. Do not use this brake for any other purposes (such as braking) other than position-lock in the stop state.
- The brake coil has no polarity.
- Switch off the S-ON signal after the motor stops.
- When the motor with brake runs, the brake may generate a click sound, which
 does not affect its function.
- When brake coils are energized (the brake is released), flux leakage may occur on the shaft end. Pay special attention when using magnetic sensors around the motor.

The connection of brake input signals is polarity-insensitive. Users need to prepare a 24 V power supply. The following figure shows the standard wiring of the brake signals (BK) and the brake power supply.



Pay attention to the following precautions during wiring:

When determining the length of the motor brake cable, take full account the voltage drop caused by cable resistance. The input voltage must be at least 21.6 V to enable the brake to work properly.

Note

- In the standard environment, the number of brake outputs at the drive side can reach at least 5 million. For details on the standard environment, see "4.2 Installation Environment" on page 56.
- The brake must not share the power supply with other electrical devices. This is to
 prevent a malfunction of the brake due to a drop in the voltage or current when
 other electrical devices work in tandem.
- Use cables with a cross-sectional area above 0.5 mm².

5.7 Expansion Safety Function Terminals CN9 and CN10




Figure 5-6 Assignment of CN9 and CN10 pins

Table 5–4 Assignment of CN9 pins

| No. | Assignment | Function | No. | Assign ment | Function |
|-----|------------|----------------------------------|-----|----------------|--|
| 1 | DO3- | Common DO3 output (-) | 2 | DO3+ | Common DO3 output (+) |
| 3 | DO2 | Safety DO2 output | 4 | DO1 | Safety DO1 output |
| 5 | DO24VA | 24 V power supply of DO1 and DO2 | 6 | DO0VA | Output reference ground of DO1 and DO2 |
| 7 | СОМ | DIA input reference ground | 8 | DI5A_IN | Safety DI5A input |
| 9 | DI4A_IN | Safety DI4A input | 10 | DI3A_IN | Safety DI3A input |
| 11 | DI2A_IN | Safety DI2A input | 12 | DI1A_IN | Safety DI1A input |
| 13 | PE | Grounding terminal | 14 | - | - |

Table 5–5 Assignment of CN10 pins

| No. | Assignment | Function | No. | Assignment | Function |
|-----|------------|----------------------------------|-----|------------|--|
| 1 | DO6- | Common DO6 output (-) | 2 | DO6+ | Common DO6 output (+) |
| 3 | DO5 | Safety DO5 output | 4 | DO4 | Safety DO4 output |
| 5 | DO24VB | 24 V power supply of DO4 and DO5 | 6 | DO0VB | Output reference ground of DO4 and DO5 |
| 7 | СОМ | DIB input reference ground | 8 | DI5B_IN | Safety DI5B input |
| 9 | DI4B_IN | Safety DI4B input | 10 | DI3B_IN | Safety DI3B input |
| 11 | DI2B_IN | Safety DI2B input | 12 | DI1B_IN | Safety DI1B input |
| 13 | PE | Grounding terminal | 14 | - | - |

Basic DI information

| Item | Description |
|--|---|
| Five dual-channel digital inputs | Voltage: 24 VDC±15% (must be powered by SELV/PELV power supply) |
| Assignment of logic levels | Low level: "0" < 3 V High level: "1" > 15 V |
| Switch contact | Only supports normally closed switch contacts. |
| Current consumption of an individual DI | 10 mA max. (dual-channel) |
| Maximum allowable cable length between drive and safety switch | 30 m |

Basic DO information

| Item | Description | | | |
|--|---|--|--|--|
| Four dual-channel digital outputs | Maximum output current: 50 mA per channel Voltage: 24 VDC±15% (must be powered by SELV/PELV power supply) | | | |
| Two common DO outputs | Maximum output current: DC 50 mA Maximum allowable external voltage: 30 VDC | | | |
| Safety state | OFF | | | |
| DO open/OFF | Maximum output voltage: 2.4 V | | | |
| Maximum allowable cable length between drive and safety switch | 30 m | | | |
| The status of SSM can be indicated by predefined parameters using DO1, DO2, DO4, and DO5 | | | | |

Note

Open/OFF means the DO is in open circuit state, and closed/ON means the DO can conduct output current.

Wiring Precautions

DI wiring requirements

Care must be taken during wiring to avoid introducing 24V and DI short circuit failures. The following method or similar method may be used.

Do as follows:

- Insert 0 V between 24 V and DI signal line with a flat cable.
- Use shielded wires for 24 V and DI respectively, with the shield connected to PE.

Care must be taken during wiring to avoid introducing short circuit failure between the dual channels (DIxA and DIxB) of the same DI.

The following method or similar methold may be used.

Do as follows:

- Insert 0 V between DIxA and DIxB signal wires with a flat cable.
- Use shielded wires for DIxA and DIxB respectively, with the shield connected to PE.

Care must be taken during wiring to avoid introducing short circuit failure between different DIs (DIx and DIy).

The following method or similar method may be used.

Do as follows:

- Insert 0 V between DIx and DIy signal wires with a flat cable.
- Use shielded wires for DIx and DIy respectively, with the shield connected to PE.

DO wiring requirements

Care must be taken during wiring to avoid introducing 24V and DO short circuit failures. The following method or similar method may be used.

Do as follows:

- Insert 0 V between 24 V and DO signal wires with a flat cable.
- Use shielded wires for 24 V and DO respectively, with the shield connected to PE.

Care must be taken during wiring to avoid introducing short circuit failure between different DOs (DOx and DOy).


The following method or similar method may be used.

Do as follows:

- Insert 0 V between DOx and DOy signal wires using a flat cable.
- Use shielded wires for DOx and DOy respectively, with the shield connected to PE.

Safety digital input

The circuits for DI1 to DI5 are the same. When DI1A and DI1B are connected at the same time, a safety DI is formed. The following description takes DI1 circuit as an example.




The safety DI is a sink-type input. Perform wiring according to the characteristics of the load circuit.

Common digital output

DO3 to DO6 circuits are the same. The following takes DO3 circuit as an example.


- When the host controller provides relay input:
 - Correct wiring:




Note


When the host controller provides relay input, a flywheel diode must be installed; otherwise, the DO terminals may be damaged.

■ Incorrect wiring:






- When the host controller adopts optocoupler input:
 - Correct wiring:



Incorrect wiring:




Safety digital output

The circuits for DO1, DO2, DO4, and DO5 are the same. The following description takes DO1 circuit as an example.

The safety DO is a source-type output. Perform wiring according to the characteristics of the load circuit.

• When the host controller provides relay input:


Correct wiring:




Note

When the host controller provides relay input, a flywheel diode must be installed; otherwise, the DO terminals may be damaged.

■ Incorrect wiring:







• When the host controller adopts optocoupler input:

Wiring

Correct wiring:



■ Incorrect wiring:




5.8 24 V Terminal (CN11)

Note

CN11 24 V backup power input terminal: It is only available in functional safety and backup power-enabled products.

Terminal Layout



| Pin No. | Descrip | Description | Pin No. | Descrip | Description |
|---------|---------|--|---------|---------|--|
| | tion | | | tion | |
| 1 | GND_BP | 0 V input of the backup power supply | 2 | 24V_BP | 24 V input of the backup power supply |

Description

Models with backup power can have separate power supply to the control circuit. When the main circuit is not energized, 24V_BP supplies power to the control circuit to maintain functions like programming, parameter configuration in the software tool, and communication. The keypad of the drive shows "NRD.1" under this circumstance.


Table 5-6 Power input specifications

| Item | Specification |
|------------------------------------|--|
| Power input range | Voltage: 24 VDC±15% (must be SELV/PELV power supply) |
| Power of the external power supply | ≥ 50 W |

Wiring

The wiring mode is shown in the following figure.

Drive CN11



6 Expansion Safety Function

6.1 General

The combination of the safety module, SV680N-INT drive and safety motor can achieve the following safety functions:

| Safety Function | Function |
|-----------------|---|
| STO | The STO function immediately shuts off the torque or force output of the motor based on an input signal from an external device. This function corresponds to stop category 0 of IEC/EN 60204-1. If the motor is running when the STO function is activated, it coasts to a stop. |
| SBC | The SBC function provides a safe output for controlling external brakes. |
| SS1 | The SS1 function starts deceleration based on an input signal from an external device. After a preset period of time elapses or zero speed is achieved, the STO function will be triggered. This function corresponds to stop category 1 of IEC/EN 60204-1. |
| SS2 | The SS1 function starts deceleration based on an input signal from an external device. After a preset period of time elapses or zero speed is achieved, the SOS function will be triggered. This function corresponds to stop category 2 of IEC/EN 60204-1. |
| SOS | The SOS function monitors whether the motor stops within the prescribed range for the stop position. The drive is in the closed-loop control mode, and can therefore withstand external forces. |
| SLS | The SLS function monitors whether the motor speed exceeds a preset speed limit. When the speed is over the limit, torque of the motor will be shut off immediately. |
| SDI | The SDI function prevents the motor shaft from moving in an unintended direction. If the motor rotates in an impermissible direction, the drive stops the motor as quickly as possible. |
| SSM | The SSM function provides a safe output signal to indicate whether the motor speed is below a prescribed limit to identify, for example, a standstill. The servo provides a safe output signal for further processing. |

Different from other functions, the SS1-t function in STO, SBC, and SS1 can be used with a non-safety motor.

You can choose to trigger the safety functions either locally or through FSoE by setting parameter H20.01. The FSoE mode is only applicable to the SV680N-INT servo drive. For a pulse servo drive, you must choose the local mode.

Related parameters:

| Parame ter | Comm. Add. | Name | Value | Default | Unit | Change Mode | Page |
|---------------|---------------|--|-------------------------------------|---------|------|----------------|-----------------------------|
| H20.01 | 2020-02h | Safety function trigger selection | 0: Local trigger 1: FSoE trigger | 0 | 1 | At stop | " H20_en.01" on page 223 |

When the local mode triggers the safety function, you can configure the safety DI to a safety function (such as STO, SS1 or SS2) and control the function through on and off of the safety DI. You can also configure the DO to a safety function (such as STO, SOS, or SSM). The DO output is active when the corresponding safety function is triggered. When you choose to trigger the safety functions through FSoE, you need to configure the PDO mapping. The RPDO transfers data from the master to the slave. You can control the triggering of a safety function by setting the bit in RPDO corresponding to the safety function. The TPDO feeds back data from the slave to the master. The safety module feeds back the current safety function state to the host controller through TPDO.

Note

- When the safety functions are configured to be locally triggered, the TPDO does not update;
- When the safety functions are triggered through FSoE, you cannot use local DIs and DOs.

Priority of safety functions


When several safety functions are activated simultaneously, the following priority applies:

- STO has priority over SS1 and SS2.
- SLS/SDI/SSM are independent of each other.

When a safety function overrides another, this does not cancel the request for the overridden safety function. Therefore, the overridden safety function is restarted after other safety functions are completed.

6.2 Software Parameter Configuration

You can configure the safety parameters in "InoDriverShop" tool on the parameter list or on the graphic user interface of corresponding safety function. The object dictionary cannot be configured.




1. On the parameter list, select a parameter you want to configure and then click "Upload" to read the value of the selected parameter.




Any changes to any safety parameters take effect only at next power-on.


2. Enter a value for the safety parameter and click "Download". A password verification dialog pops up. In the pop-up dialog, enter the password (Default:11111).




3. A confirmation dialog pops up. Make sure the value entered is correct and click "OK". The value is written into the safety module.




4. If you click "Cancel", or fail to click "OK" within 10 seconds, the tool prompts that the modification is canceled. The value will not be written into the safety module.




5. To reset the safety parameters, click "Security function restore factory".



6. To change the safety password, click "Change password". In the pop-up password verification dialog, enter the current password. The verification is passed. Then in the pop-up new password dialog, enter the new password (range: 1 to 65535).



7. The confirm password dialog pops up and then enter the new password again. Make sure the new password and the confirm password are the same. If they are different, the password change fails.



6.3 Safety DI/DO Function

6.3.1 Safety DI Function

DI Function Selection

The safety module includes five DIs. Each DI is configured to receive two input signals through two channels A and B, and default to 0 (OFF). You can assign each DI with a logic function using the software tool.

Table 6–1 Logic function selection of DI1 to DI5

| Pin No. | Name | Pin No. | Name | Configure parameters. |
|------------|------|------------|------|--|
| CI | N9 | CN | 10 | |
| 12 | DI1A | 12 | DI1B | You can configure the logic function of DI1 by setting H20.02. |
| 11 | DI2A | 11 | DI2B | You can configure the logic function of DI2 by setting H20.03. |
| 10 | DI3A | 10 | DI3B | You can configure the logic function of DI3 by setting H20.04. |
| 9 | DI4A | 9 | DI4B | You can configure the logic function of DI4 by setting H20.05. |
| 8 | DI5A | 8 | DI5B | You can configure the logic function of DI5 by setting H20.06. |

Note

The logic function configuration of each DI must be unique.

DI Input Filtering

To avoid false triggering of safety functions caused by external noise interference, five DI input filter parameters are added to the safety module. The safety module performs the corresponding safety function only when the DI input signal is 0 (OFF) and lasts for a period of time exceeding the DI noise reduction filter time.

Table 6-2 Noise reduction filter time of DI1 to DI5

| Configure parameters. | Name |
|-----------------------|--|
| H20.08 | Safety module DI1 noise reduction filter time, in 1 ms |
| H20.09 | Safety module DI2 noise reduction filter time, in 1 ms |
| H20.10 | Safety module DI3 noise reduction filter time, in 1 ms |
| H20.11 | Safety module DI4 noise reduction filter time, in 1 ms |
| H20.12 | Safety module DI5 noise reduction filter time, in 1 ms |

For example, DI1 is assigned with the STO function. The filtering time from the moment when the DI1 receives an input 0 (OFF) to the moment when the STO function is triggered is set by H20.08.




Figure 6-1 Diagram of DI1 noise reduction filter time H20.08

Note

- OFF (0): The 24V voltage of the corresponding DI is off.
- ON (1): The 24V voltage of the corresponding DI is on.

Input Discrepancy Detection

When the function assigned to the DI is active, the safety module monitors whether the signals input to the DI are consistent. If discrepancy exists between the input signals and the discrepancy lasts for a period of time exceeding the allowable discrepancy time, the servo drive issue an alarm E134.x, with x indicating the DI number.

You can configure the following parameters to monitor the discrepancy at input signals of the five DIs.

| Table 6–3 Parameter | | |
|---------------------|--|--|
| | | |

| Configure parameters. | Name |
|-----------------------|--|
| H20.14 | Safety module DI1 allowable discrepancy time, unit: 1 ms |
| H20.15 | Safety module DI2 allowable discrepancy time, unit: 1 ms |
| H20.16 | Safety module DI3 allowable discrepancy time, unit: 1 ms |
| H20.17 | Safety module DI4 allowable discrepancy time, unit: 1 ms |
| H20.18 | Safety module DI5 allowable discrepancy time, unit: 1 ms |




Figure 6-2 Checking for discrepancy at input signals of DI1

6.3.2 Safety DO Function

DO Function Selection

The safety module has six DO terminals, which are all set to 0 (Disabled) by default. DO3 and DO6 are non-safe DO circuits and cannot be used to configure SSM. You can assign each DI with a logic function using the software tool.

| Terminal | Pin No. | Name | Configure parameters. | | | |
|----------|---|------|--|--|--|--|
| | 4 DO1 You can configure the logic function of DO1 by setting parameter H20.20 | | | | | |
| CN9 | 3 | DO2 | You can configure the logic function of DO2 by setting parameter H20.21. | | | |
| | 1&2 | DO3 | You can configure the logic function of DO3 by setting parameter H20.22. | | | |
| | 4 | DO4 | You can configure the logic function of DO4 by setting parameter H20.23. | | | |
| CN10 | 3 | DO5 | You can configure the logic function of DO5 by setting parameter H20.24. | | | |
| | 1&2 | DO6 | You can configure the logic function of DO6 by setting parameter H20.25. | | | |

DO output diagnosis

To ensure that the DO circuit is able to output the signal properly, the safety module will diagnose the DO circuit. To perform DO circuit diagnosis, you need to input 24 V voltage signals to pins 5 and 6 of the CN9 and CN10 terminals.

The following figure shows that when DO1 is configured to STO, the safety module will diagnose the DO1 output circuit when STO is active. The width of the diagnostic pulse is less than 1 ms. When the pulse diagnosis feedback signal is abnormal, the servo drive issues an E125.x alarm, where x is the DO serial number.



Note

For safety DOs (DO1, DO2, DO4, DO5), the maximum DO output voltage is 2.6 V when the DO does not output, that is, the DO output is in an off state. To prevent malfunction, pay attention to the operation voltage threshold of the external electrical device at the load side of the safety DO.

6.4 FSoE Function

6.4.1 Overview

The EtherCAT safety technology was developed according to IEC 61508, is approved by TÜV Süd Rail, and is standardized in IEC 61784-3. The protocol is suitable for safety applications with a safety integrity level up to SIL 3. FSoE data communication is performed in a question-and-answer manner. All data exchanges are initiated by the safety master, and additional data are incorporated to ensure integrity. During each safety cycle, the safety connection between the FSoE master and the FSoE slave is fully monitored. The security check, connection ID and watchdog time of every FSoE frame transmission will be checked.

The SV680N-INT servo drive with FSoE functional safety consists of a drive control part (main unit) and an extended part (functional safety module). The FSoE master communicates with the FSoE slave through the EtherCAT bus. The internal safety data of the FSoE slave is exchanged through a black channel. After the FSoE data embedded in the EtherCAT process data reaches the main unit of the servo drive, it is transmitted to the functional safety module through internal communication.




Figure 6-3 FSoE data transmission

6.4.2 Fixed Safety PDO Setting

• PDO mapping for FSoE reception (170Ah)

| Index | Sub-index | Length (bit) | Name | Data type |
|-------|-----------|--------------|---------------------|-----------|
| E700h | 1 | 8 | FSoE master command | USINT |
| 6640h | 0 | 1 | STO | BOOL |
| 6650h | 0 | 1 | SS1 command | BOOL |
| 6670h | 0 | 1 | SS2 command | BOOL |
| 6668h | 0 | 1 | SOS1 command | BOOL |
| 0000h | 0 | 1 | Reserved | BOOL |
| 66D0h | 0 | 1 | SDIp command | BOOL |
| 66D1h | 0 | 1 | SDIn command | BOOL |
| 6632h | 0 | 1 | Error response | BOOL |
| 6630h | 0 | 1 | Reset response | BOOL |
| 6660h | 0 | 1 | SBC command | BOOL |
| 6690h | 1 | 1 | SLS1 command | BOOL |
| 6690h | 2 | 1 | SLS2 command | BOOL |
| 6690h | 3 | 1 | SLS3 command BOOL | |
| 6690h | 4 | 1 | SLS4 command | BOOL |
| 0000h | 0 | 1 | Reserved BOOL | |
| 0000h | 0 | 1 | Reserved | BOOL |

| Index | Sub-index Length (bit) | | Name | Data type |
|-------|------------------------|----|---------------------------|-----------|
| E700h | 3 | 16 | FFSoE master CRC_0 | UINT |
| E700h | 2 | 16 | FSoE master connection ID | UINT |

• PDO mapping for FSoE transmission (1B0Ah)

| Index | Sub-index | Length (bit) | Name | Data type |
|-------|-----------|--------------|-------------------------------|-----------|
| E600h | 1 | 8 | FSoE slave command | USINT |
| 6640h | 0 | 1 | STO activation | BOOL |
| 66E0h | 0 | 1 | SSM state | BOOL |
| 0000h | 0 | 1 | Reserved | BOOL |
| 6668h | 0 | 1 | STO activation | BOOL |
| 0000h | 0 | 1 | Reserved | BOOL |
| 66D0h | 0 | 1 | SDIp activation | BOOL |
| 66D1h | 0 | 1 | SDIn activation | BOOL |
| 6632h | 0 | 1 | Error | BOOL |
| 6630h | 0 | 1 | Reset | BOOL |
| 6660h | 0 | 1 | SBC activation | BOOL |
| 6690h | 1 | 1 | SLS1 command activation | BOOL |
| 6690h | 2 | 1 | SLS2 command activation | BOOL |
| 6690h | 3 | 1 | SLS3 command activation | BOOL |
| 6690h | 4 | 1 | SLS4 command activation | BOOL |
| 0000h | 0 | 1 | Reserved | BOOL |
| E601h | 1 | 1 | Safety connection state | BOOL |
| E600h | 3 | 16 | FFSoE slave CRC_0 | UINT |
| E600h | 2 | 16 | FSoE slave connection ID | UINT |

6.5 Safe Torque Off Function

6.5.1 Overview

For the STO function integrated in the drive, see the corresponding function guide and hardware guide. This chapter only introduces the STO function of the safety module.

The STO function cuts off the input current of the motor to stop it according to an input signal from the safety controller.

When the STO function is triggered, the servo drive turns off the S-RDY signal and enters the safe state.

The safety module can be configured to trigger the STO function in either of the following ways.

Power off and on the drive every three months or trigger the STO through the safety module, so that STO can be reset periodically.

6.5.2 STO Triggered By Local Mode

In order to use the input signal function of the safety module properly, the safety input DI cable must be connected correctly.

Set H20.01 to 0: The safety function is triggered by the local DI, which means the safety function cannot be triggered through EtherCAT communication.

| Code | Name | Description | Function | |
|----------|-------------|------------------------|-------------------------------------|--|
| FunIN.1 | STO command | STO trigger command | 0: STO active 1: STO canceled | |
| FunIN.11 | ACK command | ACK trigger command | 0: ACK canceled 1: ACK triggered | |
| FunOUT.1 | STO Active | STO active | 0: Normal state 1: STO state | |

Table 6-4 Description of function No.

Ack function not selected for DI: STO status exits automatically when the STO command is canceled.

Ack function is selected for DI: Two DI terminals are used, one configured as STO and one configured as Ack. You can exit the STO state only when the STO command is canceled, and the Ack command is triggered.

See the SBC function section for the sequence of STO and SBC.

Note

- OFF (0): The 24V voltage of the corresponding DO is disconnected.
- ON (1): The 24V voltage of the corresponding DO is connected.

Related parameters:

| | Commu | | | | | | |
|---------|-----------|------------------------|--|---------|------|----------------|--------------|
| Param. | nication | Name | Setpoint | Default | Unit | Change Mode | Page |
| | Address | 0.6 | | | | | |
| H20.02 | 2020-03h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.02" |
| | | module DI1 | 1: STO | | | | on page 223 |
| | | function | 2: SBC | | | | |
| | | selection | 3: SS1 | | | | |
| | | | 4: SS2 | | | | |
| | | | 5: SLS1 6: SLS2 | | | | |
| | | | | | | | |
| | | | 7: SLS3 | | | | |
| | | | 8: SLS4 | | | | |
| | | | 9: SDIp 10: SDIn | | | | |
| | | | 11: Ack | | | | |
| 1120.02 | 2020 041 | C () | | | | | " |
| H20.03 | 2020-04h | Safety | 0: Inactive 1: STO | 0 | - | At stop | " H20_en.03" |
| | | module DI2 function | | | | | on page 224 |
| | | selection | 2: SBC | | | | |
| | | selection | 3: SS1 4: SS2 | | | | |
| | | | 5: SLS1 | | | | |
| | | | 6: SLS2 | | | | |
| | | | 7: SLS3 | | | | |
| | | | 8: SLS4 | | | | |
| | | | 9: SDIp | | | | |
| | | | 10: SDIn | | | | |
| | | | 11: Ack | | | | |
| H20.04 | 2020-05h | Safety | 0: Inactive | 0 | _ | At stop | " H20_en.04" |
| 1120.04 | 2020-0311 | module DI3 | 1: STO | O | | Acstop | on page 224 |
| | | function | 2: SBC | | | | on page 221 |
| | | selection | 3: SS1 | | | | |
| | | Selection | 4: SS2 | | | | |
| | | | 5: SLS1 | | | | |
| | | | 6: SLS2 | | | | |
| | | | 7: SLS3 | | | | |
| | | | 8: SLS4 | | | | |
| | | | 9: SDIp | | | | |
| | | | 10: SDIn | | | | |
| | | | 11: Ack | | | | |
| H20.05 | 2020-06h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.05" |
| | | module DI4 | 1: STO | | | | on page 225 |
| | | function | 2: SBC | | | | 7.0 |
| | | selection | 3: SS1 | | | | |
| | | | 4: SS2 | | | | |
| | | | 5: SLS1 | | | | |
| | | | 6: SLS2 | | | | |
| | | | 7: SLS3 | | | | |
| | | | 8: SLS4 | | | | |
| | | | 9: SDIp | | | | |
| | | | 10: SDIn | | | | |
| | | | t control of the cont | | | | |
| | | | 7: SLS3 8: SLS4 9: SDIp | | | | |

| | Commu | | | | | | |
|--------|----------|------------|------------------|---------|------|---------|--------------|
| Param. | nication | Name | Setpoint | Default | Unit | Change | Page |
| | Address | | | | | Mode | |
| H20.06 | 2020-07h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.06" |
| | | module DI5 | 1: STO | | | | on page 225 |
| | | function | 2: SBC | | | | |
| | | selection | 3: SS1 | | | | |
| | | | 4: SS2 | | | | |
| | | | 5: SLS1 | | | | |
| | | | 6: SLS2 | | | | |
| | | | 7: SLS3 | | | | |
| | | | 8: SLS4 | | | | |
| | | | 9: SDIp | | | | |
| | | | 10: SDIn | | | | |
| | | | 11: Ack | | | | |
| H20.20 | 2020-15h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.20" |
| | | module DO1 | 1: STO Active | | | | on page 229 |
| | | function | 2: SBC Active | | | | |
| | | selection | 3: SS1 Active | | | | |
| | | | 4: SS2 Active | | | | |
| | | | 5: SLS1 Active | | | | |
| | | | 6: SLS2 Active | | | | |
| | | | 7: SLS3 Active | | | | |
| | | | 8: SLS4 Active | | | | |
| | | | 9: SDIp Active | | | | |
| | | | 10: SDIn Active | | | | |
| | | | 11: SOS Active | | | | |
| | | | 12: SSM Active | | | | |
| | | | 13: SS1-r Active | | | | |
| | | | 14: SS2-r Active | | | | |
| H20.21 | 2020-16h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.21" |
| | | module DO2 | 1: STO Active | | | | on page 230 |
| | | function | 2: SBC Active | | | | |
| | | selection | 3: SS1 Active | | | | |
| | | | 4: SS2 Active | | | | |
| | | | 5: SLS1 Active | | | | |
| | | | 6: SLS2 Active | | | | |
| | | | 7: SLS3 Active | | | | |
| | | | 8: SLS4 Active | | | | |
| | | | 9: SDIp Active | | | | |
| | | | 10: SDIn Active | | | | |
| | | | 11: SOS Active | | | | |
| | | | 12: SSM Active | | | | |
| | | | 13: SS1-r Active | | | | |
| | | | 14: SS2-r Active | | | | |

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|--|---------|------|----------------|-----------------------------|
| H20.22 | 2020-17h | Safety module DO3 function selection | 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 13: SS1-r Active | 0 | - | At stop | " H20_en.22" on page 231 |
| H20.23 | 2020-18h | Safety module DO4 function selection | 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active | 0 | - | At stop | " H20_en.23" on page 231 |

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|--|---------|------|----------------|-----------------------------|
| H20.24 | 2020-19h | Safety module DO5 function selection | 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active | 0 | - | At stop | " H20_en.24" on page 232 |
| H20.25 | 2020-1Ah | Safety module DO6 function selection | 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 13: SS1-r Active 14: SS2-r Active | 0 | - | At stop | " H20_en.25" on page 233 |

6.5.3 STO Triggered by FSoE Mode

The safety bus of the safety module currently only supports EtherCAT communication.

To use the STO function through EtherCAT communication, you need to set the network connection, EtherCAT master, and safety CPU unit.

Set the value of parameter H20.01 to "1: FSoE trigger". In this case, the safety functions are no longer triggered by safety input signals.

When 6641h is set to "0", the drive automatically exits the STO state when the STO command is canceled.

When 6641h is set to "1", exiting the STO state not only requires the cancellation of STO command, but also the triggering of the Ack signal.


Related parameters:

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------|------------------------------|-----------------------------|----------|---------|------|----------------|-------------------------|
| 6630h | 6630h | Restart Ack reset signal | 0 to 1 | 0 | - | Real time | " 6630h" on page 248 |
| 6640h | 6640h | STO signal | 0 to 1 | 0 | - | Real time | " 6640h" on page 249 |
| 6641h | 6641h | STO reset mode | 0 to 1 | 0 | - | Real time | " 6641h" on page 249 |

6.5.4 Sequence Diagrams

Operation sequence to enter safety state


• When SBC is not enabled



The safety module starts to shift to STO status when any of the STO inputs 1 and 2 is turned to "OFF".

The STO stop mode reuses the stop mode for No. 1 faults. Dynamic braking is executed based on the setting of H02.08.


When SBC is enabled
 When you set H20.28 to a negative value, the sequence of STO operations is shown in the following figure.



When SBC is activated before STO and the STO input command is active, the stop mode defined by H02.05 is executed first. When the delay defined by H20.28 elapses, the stop mode defined by H02.08 is triggered then.


Reset sequence to exit STO safety state

• When Ack signal is not required



When the Ack signal is not required, the STO state can exit automatically as long as the 24 V DI input signal of two STOs are recovered. The S-ON operation can only be performed properly after STO state exits normally.

When Ack signal is required



When an Ack signal is required, exiting the STO state not only needs the recovery of the 24V voltage, but also a trigger for an Ack signal. The S-ON operation can only be performed properly after STO state exits normally.

Note

The STO function is triggered even if the safety module is in faulty state. After the fault cause is eliminated and the fault reset is performed, the safety module automatically exits the STO state without requiring an Ack input signal.

6.6 Safe Brake Control (SBC)

6.6.1 Overview

For SBC function of the SV680N-INT servo drives including a safety module, no external relay is needed to control ON and OFF of 24 V voltage to the brake motor. The BK+ and BK- pins of the brake motor can be connected to Pin3 and Pin4 of the CN8 terminal of the servo drive, respectively, as shown below.




Figure 6-4 Description of CN8 pins

| Pin No. | Assignment | Description | Pin No. | Assignment | Description |
|---------|------------|---|---------|------------|-------------------|
| 1 | PTC | Motor temperature feedback input | 2 | COM- | Onboard 24VCOM |
| 3 | BK+ | Brake+ | 4 | BK- | Brake- |
| 5 | 24V_BK | External power supply for the brake | 6 | COM_BK | Brake 24VCOM |

The safety module can directly control the ON and OFF of the 24 V voltage connected to Pin5 and Pin6 of CN8.

The SBC applies to situations where the servo drive must remain in a safe position even if the motor is not energized. The SBC prevents the droop of suspended or stretched loads (for example, a hoist). No external relay or switch is required, as the feature is integrated in the drive.

Note

- The SBC function cannot detect mechanical wear or damage to the motor brake.
- When the SBC function is enabled or a safety brake motor with SBC function is installed, Pin5 and Pin6 of CN8 need to be connected to an external 24V voltage; otherwise, the servo drive issues an alarm E631.0.

6.6.2 SBC Triggered By Local Mode

When the safety function is triggered by the local mode, "DI: FunIN2 (SBC)" enables the DI to trigger the SBC function, and "DO: FunOUT.2 (SBC active)" enables the DO to output SBC active signal.

| Code | Name | Description | Function | |
|----------|-------------|---------------------|----------------------------------|--|
| FunIN.2 | SBC command | SBC trigger command | 0: SBC active 1: SBC canceled | |
| FunOUT.2 | SBC Active | SBC active | 0: Normal state 1: SBC state | |

Table 6-5 Description of function No.

Note

- OFF (0): The 24V voltage of the corresponding DO is disconnected.
- ON (1): The 24V voltage of the corresponding DO is connected.

Related parameters:

| | Commu | | | | | | |
|--------|----------|------------|-------------|---------|------|---------|--------------|
| Param. | nication | Name | Value Range | Default | Unit | Change | Page |
| | Address | | | | | Mode | |
| H20.03 | 2020-04h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.03" |
| | | module DI2 | 1: STO | | | | on page 224 |
| | | function | 2: SBC | | | | |
| | | selection | 3: SS1 | | | | |
| | | | 4: SS2 | | | | |
| | | | 5: SLS1 | | | | |
| | | | 6: SLS2 | | | | |
| | | | 7: SLS3 | | | | |
| | | | 8: SLS4 | | | | |
| | | | 9: SDIp | | | | |
| | | | 10: SDIn | | | | |
| | | | 11: Ack | | | | |
| H20.04 | 2020-05h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.04" |
| | | module DI3 | 1: STO | | | | on page 224 |
| | | function | 2: SBC | | | | |
| | | selection | 3: SS1 | | | | |
| | | | 4: SS2 | | | | |
| | | | 5: SLS1 | | | | |
| | | | 6: SLS2 | | | | |
| | | | 7: SLS3 | | | | |
| | | | 8: SLS4 | | | | |
| | | | 9: SDIp | | | | |
| | | | 10: SDIn | | | | |
| | | | 11: Ack | | | | |
| H20.05 | 2020-06h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.05" |
| | | module DI4 | 1: STO | | | | on page 225 |
| | | function | 2: SBC | | | | |
| | | selection | 3: SS1 | | | | |
| | | | 4: SS2 | | | | |
| | | | 5: SLS1 | | | | |
| | | | 6: SLS2 | | | | |
| | | | 7: SLS3 | | | | |
| | | | 8: SLS4 | | | | |
| | | | 9: SDIp | | | | |
| | | | 10: SDIn | | | | |
| | | | 11: Ack | | | | |
| H20.06 | 2020-07h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.06" |
| | | module DI5 | 1: STO | | | | on page 225 |
| | | function | 2: SBC | | | | |
| | | selection | 3: SS1 | | | | |
| | | | 4: SS2 | | | | |
| | | | 5: SLS1 | | | | |
| | | | 6: SLS2 | | | | |
| | | | 7: SLS3 | | | | |
| | | | 8: SLS4 | | | | |
| | | | 9: SDIp | | | | |
| | | | 10: SDIn | | | | |
| | | | 11: Ack | | | | |

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|--|---------|------|----------------|-----------------------------|
| H20.20 | Address 2020-15h | Safety module DO1 function selection | 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active | 0 | | At stop | " H20_en.20" on page 229 |
| H20.21 | 2020-16h | Safety module DO2 function selection | 14: SS2-r Active 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active | 0 | - | At stop | " H20_en.21" on page 230 |
| H20.22 | 2020-17h | Safety module DO3 function selection | 0: Inactive | 0 | - | At stop | " H20_en.22" on page 231 |

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|------------|------------------|---------|------|----------------|--------------|
| H20.23 | 2020-18h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.23" |
| | | module DO4 | 1: STO Active | | | · | on page 231 |
| | | function | 2: SBC Active | | | | |
| | | selection | 3: SS1 Active | | | | |
| | | | 4: SS2 Active | | | | |
| | | | 5: SLS1 Active | | | | |
| | | | 6: SLS2 Active | | | | |
| | | | 7: SLS3 Active | | | | |
| | | | 8: SLS4 Active | | | | |
| | | | 9: SDIp Active | | | | |
| | | | 10: SDIn Active | | | | |
| | | | 11: SOS Active | | | | |
| | | | 12: SSM Active | | | | |
| | | | 13: SS1-r Active | | | | |
| | | | 14: SS2-r Active | | | | |
| H20.24 | 2020-19h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.24" |
| | | module DO5 | 1: STO Active | | | | on page 232 |
| | | function | 2: SBC Active | | | | |
| | | selection | 3: SS1 Active | | | | |
| | | | 4: SS2 Active | | | | |
| | | | 5: SLS1 Active | | | | |
| | | | 6: SLS2 Active | | | | |
| | | | 7: SLS3 Active | | | | |
| | | | 8: SLS4 Active | | | | |
| | | | 9: SDIp Active | | | | |
| | | | 10: SDIn Active | | | | |
| | | | 11: SOS Active | | | | |
| | | | 12: SSM Active | | | | |
| | | | 13: SS1-r Active | | | | |
| | | | 14: SS2-r Active | | | | |
| H20.25 | 2020-1Ah | Safety | 0: Inactive | 0 | - | At stop | " H20_en.25" |
| | | module DO6 | 1: STO Active | | | | on page 233 |
| | | function | 2: SBC Active | | | | |
| | | selection | 3: SS1 Active | | | | |
| | | | 4: SS2 Active | | | | |
| | | | 5: SLS1 Active | | | | |
| | | | 6: SLS2 Active | | | | |
| | | | 7: SLS3 Active | | | | |
| | | | 8: SLS4 Active | | | | |
| | | | 9: SDIp Active | | | | |
| | | | 10: SDIn Active | | | | |
| | | | 11: SOS Active | | | | |
| | | | 13: SS1-r Active | | | | |
| | | | 14: SS2-r Active | | | | |

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|--|-------------|---------|------|----------------|-----------------------------|
| H02.11 | 2002-0Ch | Motor speed threshold at brake output OFF in rotation state | 20 to 3000 | 30 | rpm | Real time | " H02_en.11" on page 221 |
| H02.12 | 2002-0Dh | Delay from S-ON OFF to brake output OFF in rotation state | 1 to 65535 | 500 | ms | Real time | " H02_en.12" on page 221 |

6.6.3 SBC Triggered by FSoE Mode

To avoid damage to the motor caused by brake operation during high-speed rotation, the safety module SBC command does not trigger brake action immediately after it is enabled, but executes "Stop at servo-ON OFF" first.

When the motor speed is lower than the SBC zero speed threshold or the SBC delay expires, the safety module triggers the brake operation.

Parameters involved are shown below.

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------|------------------------------|--|------------|---------|------|----------------|-----------------------------|
| H02.11 | 2002-0Ch | Motor speed threshold at brake output OFF in rotation state | 20 to 3000 | 30 | rpm | Real time | " H02_en.11" on page 221 |
| H02.12 | 2002-0Dh | Delay from S-ON OFF to brake output OFF in rotation state | 1 to 65535 | 500 | ms | Real time | " H02_en.12" on page 221 |
| 6660h | 6660h | SBC signal | 0 to 1 | 0 | - | Real time | " 6660h" on page 252 |

6.6.4 Sequence Diagrams

The response sequence of the SBC function execution is shown below.




Figure 6-5 Response sequence of SBC execution


When the SBC command is activated after noise filtering, the "Stop at S-ON OFF" mode is executed. When the SBC zero speed threshold set by H02.11 is reached or the SBC delay threshold set by H02.12 expires, the safety module triggers the motor to brake. In this case, the motor rotor is locked and the safety module outputs SBC active state.

In addition to being triggered by the SBC command, the SBC function can also be triggered by the STO function.

The sequence of STO and SBC functions can be configured based on the application conditions of STO in different situations.

For example, in the vertical axis applications, to ensure that the load does not drop unexpectedly when the STO function is triggered, you can configure the SBC function to be activated before the PWM pulsing signal is blocked.

SBC activated before STO




When the delay H20.28 from STO activation to SBC activation is negative, the servo drive performs deceleration after the safety module receives the STO trigger command.

When the delay or the SBC zero speed threshold is reached, the SBC brake takes effect and the motor rotor is held.

The configuration value of H20.28 needs to cover the time required for the motor to decelerate from the maximum speed to 0 rpm, preventing the STO function from being activated before activation of SBC brake.

SBC activated after STO



When the delay H20.28 from STO activation to SBC activation is positive, after the safety module receives the STO trigger command, the drive cuts off the S-ON signal and performs coast-to-stop, and triggers the SBC function when the delay is reached.

6.7 Safe Stop 1 (SS1)

6.7.1 Overview

SS1 is used to activate motor deceleration stop. It triggers STO after a certain delay or the speed is lower than a certain threshold. The SS1 stop mode includes "ramp to stop" and "stop as defined by host controller", which can be selected through parameter H20.29.

- When you select "ramp to stop", the drive plans the stop command and stop the motor at the planned speed.
- When you select "stop as defined by host controller", the host controller plans the stop command.
- When the pulse-type servo drive is used, you can only select "ramp to stop". In this
 case, even if you select the "stop as defined by host controller", the stop mode is
 forcibly set to "ramp to stop".

If you choose to trigger safety function by the local mode, you can set H20.02...H20.06 and DI function to 3-SS1 to trigger SS1 through DI. When you choose to trigger safety function by the FSoE mode, you can trigger SS1 by controlling the bits in the RPDO corresponding to the SS1 command.

SS1 stop monitoring includes two modes: SS1-t and SS1-r, which can be selected through H20.32. When SS1-r is selected, the safety motor must be used.

When SS1-t is selected, the drive switches to the STO status regardless of the motor speed after the delay time between triggering of SS1 and application of STO state elapsed. In this case, a safety motor is not required. When the safety motor is used, the drive switches to the STO status when the speed feedback is lower than the zero speed threshold and the duration exceeds the zero speed window time.

When SS1-r is selected, as it contains SS1-t, the drive switches to STO status after the delay time elapsed or when the speed feedback is lower than the zero speed threshold and the duration exceeds the zero speed window time. At the same time, the deceleration process is monitored, and the minimum deceleration speed is set. The actual deceleration must be larger than the monitoring threshold. If the actual deceleration is smaller than the set monitoring ramp range, a fault is reported and the STO status is activated.

The response mode for certain faults can be set to SS1-t. If the fault is triggered, the drive switches to the SS1 stop state and then enters STO sate if the SS1-t status switching condition is met.

6.7.2 SS1 Triggered By Local Mode

SS1 function trigger-related parameters

When the safety function is triggered by the local mode, "DI: FunIN.3 (SS1)" enables the DI to trigger the SS1 function, "DO: FunOUT.3 (SS1 Active)" enables the DO to output SS1 active signal, and "DO: FunOUT.13 (SS1-r active)" enables the DO to output SS1-r monitoring active signal.

| Code | Name | Description | Function | |
|-----------|--------------|------------------------|--|--|
| FunIN.3 | SS1 command | SS1 trigger command | 0: SS1 active 1: SS1 canceled | |
| FunOUT.3 | SS1 Active | SS1-r active | 0: SS1 stop state not applied 1: SS1 stop state applied | |
| FunOUT.13 | SS1-r Active | SS1-r active | 0: SS1-r monitoring state not applied 1: SS1-r monitoring state applied | |

Table 6–6 Description of function No.

When any DI in DI1 to DI5 is configured to FunIN.11-Ack and after the DI corresponding to SS1 is triggered and recovered, the drive recovers from STO state to normal operation state only if the DI corresponding to the Ack function is triggered.

When no DI is configured to Ack function, the drive returns to normal operation state after the corresponding DI of SS1 is triggered and recovered.

Note

- OFF (0): The 24V voltage of the corresponding DO is disconnected.
- ON (1): The 24V voltage of the corresponding DO is connected.

SS1 stop-related parameters

You can select the SS1 stop mode through H20.29.

- If you choose "0: Ramp to stop", the servo drive plans stop commands to control the motor to decelerate to stop according to the planned speed ramp.
- If you choose "1: Stop as defined by the host controller", the host controller plans the stop command to control the motor to decelerate to stop.
- When the pulse-type servo drive is used, you can only select "ramp to stop". If you choose "stop as defined by host controller", ramp-to-stop applies forcibly.

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|----------------------|---|---------|------|----------------|-----------------------------|
| H20.29 | 2020-1Eh | SS1/SS2 stop mode | 0: Ramp to stop 1: Stop as defined by host | 1 | 1 | At stop | " H20_en.29" on page 233 |
| | | | controller | | | | |

When the stop mode is set to "ramp to stop", set the ramp-to-stop speed through H20.30 and the deceleration time for ramp-to-stop through H20.31. After the time defined by H20.31 elapses, the motor speed decelerates from H20.30 to 0, as shown in the figure.




Figure 6-6 Motor speed during ramp-to-stop

Related parameters:

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|-------------|---------|------|----------------|-----------------------------|
| H20.30 | 2020-1Fh | SS1/SS2 ramp-to- stop reference speed | 60 to 6000 | 1000 | rpm | At stop | " H20_en.30" on page 234 |
| H20.31 | 2020-20h | SS1/SS2 ramp-to- stop deceleration time | 1 to 65535 | 500 | ms | At stop | " H20_en.31" on page 234 |

When the safety function is triggered by the local mode, you can set the delay from the moment SS1 is triggered to the moment the drive enters STO state through H20.33, the SS1 zero speed threshold by H20.34, and SS1 zero speed window time by H20.35. When the delay time after SS1 is triggered reaches the setpoint of H20.33, the drive is switched to STO state regardless of the motor speed.

When used together with a safety encoder, the STO state applies in advance when the delay time after SS1 is triggered does not reach the setpoint of H20.33, the motor

speed is lower than the setpoint of H20.34, and such state lasts for the time set by $\,$ H20.35.




Figure 6-7 Safety function triggered by the local mode, motor speed changing

Related parameters:

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|-------------|---------|------|----------------|-----------------------------|
| H20.33 | 2020-22h | SS1 trigger- to-STO delay/SS2 trigger-to- STO delay | 0 to 65535 | 1000 | ms | At stop | " H20_en.33" on page 235 |
| H20.34 | 2020-23h | SS1/SS2 zero speed threshold | 1 to 6000 | 10 | rpm | At stop | " H20_en.34" on page 235 |
| H20.35 | 2020-24h | SS1/SS2 zero speed window time | 0 to 65535 | 0 | ms | At stop | " H20_en.35" on page 235 |

SS1 function monitoring-related parameters

You can select the SS1 monitoring mode through H20.32.

- The speed ramp during deceleration is not monitored when "0-SS1-t" is selected.
- When "1-SS1-r" is selected, the speed ramp during deceleration is monitored. The actual deceleration must be greater than the set minimum deceleration.

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|------------|-------------|---------|------|----------------|--------------|
| H20.32 | 2020-21h | SS1 | 0:SS1-t | 0 | - | At stop | " H20_en.32" |
| | | monitoring | 1:SS1-r | | | | on page 234 |
| | | mode | | | | | |

In SS1-r monitoring mode, when the safety function is triggered by the local mode:

- You can set the delay time (starting from the time when SS1 is triggered) for ramp monitoring to be activated through H20.36. Speed ramp is monitored after the delay time elapsed.
- You can set the ramp monitoring reference speed through H20.37 and the ramp monitoring time through H20.38. The ratio between H20.37 and H20.38 corresponds to the motor's minimum deceleration ramp. The actual deceleration must be greater than the minimum deceleration speed; otherwise a deceleration limit violation fault is reported.
- You can configure the time from triggering of the ramp limit to issuance of the alarm by H20.41. When the number of consecutive overruns of the deceleration ramp reaches the value of H20.41, a fault will be reported.
- You can configure the speed for stopping the ramp monitoring by H20.42. When the motor speed falls below the value of H20.42, the ramp monitoring is stopped.




Figure 6-8 Motor speed when safety function is triggered




Figure 6-9 Motor speed when ramp limit is triggered

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|-------------|---------|------|----------------|-----------------------------|
| H20.36 | 2020-25h | SS1/SS2 ramp monitor start delay | 5 to 65535 | 10 | ms | At stop | " H20_en.36" on page 236 |
| H20.37 | 2020-26h | SS1/SS2 ramp monitor reference speed | 60 to 6000 | 1000 | rpm | At stop | " H20_en.37" on page 236 |
| H20.38 | 2020-27h | SS1/SS2 ramp deceleration monitoring time | 1 to 65535 | 65535 | ms | At stop | " H20_en.38" on page 236 |
| H20.41 | 2020-2Ah | SS1/SS2 ramp limit trigger-to- alarm time | 0 to 65535 | 5 | ms | At stop | " H20_en.41" on page 237 |
| H20.42 | 2020-2Bh | SS1/SS2 ramp monitor stop speed | 0 to 6000 | 1 | rpm | At stop | " H20_en.42" on page 237 |

6.7.3 SS1 Triggered By FSoE Mode

SS1 trigger-related parameters

6650h in the RPDO mapping is the object dictionary of SS1 trigger, and 6650h in the TPDO mapping is the object dictionary of SS1 state.

Related parameters:

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------------|------------------------------|------------|----------|---------|------|----------------|-------------------------------|
| 6650.01 h | 6650-01h | SS1 signal | 0 to 1 | 0 | - | Real time | " 6650_en.01h" on page 250 |

You can use the object dictionary 6641h to set whether a Restart Ack signal is required when the STO state is reset. In the RPDO mapping, 6630h indicates the Restart Ack signal. If 6641h is set to 1, when SS1 is triggered and then reset, the Restart Ack signal must be written to 1 to recover from the STO state to the normal operation state.

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------|------------------------------|-------------------|----------|---------|------|----------------|-------------------------|
| 6641h | 6641h | STO reset mode | 0 to 1 | 0 | = | Real time | " 6641h" on page 249 |

SS1 stop-related parameters

You can configure the stop mode of SS1 by setting H20.29.

When you choose "Ramp to stop", you can configure the ramp-to-stop reference speed by setting H20.30 and the ramp-to-stop deceleration time by setting H20.31.

When you choose to trigger the safety functions through FSoE, you can configure the SS1 trigger-to-STO delay by setting 6651h, the SS1 zero speed threshold by setting 6653h, and the SS1 zero speed window time by setting 6654h.

Related parameters:

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------------|------------------------------|-------------------------------------|------------|---------|------|----------------|-------------------------------|
| 6651.01 h | 6651-01h | SS1 trigger- to-STO delay | 0 to 65535 | 1000 | ms | Real time | " 6651_en.01h" on page 250 |
| 6653.01 h | 6653-01h | SS1 zero speed threshold | 1 to 6000 | 10 | rpm | Real time | " 6653_en.01h" on page 250 |
| 6654.01 h | 6654-01h | SS1 zero speed window time | 0 to 65535 | 0 | ms | Real time | " 6654_en.01h" on page 251 |

SS1 monitoring-related parameters


You can configure the SS1 monitoring mode by setting H20.32.

In case of SS1-r monitoring, when you choose to trigger the safety function through FSoE, you can configure the delay for starting the speed ramp monitoring by setting 6657h and the minimum SS1 deceleration limit by setting 6656h. You can configure the time from triggering the ramp limit to generating the alarm through H20.41, and the speed for stopping the ramp monitoring through H20.42.

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------------|------------------------------|------------------------------------|-----------------|---------|-------------------------------------|----------------|-------------------------------|
| 6656.01 h | 6656-01h | SS1 deceleration limit | 0 to 4294967295 | 15 | Encod er unit/ s ² | Real time | " 6656_en.01h" on page 251 |
| 6657.01 h | 6657-01h | SS1 ramp monitor start delay | 0 to 65535 | 10 | ms | Real time | " 6657_en.01h" on page 251 |


6.7.4 Sequence Diagrams

SS1 is triggered and the drive enters STO state after a delay time has elapsed.




After SS1 is triggered, the SS1 command is canceled during the stop process of SS1. The drive continues to execute the stop process until the stop process is done.

$\ensuremath{\mathsf{SS1}}$ is triggered and the drive enters STO state when the speed meets zero speed conditions.




If the SS1 command is canceled after SS1 has been triggered, the SS1 stop state still remains until the delay time has elapsed or the zero speed conditions are met.


Starting SS1 speed ramp monitoring



SS1-t is triggered by fault and the drive enters STO state when the speed meets zero speed conditions



SS1 recovery



6.8 Safe Stop 2 (SS2)

6.8.1 Overview

SS2 is used to activate the motor to decelerate to stop. It triggers SOS after a certain delay or the speed is lower than a certain threshold. The SS2 stop mode includes "ramp to stop" and "stop as defined by host controller", which can be selected through H20.29. When you select "ramp to stop", the drive plans the stop command and stop the motor at the planned speed. When you select "stop as defined by host

controller", the host controller plans the stop commands. When the pulse-type servo drive is used, you can only select "ramp to stop", in this case, when you select "stop as defined by host controller", the stop mode is forcibly set to "ramp to stop". The SS2 function requires a safety encoder.

If you choose to trigger safety function by the local mode, you can set H20.02...H20.06 and DI function to 4-SS2 to trigger SS2 through DI. When you choose to trigger safety function by the FSoE mode, you can trigger SS2 by controlling the bits in the RPDO corresponding to the SS2 command.

SS2 stop monitoring includes two modes: SS2-t and SS2-r, which can be selected through H20.43.

When SS2-t is selected, the drive switches to SOS status after the delay time between triggering of SS2 and activation of the SOS state or when the speed feedback is lower than the zero speed threshold and the duration exceeds the zero speed window time.

When SS2-r is selected, as it contains SS2-t, the drive switches to SOS status after the delay time elapsed or when the speed feedback is lower than the zero speed threshold and the duration exceeds the zero speed window time. At the same time, the deceleration process is monitored, and the minimum deceleration speed is set. The actual deceleration must be larger than the monitoring threshold. If the actual deceleration is smaller than the set monitoring ramp range, a fault is reported and the STO status is activated.

6.8.2 SS2 Triggered in Local Mode

SS2 function trigger-related parameters

The "DI: FunIN.4 (SS2)" enables the DI to trigger the SS2 function, "DO: FunOUT.4 (SS2 Active)" enables the DO to output SS2 active signal, and "DO: FunOUT.14 (SS2-r Active)" enables the DO to output SS2-r monitor active signal.

| Code | Name | Function | Description |
|-----------|--------------|------------------------|--|
| FunIN.4 | SS2 command | SS2 trigger command | 0: SS2 active 1: SS2 canceled |
| FunOUT.4 | SS2 Active | SS2 activated | 0: SS2 stop state not applied 1: SS2 stop state applied |
| FunOUT.14 | SS2-r Active | SS2-r activated | 0: SS2-r monitoring state not applied 1: SS2-r monitoring state applied |

Table 6-7 Description of function No.

When any DI in DI1 to DI5 is configured to FunIN.11-Ack and after the DI corresponding to SS2 is triggered and recovered, the drive recovers from STO state to

normal operation state only if the DI corresponding to the Ack function is triggered. When no DI is configured to Ack function, the drive returns to normal operation state after the corresponding DI of SS2 is triggered and recovered.

Note

- OFF (0): The 24V voltage of the corresponding DO is disconnected.
- ON (1): The 24V voltage of the corresponding DO is connected.

SS2 stop-related parameters

You can configure the stop mode by setting H20.29. If you choose "0: Ramp to stop", the servo drive generates stop commands to control the motor to decelerate to stop according to the designated speed. If you choose "1: Stop as defined by the host controller", the host controller generates the stop command to control the motor to decelerate to stop. When the pulse-type servo drive is used, you can only select "ramp-to-stop". If you choose "1: Stop as defined by the host controller", ramp-to-stop applies forcibly.

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------|------------------------------|----------------------|---|---------|------|----------------|-----------------------------|
| H20.29 | 2020-1Eh | SS1/SS2 stop mode | 0: Ramp to stop 1: Stop as defined by host | 1 | - | At stop | " H20_en.29" on page 233 |
| | | | controller | | | | |

When the stop mode is set to "ramp-to-stop", set the ramp-to-stop speed through H20.30 and the deceleration time for ramp-to-stop through H20.31. After the time defined by H20.31 elapses, the motor speed decelerates from H20.30 to 0, as shown in the figure.




Figure 6-10 Motor speed during ramp-to-stop



In the CSP mode, the SS2 stop mode H20.29 is set to ramp-to-stop, and SS2 state is canceled during or after stop. Note that 607A of the host controller is aligned to 6064. Otherwise, alignment to 607A can cause a high speed or even alarm B01.2 upon exiting.

Related parameters:

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|------------|---------|------|----------------|-----------------------------|
| H20.30 | 2020-1Fh | SS1/SS2 ramp-to- stop reference speed | 60 to 6000 | 1000 | rpm | At stop | " H20_en.30" on page 234 |
| H20.31 | 2020-20h | SS1/SS2 ramp-to- stop deceleration time | 1 to 65535 | 500 | ms | At stop | " H20_en.31" on page 234 |

When the safety function is triggered in the local mode, you can set the delay from the moment SS2 is triggered to the moment the drive enters STO state through H20.33, set SS2 zero speed threshold by H20.34, and set SS2 zero speed window time through H20.35. If the delay after the SS2 is triggered reaches the value of H20.33, the drive switches to the SOS state regardless of the motor speed. If the delay after the SS2 function is triggered does not reach the value of H20.33 but the motor speed falls below the value of H20.34 for a period of time exceeding the value of H20.35, the drive switches to the SOS state in advance.




Figure 6-11 Safety function triggered by the local mode, motor speed changing

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|------------|---------|------|----------------|-----------------------------|
| H20.33 | 2020-22h | SS1 trigger- to-STO delay/SS2 trigger-to- STO delay | 0 to 65535 | 1000 | ms | At stop | " H20_en.33" on page 235 |
| H20.34 | 2020-23h | SS1/SS2 zero speed threshold | 1 to 6000 | 10 | rpm | At stop | " H20_en.34" on page 235 |
| H20.35 | 2020-24h | SS1/SS2 zero speed window time | 0 to 65535 | 0 | ms | At stop | " H20_en.35" on page 235 |

SS2 monitoring-related parameters

You can configure the SS2 monitoring mode by setting parameter H20.43. If you choose "0: SS2-t", the speed ramp will not be monitored during the deceleration process; if you choose "1: SS2-r", the speed ramp will be monitored during the deceleration process and the actual deceleration of the motor must be larger than the preset minimum deceleration.

Related parameters:

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------|------------------------------|---------------------|----------------------|---------|------|----------------|-----------------------------|
| H20.43 | 2020-2Ch | SS2 monitor mode | 0: SS2-t 1: SS2-r | 0 | = | At stop | " H20_en.43" on page 237 |

In the SS2-r monitoring mode, after you choose to trigger the safety function locally, you can set the delay (starting from the time when SS2 is triggered) for ramp monitoring to be activated through parameter H20.36. Speed ramp is monitored after the delay elapsed.

You can set the ramp monitoring reference speed through H20.37 and the ramp monitoring time through H20.38. The ratio between H20.37 and H20.38 corresponds to the motor's minimum deceleration ramp. The actual deceleration must be greater than the minimum deceleration speed, otherwise a deceleration overrun fault is reported.

You can configure the time from triggering the ramp limit to issuance of the alarm by setting H20.41. When the number of consecutive overruns of the deceleration ramp reaches the value of H20.41, a fault will be reported. You can configure the speed for stopping the ramp monitoring by setting H20.42. When the motor speed falls below the value of H20.42, the ramp monitoring is stopped.




Figure 6-12 Motor speed when safety function is triggered




Figure 6-13 Motor speed when ramp limit is triggered

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|------------|---------|------|----------------|-----------------------------|
| H20.36 | 2020-25h | SS1/SS2 ramp monitor start delay | 5 to 65535 | 10 | ms | At stop | " H20_en.36" on page 236 |
| H20.37 | 2020-26h | SS1/SS2 ramp monitor reference speed | 60 to 6000 | 1000 | rpm | At stop | " H20_en.37" on page 236 |
| H20.38 | 2020-27h | SS1/SS2 ramp deceleration monitoring time | 1 to 65535 | 65535 | ms | At stop | " H20_en.38" on page 236 |

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------|------------------------------|--|------------|---------|------|----------------|-----------------------------|
| H20.41 | 2020-2Ah | SS1/SS2 ramp limit trigger-to- alarm time | 0 to 65535 | 5 | ms | At stop | " H20_en.41" on page 237 |
| H20.42 | 2020-2Bh | SS1/SS2 ramp monitor stop speed | 0 to 6000 | 1 | rpm | At stop | " H20_en.42" on page 237 |

6.8.3 SS2 Triggered By FSoE Mode

SS2 function trigger-related parameters

When you trigger the safety function through FSoE mode, 6670h in the RPDO mapping is the object dictionary of SS2 triggering state, and 6670h in the TPDO mapping is the object dictionary of SS2 triggering state.

Related parameters:

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|---------|------------------------------|------------|----------|---------|------|----------------|----------------|
| 6670.01 | 6670-01h | SS2 signal | 0 to 1 | 0 | - | Real time | " 6670_en.01h" |
| h | | | | | | | on page 253 |

You can use the object dictionary 6676h to set whether a Restart Ack signal is required when the SOS state is reset. In the RPDO mapping, 6630h indicates the Restart Ack signal. If 6676h is set to 1, when SS2 is triggered and then reset, the Restart Ack signal must be written to 1 to recover from the SOS state to the normal operation state.

Related parameters:

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------------|------------------------------|-------------------|----------|---------|------|----------------|-------------------------------|
| 6676.01 h | 6676-01h | SS2 reset mode | 0 to 1 | 0 | - | Real time | " 6676_en.01h" on page 255 |

SS2 stop-related parameters

You can configure the stop mode of SS2 by setting H20.29.

When you choose "Ramp to stop", you can configure the ramp-to-stop reference speed by setting H20.30 and the ramp-to-stop deceleration time by setting H20.31.

When you choose to trigger the safety functions through FSoE, you can configure the SS2 trigger-to-SOS delay by setting 6671h, the SS2 zero speed threshold by setting 666Ch, and the SS2 zero speed window time by setting 6672h.



In the CSP mode, the SS2 stop mode H20.29 is set to ramp-to-stop, and SS2 state is canceled during or after stop. Note that 607A of the host controller is aligned to 6064. Otherwise, alignment to 607A can cause a high speed or even alarm B01.2 upon exiting.

Related parameters:

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------------|------------------------------|-------------------|------------|---------|------|----------------|-------------------------------|
| 666C.01 h | 666C-01h | SOS zero speed | 0 to 6000 | 10 | rpm | Real time | " 666C_en.01h" on page 253 |
| | | threshold | | | | | |
| 6671.01 | 6671-01h | SS2 trigger- | 0 to 65535 | 10 | ms | Real time | " 6671_en.01h" |
| h | | to-STO | | | | | on page 253 |
| | | delay | | | | | |
| 6672.01 | 6672-01h | SS2 zero | 0 to 65535 | 0 | ms | Real time | " 6672_en.01h" |
| h | | speed | | | | | on page 254 |
| | | window | | | | | |
| | | time | | | | | |

SS2 function monitoring-related parameters


You can configure the SS2 monitoring mode by setting H20.43.

In case of SS2-r monitoring, when you choose to trigger the safety function through FSoE, you can configure the delay for starting the speed ramp monitoring by setting 6675h and the minimum SS2 deceleration limit by setting 6674h. You can configure the time from triggering the ramp limit to generating the alarm through H20.41, and the speed for stopping the ramp monitoring through H20.42.

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|---------|------------------------------|--------------|-----------------|---------|----------------|----------------|----------------|
| 6674.01 | 6674-01h | SS2 | 0 to 4294967295 | 15 | Encod | Real time | " 6674_en.01h" |
| h | | deceleration | | | er unit/ | | on page 254 |
| | | limit | | | s ² | | |
| 6675.01 | 6675-01h | SS2 ramp | 0 to 65535 | 10 | ms | Real time | " 6675_en.01h" |
| h | | monitor | | | | | on page 254 |
| | | start delay | | | | | |


6.8.4 Sequence Diagrams

SS2 is triggered and the drive enters STO state after the delay time has elapsed.




If the SS2 command is canceled after SS2 has been triggered, the SS2 state remains until the delay time has elapsed.

SS2 is triggered and the drive enters STO state when the speed meets zero speed conditions.




If the SS2 command is deselected after SS2 has been triggered, the SS2 state remains until the delay time has elapsed or the zero speed conditions are met.

Starting SS2 speed ramp monitor



SS2 recovery



6.9 Safe Operating Stop (SOS)

6.9.1 Overview

The SOS function monitors whether the speed and position of the motor at a standstill are within thresholds, ensuring that the motor is in a safe stop state while providing the power needed to maintain the external load. After SS2 is triggered, the drive switches from the SS2 state to the SOS state when the switching conditions are met. The SOS function requires a safety encoder.

In the SOS state, the position and speed of the motor will be monitored. When the position or speed of the motor exceeds the threshold, a fault will be reported and the drive will enter the STO state.

6.9.2 SOS Triggered By Local Mode

SOS trigger-related parameters

When you trigger the safety function by the local mode, DO: FunOUT.11 (SOS Active) enables the DO to output SOS active signal.

| Code | Name | Description | Function |
|-----------|------------|-------------|--|
| FunOUT.11 | SOS Active | 606 1: | 0: SOS monitor state not applied 1: SOS monitor state applied |

Table 6–8 Description of function No.

When any DI among DI1 to DI5 is assigned with "FunIN.11-Ack" and the DI corresponding to SS2 is triggered and recovered, the drive recovers from STO state to normal operation state only if the DI corresponding to the Ack function is triggered.

When no DI is assigned with Ack function, the drive returns to normal operation state after the corresponding DI of SS2 is triggered and recovered.

Note

- OFF (0): The 24V voltage of the corresponding DO is disconnected.
- ON (1): The 24V voltage of the corresponding DO is connected.

SOS-related parameters

You can configure the SOS speed change threshold by H20.44, the SOS position change threshold by H20.45, and the SOS overthreshold-to-alarm time by H20.47.




Figure 6-14 SOS speed change threshold




Figure 6-15 SOS position change threshold

Related parameters:

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|--|----------------|---------|-----------------|----------------|-----------------------------|
| H20.44 | 2020-2Dh | SOS speed change threshold | 1 to 6000 | 10 | rpm | At stop | " H20_en.44" on page 238 |
| H20.45 | 2020-2Eh | SOS position change threshold | 1 to 536870912 | 932067 | Encoder unit | At stop | " H20_en.45" on page 238 |
| H20.47 | 2020-30h | SOS overthres hold-to- alarm time | 0 to 65535 | 5 | ms | At stop | " H20_en.47" on page 238 |

6.9.3 SOS Triggered by FSoE Mode

SOS trigger-related parameters

When you trigger the safety function through FSoE mode, 6668h in the TPDO mapping is the object dictionary of SOS triggering state.

Related parameters:

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|---------|------------------------------|------------|----------|---------|------|----------------|----------------|
| 6668.01 | 6668-01h | SOS signal | 0 to 1 | 0 | - | Real time | " 6668_en.01h" |
| h | | | | | | | on page 252 |

You can use the object dictionary 6676h to set whether a Restart Ack signal is required when the SOS state is reset. In the RPDO mapping, 6630h indicates the Restart Ack signal. If 6676h is set to 1, when SS2 is triggered and then reset, the Restart Ack signal must be written to 1 to recover from the SOS state to the normal operation state.

Related parameters:

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------------|------------------------------|-------------------|----------|---------|------|----------------|-------------------------------|
| 6676.01 h | 6676-01h | SS2 reset mode | 0 to 1 | 0 | ı | Real time | " 6676_en.01h" on page 255 |


SOS-related parameters

When you choose to trigger the safety functions through FSoE, you can configure the SOS zero position threshold by setting 666Ah and the SOS zero speed threshold by setting 666Ch. You can configure the SOS overthreshold-to-alarm time by setting H20.47.


| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------------|------------------------------|-----------------------------------|----------------|---------|------------------|----------------|-------------------------------|
| 666A.01 h | 666A-01h | SOS zero position threshold | 0 to 536870912 | 932067 | Encod er unit | Real time | " 666A_en.01h" on page 252 |
| 666C.01 h | 666C-01h | SOS zero speed threshold | 0 to 6000 | 10 | rpm | Real time | " 666C_en.01h" on page 253 |

6.9.4 Sequence Diagrams

SOS speed monitoring



SOS position monitoring



6.10 Safely-Limited Speed (SLS)

6.10.10verview

When the SLS function is active, the safety module monitors whether the motor speed exceeds the SLS threshold. Once the allowable speed is exceeded, the servo drive responds in a preset way. You can configure the way for the servo drive to handle the SLS fault by setting the parameter H20.60.

There are four SLS thresholds and you can switch monitoring of these these thresholds during operation.

The SLS function is suitable for motors that can be dangerous due to overspeed.

6.10.2SLS Triggered By Local Mode

The "DI: FunIN5 (SLS1)", "DI: FunIN6 (SLS2)", "DI: FunIN7 (SLS3)", and "DI: FunIN8 (SLS4)" are used to enable the DI to trigger SLS1, SLS2, SLS3, and SLS4 functions respectively. The "DO: FunOUT.5 (SLS1 active)", "DO: FunOUT.6 (SLS2 active)", "DO: FunOUT.7 (SLS3 active)" and "DO: FunOUT.8 (SLS4 active)" are used to enable the DO to output SLS1, SLS2, SLS3, and SLS4 active signals respectively.

| Table | 6-9 | Descri | ntion | of fi | unction | Nο |
|-------|-----|--------|-------|-------|---------|----|
| | | | | | | |

| Code | Name | Description | Function |
|-----------|------------------|----------------|--------------------|
| FunIN.5 | SLS1 command | SLS1 trigger | 0: SS1 active |
| Turiny.5 | JEST COMMITTALIA | command | 1: SS1 canceled |
| FunIN.6 | SLS2 command | SLS2 trigger | 0: SS2 active |
| Tulliv.o | JEJZ COMMINANO | command | 1: SS2 canceled |
| FunIN.7 | SLS3 command | SLS3 trigger | 0: SS3 active |
| Tullin.7 | 3L33 Command | command | 1: SS3 canceled |
| FunIN.8 | SLS4 command | SLS4 trigger | 0: SS4 active |
| i uiiiv.o | SLS4 Command | command | 1: SS4 canceled |
| | | | 0: Normal state |
| FunOUT.5 | SLS1 Active | 0: SLS1 active | 1: SLS1 monitoring |
| | | | state |
| | | | 0: Normal state |
| FunOUT.6 | SLS2 Active | 0: SLS2 active | 1: SLS2 monitoring |
| | | | state |
| | | | 0: Normal state |
| FunOUT.7 | SLS3 Active | 0: SLS3 active | 1: SLS3 monitoring |
| | | | state |
| | | | 0: Normal state |
| FunOUT.8 | SLS4 Active | 0: SLS4 active | 1: SLS4 monitoring |
| | | | state |

Note

- OFF (0): The 24V voltage of the corresponding DO is disconnected.
- ON (1): The 24V voltage of the corresponding DO is connected.

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|--|---------|------|----------------|-----------------------------|
| H20.02 | 2020-03h | Safety module DI1 function selection | 0: Inactive 1: STO 2: SBC 3: SS1 4: SS2 5: SLS1 6: SLS2 7: SLS3 8: SLS4 9: SDIp 10: SDIn 11: Ack | 0 | - | At stop | " H20_en.02" on page 223 |
| H20.03 | 2020-04h | Safety module DI2 function selection | 0: Inactive 1: STO 2: SBC 3: SS1 4: SS2 5: SLS1 6: SLS2 7: SLS3 8: SLS4 9: SDIp 10: SDIn 11: Ack | 0 | - | At stop | " H20_en.03" on page 224 |
| H20.04 | 2020-05h | Safety module DI3 function selection | 0: Inactive 1: STO 2: SBC 3: SS1 4: SS2 5: SLS1 6: SLS2 7: SLS3 8: SLS4 9: SDIp 10: SDIn 11: Ack | 0 | - | At stop | " H20_en.04" on page 224 |

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|--|---------|------|----------------|-----------------------------|
| H20.05 | 2020-06h | Safety module DI4 function selection | 0: Inactive 1: STO 2: SBC 3: SS1 4: SS2 5: SLS1 6: SLS2 7: SLS3 8: SLS4 9: SDIp 10: SDIn 11: Ack | 0 | - | At stop | " H20_en.05" on page 225 |
| H20.06 | 2020-07h | Safety module DI5 function selection | 0: Inactive 1: STO 2: SBC 3: SS1 4: SS2 5: SLS1 6: SLS2 7: SLS3 8: SLS4 9: SDIp 10: SDIn 11: Ack | 0 | - | At stop | " H20_en.06" on page 225 |
| H20.20 | 2020-15h | Safety module DO1 function selection | 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active | 0 | - | At stop | " H20_en.20" on page 229 |

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|--|---------|------|----------------|-----------------------------|
| H20.21 | 2020-16h | Safety module DO2 function selection | 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active | 0 | _ | At stop | " H20_en.21" on page 230 |
| H20.22 | 2020-17h | Safety module DO3 function selection | 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 13: SS1-r Active 14: SS2-r Active | 0 | - | At stop | " H20_en.22" on page 231 |
| H20.23 | 2020-18h | Safety module D04 function selection | 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active | 0 | - | At stop | " H20_en.23" on page 231 |

| | Commu | | | | | | |
|-----------|--------------|-------------|------------------|---------|-------|---------|--------------|
| Param. | nication | Name | Value Range | Default | Unit | Change | Page |
| i didiii. | Address | Nume | | Delaate | Onic | Mode | 6- |
| H20.24 | 2020-19h | Safety | 0: Inactive | 0 | _ | At stop | " H20_en.24" |
| 1120.24 | 2020-1311 | module DO5 | 1: STO Active | Ü | | лізіор | on page 232 |
| | | function | 2: SBC Active | | | | on page 232 |
| | | selection | 3: SS1 Active | | | | |
| | | Selection | 4: SS2 Active | | | | |
| | | | 5: SLS1 Active | | | | |
| | | | 6: SLS2 Active | | | | |
| | | | 7: SLS3 Active | | | | |
| | | | 8: SLS4 Active | | | | |
| | | | 9: SDIp Active | | | | |
| | | | 10: SDIn Active | | | | |
| | | | 11: SOS Active | | | | |
| | | | 12: SSM Active | | | | |
| | | | 13: SS1-r Active | | | | |
| | | | 14: SS2-r Active | | | | |
| H20.25 | 2020-1Ah | Safety | 0: Inactive | 0 | | At stop | " H20_en.25" |
| П20.23 | 2020-1AII | module DO6 | 1: STO Active | U | - | At Stop | |
| | | function | 2: SBC Active | | | | on page 233 |
| | | selection | 3: SS1 Active | | | | |
| | | Selection | 4: SS2 Active | | | | |
| | | | 5: SLS1 Active | | | | |
| | | | 6: SLS2 Active | | | | |
| | | | 7: SLS3 Active | | | | |
| | | | 8: SLS4 Active | | | | |
| | | | 9: SDIp Active | | | | |
| | | | 10: SDIn Active | | | | |
| | | | 11: SOS Active | | | | |
| | | | 13: SS1-r Active | | | | |
| | | | 14: SS2-r Active | | | | |
| 1120 40 | 2020 211 | SLS | | 100 | | | # 1120 40# |
| H20.48 | 2020-31h | | 0 to 65535 | 100 | ms | At stop | " H20_en.48" |
| | | switchover | | | | | on page 239 |
| | | delay 1 | | | | | |
| H20.49 | 2020-32h | SLS | 0 to 65535 | 100 | ms | At stop | " H20_en.49" |
| | | switchover | | | | | on page 239 |
| | | delay 2 | | | | | |
| H20.50 | 2020-33h | SLS | 0 to 65535 | 100 | ms | At stop | " H20_en.50" |
| | | switchover | | | | | on page 239 |
| | | delay 3 | | | | | |
| H20.51 | 2020-34h | SLS | 0 to 65535 | 100 | ms | At stop | " H20_en.51" |
| | | switchover | | | | | on page 240 |
| | | delay 4 | | | | | , 0 |
| H20.52 | 2020–35 | SLS speed | 0 to 6000 | 1000 | rpm | At stop | " H20_en.52" |
| 1120.32 | 2020–35 h | limit | 0 10 0000 | 1000 | ipili | At stup | |
| | " | threshold 1 | | | | | on page 240 |
| U20 F2 | 2020 201- | | 0 to 6000 | 1000 | rn | At cton | " U20 an E2" |
| H20.53 | 2020-36h | SLS speed | 0 to 6000 | 1000 | rpm | At stop | " H20_en.53" |
| | | limit | | | | | on page 240 |
| | | threshold 2 | | | | | |

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|---------------------------------------|-------------|---------|------|----------------|-----------------------------|
| H20.54 | 2020-37h | SLS speed limit threshold 3 | 0 to 6000 | 1000 | rpm | At stop | " H20_en.54" on page 240 |
| H20.55 | 2020-38h | SLS speed limit threshold 4 | 0 to 6000 | 1000 | rpm | At stop | " H20_en.55" on page 241 |
| H20.56 | 2020-39h | SLS speed limit active filter 1 | 0 to 65535 | 100 | ms | At stop | " H20_en.56" on page 241 |
| H20.57 | 2020-3Ah | SLS speed limit active filter 2 | 0 to 65535 | 100 | ms | At stop | " H20_en.57" on page 241 |
| H20.58 | 2020-3Bh | SLS speed limit active filter 3 | 0 to 65535 | 100 | ms | At stop | " H20_en.58" on page 241 |
| H20.59 | 2020-3Ch | SLS speed limit active filter 4 | 0 to 65535 | 100 | ms | At stop | " H20_en.59" on page 242 |

6.10.3SLS Triggered by FSoE Mode

The SLS speed monitoring can be triggered in the following two ways.

- You can set the delay from activation of the SLS command to starting of the SLS speed monitoring (6691h). When the delay has elapsed, the safety module will turn on the speed monitoring no matter whether the current speed of the servo motor is within the speed range.
- 2. You can also set the SLS filter time (6694h). It defines the filtering time for determining that the motor speed is within the SLS limit. When the SLS filter time is reached, the SLS speed monitoring will be activated no matter whether the delay elapses.


The object dictionary involved in the SLS function triggered through FSoE is as follows.

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------------|------------------------------|-------------|----------|---------|------|----------------|-------------------------------|
| 6690.01 h | 6690-01h | SLS1 signal | 0 to 1 | 0 | = | Real time | " 6690_en.01h" on page 255 |
| 6690.02 h | 6690-02h | SLS2 signal | 0 to 1 | 0 | = | Real time | " 6690_en.02h" on page 255 |
| 6690.03 h | 6690-03h | SLS3 signal | 0 to 1 | 0 | ī | Real time | " 6690_en.03h" on page 256 |

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------------|------------------------------|---------------------------------------|------------|---------|------|----------------|-------------------------------|
| 6690.04 h | 6690-04h | SLS4 signal | 0 to 1 | 0 | - | Real time | " 6690_en.04h" on page 256 |
| 6691.01 h | 6691-01h | SLS switchover delay 1 | 0 to 65535 | 100 | ms | Real time | " 6691_en.01h" on page 257 |
| 6691.02 h | 6691-02h | SLS switchover delay 2 | 0 to 65535 | 100 | ms | Real time | " 6691_en.02h" on page 257 |
| 6691.03 h | 6691-03h | SLS switchover delay 3 | 0 to 65535 | 100 | ms | Real time | " 6691_en.03h" on page 257 |
| 6691.04 h | 6691-04h | SLS switchover delay 4 | 0 to 65535 | 100 | ms | Real time | " 6691_en.04h" on page 258 |
| 6693.01 h | 6693-01h | SLS speed limit threshold 1 | 0 to 6000 | 1000 | rpm | Real time | " 6693_en.01h" on page 258 |
| 6693.02 h | 6693-02h | SLS speed limit threshold 2 | 0 to 6000 | 1000 | rpm | Real time | " 6693_en.02h" on page 258 |
| 6693.03 h | 6693-03h | SLS speed limit threshold 3 | 0 to 6000 | 1000 | rpm | Real time | " 6693_en.03h" on page 259 |
| 6693.04 h | 6693-04h | SLS speed limit threshold 4 | 0 to 6000 | 1000 | rpm | Real time | " 6693_en.04h" on page 259 |
| 6694.01 h | 6694-01h | SLS speed limit active filter 1 | 0 to 65535 | 10 | ms | Real time | " 6694_en.01h" on page 259 |
| 6694.02 h | 6694-02h | SLS speed limit active filter 2 | 0 to 65535 | 10 | ms | Real time | " 6694_en.02h" on page 259 |
| 6694.03 h | 6694-03h | SLS speed limit active filter 3 | 0 to 65535 | 10 | ms | Real time | " 6694_en.03h" on page 260 |
| 6694.04 h | 6694-04h | SLS speed limit active filter 4 | 0 to 65535 | 10 | ms | Real time | " 6694_en.04h" on page 260 |

6.10.4Sequence Diagrams


Sequence for triggering SLS function



- When the SLS command is active, the speed of the servo motor must be lower than the SLS threshold before the SLS switchover delay expires; otherwise, the safety module can generate a SLS alarm.
- The safety module only monitors whether the motor speed and SLS switchover delay reach the thresholds. It will not actively send deceleration commands to the servo drive. To make the motor speed fall below the SLS threshold within the SLS switchover delay, the host controller needs to send a signal to the drive to make the drive perform braking deceleration.
- When the SLS command is canceled, the SLS monitoring function is turned off, and the servo drive can immediately continue to run at a higher preset speed.
- Conditions for SLS to enter the monitoring state:
 - 1. SLS switchover delay expired
 - 2. SLS speed limit filter time expired

Sequence for triggering multiple SLS

The SLS function enables monitoring of four different SLS target speed limits. When multiple SLS commands are active, the motor speed must be kept below the lowest SLS threshold; otherwise, the safety module will trigger an SLS alarm.



During normal operation of the servo drive, the SLS1 speed limit monitoring is triggered. Before the SLS1 switchover delay expires, the motor speed needs to be kept below the SLS1 threshold. After the SLS1 switchover delay expires, the SLS1 monitoring is turned on. During the SLS1 monitoring, the SLS2 monitoring is triggered again. Before the SLS2 switchover delay expires, the motor speed needs to be kept below the SLS2 threshold. After the SLS2 switchover delay expires, the SLS2 speed limit monitoring is turned on.

In this case, both SLS1 and SLS2 monitoring are executed at the same time. The lower one of the SLS1 and SLS2 thresholds is used. When the SLS1 command is canceled, the SLS1 speed limit monitoring is turned off.

6.11 Safe Direction (SDI)

6.11.10verview

The SDI function prevents the motor shaft from moving in an unintended direction.

When the SDIp input command is active, the safety module monitors whether the motor shaft moves in the prohibited forward direction; when the SDIn input command is active, the safety module monitors whether the motor shaft moves in the prohibited reverse direction.

When the motor shaft moves in an unexpected direction and exceeds the allowable threshold, the safety module triggers the corresponding stop alarm. You can configure the way for the servo drive to handle the SDI fault by setting the parameter H20.78.

The SDI function must be used with a safety motor.

6.11.2SDI Triggered By Local Mode

The SDI function controlled by the DI involve the following parameter configurations.

The "DI: FunIN9 (SDIp)" and "DI: FunIN10 (SDIn)" are used to enable the DI to trigger the SDIp and SDIn function respectively. The "DO: FunOUT.9 (SDIp active)" and "DO: FunOUT.10 (SDIn active)" are used to enable the DO to output SDIp and SDIn active signals respectively.


| Code | Name | Description | Function |
|-----------|--------------|-------------------------|---|
| FunIN.9 | SDIp command | SDIp trigger command | 0: SDIp active, forward rotation prohibited 1: SDIp canceled, forward rotation allowed |
| FunIN.10 | SDIn command | SDIn trigger command | 0: SDIn active, reverse rotation prohibited 1: SDIn canceled, reverse rotation allowed |
| FunOUT.9 | SDIp Status | SDIp status | 0: SDIp inactive, motor not rotating forwardly 1: SDIp active, motor rotating forwardly |
| FunOUT.10 | SDIn Status | SDIn state | 0: SDIn inactive, motor not rotating reversely 1: SDIn active, motor rotating reversely |

Table 6-10 Description of function No.

Note

- OFF (0): The 24V voltage of the corresponding DO is disconnected.
- ON (1): The 24V voltage of the corresponding DO is connected.

From the perspective of the motor load side, clockwise rotation of the motor is abbreviated as CW, and counterclockwise rotation is abbreviated as CCW, as shown below.



The logical relationship between SDI command and state is as follows.

| SDI cor | mmand | SDI s | state | Description |
|---------|-------|-------|-------|--|
| SDIp | SDIn | SDIp | SDIn | Description |
| 1 | 1 | - | - | The motor can rotate both forwardly and reversely. |
| 1 | 0 | 1 | 0 | The motor can only rotate forwardly. |
| 0 | 1 | 0 | 1 | The motor can only rotate reversely. |
| 0 | 0 | 0 | 0 | The motor is not allowed to rotate. |

0: Inactive, meaning that the 24V voltage of the corresponding DI is off;

1: Active, meaning that the 24V voltage of the corresponding DI is on.

Related parameters:

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|------------|-------------|---------|------|----------------|--------------|
| H20.02 | 2020-03h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.02" |
| | | module DI1 | 1: STO | | | | on page 223 |
| | | function | 2: SBC | | | | |
| | | selection | 3: SS1 | | | | |
| | | | 4: SS2 | | | | |
| | | | 5: SLS1 | | | | |
| | | | 6: SLS2 | | | | |
| | | | 7: SLS3 | | | | |
| | | | 8: SLS4 | | | | |
| | | | 9: SDIp | | | | |
| | | | 10: SDIn | | | | |
| | | | 11: Ack | | | | |
| H20.03 | 2020-04h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.03" |
| | | module DI2 | 1: STO | | | | on page 224 |
| | | function | 2: SBC | | | | |
| | | selection | 3: SS1 | | | | |
| | | | 4: SS2 | | | | |
| | | | 5: SLS1 | | | | |
| | | | 6: SLS2 | | | | |
| | | | 7: SLS3 | | | | |
| | | | 8: SLS4 | | | | |
| | | | 9: SDIp | | | | |
| | | | 10: SDIn | | | | |
| | | | 11: Ack | | | | |

| | Commu | | | | | | |
|--------|----------|------------|-------------|---------|------|---------|--------------|
| Param. | nication | Name | Value Range | Default | Unit | Change | Page |
| | Address | | | | | Mode | |
| H20.04 | 2020-05h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.04" |
| | | module DI3 | 1: STO | | | | on page 224 |
| | | function | 2: SBC | | | | |
| | | selection | 3: SS1 | | | | |
| | | | 4: SS2 | | | | |
| | | | 5: SLS1 | | | | |
| | | | 6: SLS2 | | | | |
| | | | 7: SLS3 | | | | |
| | | | 8: SLS4 | | | | |
| | | | 9: SDIp | | | | |
| | | | 10: SDIn | | | | |
| | | | 11: Ack | | | | |
| H20.05 | 2020-06h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.05" |
| | | module DI4 | 1: STO | | | | on page 225 |
| | | function | 2: SBC | | | | |
| | | selection | 3: SS1 | | | | |
| | | | 4: SS2 | | | | |
| | | | 5: SLS1 | | | | |
| | | | 6: SLS2 | | | | |
| | | | 7: SLS3 | | | | |
| | | | 8: SLS4 | | | | |
| | | | 9: SDIp | | | | |
| | | | 10: SDIn | | | | |
| | | | 11: Ack | | | | |
| H20.06 | 2020-07h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.06" |
| | | module DI5 | 1: STO | | | | on page 225 |
| | | function | 2: SBC | | | | |
| | | selection | 3: SS1 | | | | |
| | | | 4: SS2 | | | | |
| | | | 5: SLS1 | | | | |
| | | | 6: SLS2 | | | | |
| | | | 7: SLS3 | | | | |
| | | | 8: SLS4 | | | | |
| | | | 9: SDIp | | | | |
| | | | 10: SDIn | | | | |
| | | | 11: Ack | | | | |

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|---|---------|------|----------------|-----------------------------|
| H20.20 | 2020-15h | Safety module DO1 function selection | 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active | 0 | - | At stop | " H20_en.20" on page 229 |
| H20.21 | 2020-16h | Safety module DO2 function selection | 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active | 0 | 2 | At stop | " H20_en.21" on page 230 |
| H20.22 | 2020-17h | Safety module DO3 function selection | 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 13: SS1-r Active 14: SS2-r Active | 0 | - | At stop | " H20_en.22" on page 231 |

| | C | | | | | | |
|--------|-----------|------------|------------------|---------|---------|---------|---------------|
| | Commu | | Value Dange | 5 (); | | Change | Dogo |
| Param. | nication | Name | Value Range | Default | Unit | Mode | Page |
| | Address | - 6 | | _ | | | |
| H20.23 | 2020-18h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.23" |
| | | module DO4 | 1: STO Active | | | | on page 231 |
| | | function | 2: SBC Active | | | | |
| | | selection | 3: SS1 Active | | | | |
| | | | 4: SS2 Active | | | | |
| | | | 5: SLS1 Active | | | | |
| | | | 6: SLS2 Active | | | | |
| | | | 7: SLS3 Active | | | | |
| | | | 8: SLS4 Active | | | | |
| | | | 9: SDIp Active | | | | |
| | | | 10: SDIn Active | | | | |
| | | | 11: SOS Active | | | | |
| | | | 12: SSM Active | | | | |
| | | | 13: SS1-r Active | | | | |
| | | | 14: SS2-r Active | | | | |
| H20.24 | 2020-19h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.24" |
| | | module DO5 | 1: STO Active | | | | on page 232 |
| | | function | 2: SBC Active | | | | 1.0 |
| | | selection | 3: SS1 Active | | | | |
| | | Setection | 4: SS2 Active | | | | |
| | | | 5: SLS1 Active | | | | |
| | | | 6: SLS2 Active | | | | |
| | | | 7: SLS3 Active | | | | |
| | | | 8: SLS4 Active | | | | |
| | | | 9: SDIp Active | | | | |
| | | | 10: SDIn Active | | | | |
| | | | 11: SOS Active | | | | |
| | | | 12: SSM Active | | | | |
| | | | 13: SS1-r Active | | | | |
| | | | 14: SS2-r Active | | | | |
| H20.25 | 2020-1Ah | Cafata | 0: Inactive | 0 | | Atoton | " 1120 on 25" |
| H20.25 | 2020-1AII | Safety | | U | - | At stop | " H20_en.25" |
| | | module DO6 | 1: STO Active | | | | on page 233 |
| | | function | 2: SBC Active | | | | |
| | | selection | 3: SS1 Active | | | | |
| | | | 4: SS2 Active | | | | |
| | | | 5: SLS1 Active | | | | |
| | | | 6: SLS2 Active | | | | |
| | | | 7: SLS3 Active | | | | |
| | | | 8: SLS4 Active | | | | |
| | | | 9: SDIp Active | | | | |
| | | | 10: SDIn Active | | | | |
| | | | 11: SOS Active | | | | |
| | | | 13: SS1-r Active | | | | |
| | | | 14: SS2-r Active | | | | |
| H20.74 | 2020-4Bh | SDI zero | 1 to 536870912 | 932067 | Encod | At stop | " H20_en.74" |
| | | position | | | er unit | | on page 243 |
| | | window | | | | | |

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|--|---------|------|----------------|-----------------------------|
| H20.76 | 2020-4Dh | SDI zero speed window | 0 to 3000 | 10 | rpm | At stop | " H20_en.76" on page 244 |
| H20.77 | 2020 to 4Eh | SDI delay time | 0 to 65535 | 0 | ms | At stop | " H20_en.77" on page 244 |
| H20.78 | 2020-4Fh | SDI fault response mode | 0:ST0 1:SS1-t | 0 | - | At stop | " H20_en.78" on page 244 |
| H20.00 | 2020-01h | Functional safety module software version | 0.00 to 655.35 | 0.00 | - | N/A | " H20_en.00" on page 223 |
| H02.02 | 2002-03h | Rotation direction selection | 0: Counterclockwise (CCW) as forward direction 1: Clockwise (CW) as forward direction | 0 | - | At stop | " H02_en.02" on page 221 |

6.11.3SDI Function Triggered by FSoE Mode

The characteristics of the SDI function triggered through FSoE are the same as those of the SDI function triggered locally. The SDI function triggered through FSoE involves the following object dictionary configuration.


Related parameters:

| Param. | Communi cation Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|--------|------------------------------|------------------------------------|---|---------|------------------|----------------|-----------------------------|
| H02.02 | 2002-03h | Rotation direction selection | Counterclockwise (CCW) as forward direction Clockwise (CW) as forward direction | 0 | - | At stop | " H02_en.02" on page 221 |
| 66D0h | 66D0h | SDIp signal | 0 to 1 | 0 | - | Real time | " 66D0h" on page 260 |
| 66D1h | 66D1h | SDIn signal | 0 to 1 | 0 | - | Real time | " 66D1h" on page 261 |
| 66D3h | 66D3h | SDI zero position window | 0 to 536870912 | 932067 | Encod er unit | Real time | " 66D3h" on page 261 |
| 66D5h | 66D5h | SDI zero speed window | 0 to 3000 | 10 | rpm | Real time | " 66D5h" on page 262 |

6.11.4Sequence Diagrams

SDI control bit setting

You can control rotation direction of the motor by setting the SDI control bit. The permissible rotation direction is given by SDI positive (SDIp) and SDI negative (SDIn) control bits.




- The SDIp and SDIn states displayed by the safety module indicate the current rotational state of the servo motor, independent of the input SDI command state. When both SDIp and SDIn states are 0, it means the servo motor is stopped.
- When the SDIp command is deactivated, the motor can rotate in forward direction, and when it is activated, the motor can only rotate in reverse direction.
- When the SDIn command is deactivated, the motor can rotate in reverse direction, and when it is activated, the motor can only rotate in forward direction.

SDI monitoring

When the SDI zero position threshold or SDI zero speed threshold is exceeded, the stop mode defined by ${\tt H02.78}$ is triggered.

The SDI monitoring sequence diagram is shown below.


Stop according to the stop mode defined by H20.78 when the SDI zero position threshold is exceeded.



The sequence is described as follows:


- ① The safety module receives an active SDIn command and starts monitoring whether the motor shaft rotates into the reverse direction. The motor rotates into the allowable forward direction.
- ② The motor stops rotating and the position feedback remains unchanged.
- ③ The motor continues to rotate into the allowable forward direction.
- ④ The motor rotates in the reverse direction, the safety module locks the maximum allowable reverse position threshold and checks whether the current position exceeds the maximum allowable value.
- ⑤ The motor stops before the maximum reverse position threshold is reached.
- 6 The motor continues to rotate in the allowable forward direction.
- ① The motor returns to the position where the reverse position threshold was locked previously.
- ® The zero position window is exceeded and the safety stop set by H20.78 is triggered.

Stop as defined by H20.78 when the zero speed threshold is exceeded.



Hysteresis speed

To avoid the SDIp and SDIn states from jumping back and forth near zero speed, the safety module is configured with a hysteresis speed of 10 rpm. Only when the speed exceeds ± 10 rpm, the corresponding SDI state value changes to 1.



6.12 Safe Speed Monitor (SSM)

6.12.10verview

The SSM function provides a safe output signal to indicate whether the motor speed is below a prescribed limit to identify, for example, a standstill. The safety module provides a safe output signal for further processing.

The SSM monitors whether the motor speed is within the limit threshold. The safety module does not trigger any stop response when the motor speed exceeds the SSM limit threshold.

The SSM applies to enabling through feedback in the local mode, such as unlocking the protective door at a speed lower than the critical speed.

The SSM state can be output through the local mode or through the TPDO status word of the EtherCAT safety bus.

6.12.2SSM Triggered By the Local Mode

When you trigger the safety function by the local mode, "FunOUT.12 (SSM Active)" enables the DO to output SSM active signal.

| Code | Name | Description | Function | |
|-----------|------------|-------------|--|--|
| FunOUT.12 | SSM Active | SSM active | 0: Out of SSM limit 1: Within SSM limit | |

Table 6-11 Description of function No.

- OFF (0): The 24V voltage of the corresponding DO is disconnected.
- ON (1): The 24V voltage of the corresponding DO is connected.

The SSM state can be output through DO.

Related parameters:

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|--|---------|------|----------------|-----------------------------|
| H20.20 | 2020-15h | Safety module DO1 function selection | 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active | 0 | - | At stop | " H20_en.20" on page 229 |
| H20.21 | 2020-16h | Safety module DO2 function selection | 14: SS2-r Active 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active | 0 | - | At stop | " H20_en.21" on page 230 |

| | Commu | | | | | | |
|--------|----------|-----------------------|----------------------------------|---------|------|---------|--------------|
| Param. | nication | Name | Value Range | Default | Unit | Change | Page |
| | Address | | | | | Mode | |
| H20.22 | 2020-17h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.22" |
| | | module DO3 | 1: STO Active | | | | on page 231 |
| | | function | 2: SBC Active | | | | |
| | | selection | 3: SS1 Active | | | | |
| | | | 4: SS2 Active | | | | |
| | | | 5: SLS1 Active 6: SLS2 Active | | | | |
| | | | 7: SLS3 Active | | | | |
| | | | 8: SLS4 Active | | | | |
| | | | 9: SDIp Active | | | | |
| | | | 10: SDIn Active | | | | |
| | | | 11: SOS Active | | | | |
| | | | 13: SS1-r Active | | | | |
| | | | 14: SS2-r Active | | | | |
| H20.23 | 2020-18h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.23" |
| | | module DO4 | 1: STO Active | | | | on page 231 |
| | | function | 2: SBC Active | | | | |
| | | selection | 3: SS1 Active | | | | |
| | | | 4: SS2 Active 5: SLS1 Active | | | | |
| | | | 6: SLS2 Active | | | | |
| | | | 7: SLS3 Active | | | | |
| | | | 8: SLS4 Active | | | | |
| | | | 9: SDIp Active | | | | |
| | | | 10: SDIn Active | | | | |
| | | | 11: SOS Active | | | | |
| | | | 12: SSM Active | | | | |
| | | | 13: SS1-r Active | | | | |
| | | | 14: SS2-r Active | | | | |
| H20.24 | 2020-19h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.24" |
| | | module DO5 | 1: STO Active | | | | on page 232 |
| | | function selection | 2: SBC Active 3: SS1 Active | | | | |
| | | Selection | 4: SS2 Active | | | | |
| | | | 5: SLS1 Active | | | | |
| | | | 6: SLS2 Active | | | | |
| | | | 7: SLS3 Active | | | | |
| | | | 8: SLS4 Active | | | | |
| | | | 9: SDIp Active | | | | |
| | | | 10: SDIn Active | | | | |
| | | | 11: SOS Active | | | | |
| | | | 12: SSM Active | | | | |
| | | | 13: SS1-r Active | | | | |
| | | | 14: SS2-r Active | | | | |

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|--|---------|------|----------------|-----------------------------|
| H20.25 | 2020-1Ah | Safety module DO6 function selection | 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 13: SS1-r Active | 0 | - | At stop | " H20_en.25" on page 233 |
| H20.70 | 2020-47h | SSM upper limit threshold | -6000 to +6000 | 200 | rpm | At stop | " H20_en.70" on page 242 |
| H20.71 | 2020-48h | SSM lower limit threshold | -6000 to +6000 | -200 | rpm | At stop | " H20_en.71" on page 243 |
| H20.72 | 2020-49h | SSM hysteresis threshold | 0 to 6000 | 10 | rpm | At stop | " H20_en.72" on page 243 |

- When the upper and lower limits of SSM are set to 0 at the same time, the SSM function can be disabled, and the SSM status is always inactive.
- The upper limit of the SSM must be greater than the lower limit, and the hysteresis threshold of the SSM must be lower than the result of the upper limit minus the lower limit.
- The SSM hysteresis threshold is set by H20.72, and is valid for both local DO and FSoE output status words.

6.12.3SSM Output in FSoE Mode

The SSM hysteresis threshold is not planned in the object dictionary. To prevent the motor speed from fluctuating near the upper or lower SSM threshold, the SSM hysteresis threshold configured for the SSM function triggered locally adopts the value set by H20.72.

That is, the SSM hysteresis threshold set by H20.72 is active both in the local mode and in the FSoF mode.


The object dictionaries involved by the SSM safety bus are as follows: Related parameters:

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change Mode | Page |
|---------|------------------------------|-----------|----------------|---------|------|----------------|----------------|
| 66E0.01 | 66E0-01h | SSM state | 0 to 1 | 0 | - | N/A | " 66E0_en.01h" |
| h | | | | | | | on page 262 |
| 66E2.01 | 66E2-01h | SSM upper | -6000 to +6000 | 200 | rpm | Real time | " 66E2_en.01h" |
| h | | limit | | | | | on page 262 |
| | | threshold | | | | | |
| 66E4.01 | 66E4-01h | SSM lower | -6000 to +6000 | -200 | rpm | Real time | " 66E4_en.01h" |
| h | | limit | | | | | on page 262 |
| | | threshold | | | | | |

Note

- When the upper and lower limits of SSM are set to 0 at the same time, the SSM function is turned off and the SSM state is always inactive.
- The upper limit of the SSM must be greater than the lower limit, and the hysteresis threshold of the SSM must be less than the upper limit minus the lower limit.
- The SSM hysteresis threshold is set by parameter H20.72, and is valid for both local DO and FSoE output status words.

6.12.4Sequence Diagrams



The purpose of the SSM hysteresis setting is to achieve a stable signal output when the motor speed is near the upper and lower SSM threshold. The SSM function prevents the SSM output signal from jumping back and forth between 0 and 1 several times around the threshold due to the real-time fluctuation of the motor speed.

- When the motor speed is within the upper and lower SSM thresholds, the SSM output is 1.
- When the motor speed exceeds the upper SSM threshold, the SSM output is 0.
- When the motor speed drops below the difference between upper SSM threshold and hysteresis threshold, the SSM output is 1 again.
- When the motor speed drops below the lower SSM threshold, the SSM output is 0.
- When the motor speed increases to the sum of lower SSM threshold and hysteresis threshold, the SSM output is 1 again.

6.13 Safety Function Response Time



Set the parameters correctly to achieve the desired response time and ensure the accumulation of diagnostic test interval (DTI) and safety function response time can meet the safety requirements of the system.

6.13.1 Response Time for Triggering Local Mode

To trigger the safety functions through the local mode, you need to configure a safety DI with a certain safety function. Then you can trigger the corresponding safety function by controlling the safety DI. The response time from DI action to activation of the safety function is shown in the following table.

| | [5] |
|---|----------------------------|
| Table 6–12 Response tin | ne during terminal control |
| the safety function is snown in the following | g table. |

| Function | Max. response time ^[5] |
|-----------------|--|
| STO/SBC/SS1/SS2 | t_DI ^[1] +2.5 ms |
| SLS | t_DI ^[1] +t_SLS ^[3] + 6.5 ms |
| SDI | t_DI ^[1] +t_SDI ^[4] + 6.5 ms |
| SOS | t_SOS ^[2] + 6.5 ms |
| SSM | 4 ms |

- [1]: t_DI is the noise reduction filter time of the safety module DI, which is configured by H20.08 to H20.12, with setpoints ranging from 1 ms to 500 ms.
- [2]: t_SOS is the filter time set by H20.47, which ranges from 0 ms to 65535 ms.
- [3]: t_SLS is the delay time set by H20.48 to H20.51, which ranges from 0 ms to 65535 ms.
- [4]: t_SDI is the delay time set by H20.77, which ranges from 0 ms to 65535 ms.
- [5]: Indicates the time interval between the safety function demand state and the safety function completion state (such as entering the safety state).

6.13.2Response Time in FSoE Mode

When the safety function is triggered through the FSoE mode, the corresponding safety function is triggered by the control word of a certain safety function in the RPDO. The following table shows the time between function trigger and function execution.

| Function | Max. response time [7] |
|-----------------|--|
| STO/SBC/SS1/SS2 | 2xt_ET ^[1] + 2 ms |
| SLS | 2xt_ET ^[1] + t_SLS ^[3] + 6.5 ms |
| SDI | 2xt_ET ^[1] + t_SDI [^{4]} + 6.5 ms |
| SOS | T_SOS ^[2] + 6.5 ms |
| SSM | 4xt_EPS ^[5] + 4xt_EFM ^{[6} |

Table 6–13 Response time during FSoE control

- [1]: t_ET is the EtherCAT communication synchronization cycle. The setpoint is determined by the parameter configurations of the customer controller.
- [2]: t_SOS is the filter time set by H20.47, which ranges from 0 ms to 65535 ms.
- [3]: t_SLS is the delay set by H20.48 to H20.51, which ranges from 0 ms to 65535 ms.
- [3]: t_SDI is the delay set by H20.77, which ranges from 0 ms to 65535 ms.
- [5] t_EPS is the communication cycle between the EtherCAT master and the FSoE slave. The setpoint is determined by the parameter configurations of the customer controller.
- [6]: t_EFM is the communication cycle between the EtherCAT master and the FSoE master. The setpoint is determined by the parameter configurations of the customer controller.
- [7]: Indicates the time interval between the safety function demand state and the safety function completion state (such as entering the safety state).

6.14 Fault Reset

When the resettable safety function fault occurs, you can stop the keypad from displaying the fault using the fault reset function.


- To stop the keypad from displaying the fault/warning, set H0d.01 (Fault reset) to 1
 or activate the DI terminal assigned with DI function 2 (FunIN.2: ALM- RST, fault and
 warning reset).
- 2. For EtherCAT servo drives, enable the rising edge of the control word 6040h bit7 on the host controller to stop the keypad from displaying the fault.

For No. 1 and No. 2 resettable faults, turn off the S-ON signal before resetting the faults.

When a non-resettable safety function fault occurs, the power must be restarted to stop the fault display.

7 Integrated STO Safety Function

7.1 Overview



Motor-torque-off is achieved by cutting off the motor supply current through cutting off motor power supply module output.

Figure 7-1 Schematics of the STO function

Safe Torque Off (STO) is a safety function that complies with IEC 61800-5-2:2016. It is integrated in Inovance SV680-INT series servo drives.

Remember to perform a power cycle of the drive every three months or trigger the STO through disconnecting the 24V input of CN6, so that STO can be reset periodically.

The STO function inhibits the control signal of the power semiconductors on the drive output end, preventing the drive from generating torque at the motor shaft end.

The STO function prevents movement of the motor by two redundant external hardware signals (STO1 and STO2) that block the PWM signals from being outputted to the power layer of the servo drive. STO1 and STO2 input signals must be both active to allow the servo drive to operate normally.

See the following table for the STO function.

| STO1 Input | STO2 Input | PWM Signal |
|------------|------------|------------|
| Н | Н | Normal |
| L | Н | Prohibit |
| Н | L | Prohibit |
| L | L | Prohibit |

| | STO (safe torque) |
|----------------|--|
| Description | Cuts off the power of the motor. |
| Description | The safe torque off (STO) function brings the machine safely into a notorque state and prevents it from unexpected start. If the motor is running when STO function is activated, it coasts to stop. |
| Safe state | Disables the PWM gating signal of the drive. |
| Operation mode | High demand mode or continuous mode |

7.2 Use of the STO Function

Use of the STO function

The keypad displays the STO function state and fault information.

See the following table to determine the cause of the faults and the measures to be taken. Contact Inovance technical support if the fault persists after corrective actions listed in the following table are taken.

Fault codes related to the STO function are listed in the following table:

| Fault code | Status | Description | Cause | Solution |
|------------|---|--|---|---|
| E150.0 | STO function triggered normally | When H0A.21 is set to 1, the servo drive reports E150.0 fault code after STO is triggered. | When H0A.21 is set to 1, the servo drive reports E150.0 fault code after STO is triggered. | To exit from STO, both STO request commands need to be canceled, and fault reset is required to clear E150.0. |
| E150.1 | Status of STO1 and STO2 inconsistent | Only one of STO1 and STO2 is in "Low" state, status of STO1 and STO2 are inconsistent. | The input states of STO1 and STO2 are inconsistent. | 1. Ensure the requests for disconnecting the voltage of STO1 and STO2 are triggered simultaneously. 2. The input circuit is abnormal and a certain STO input signal is still in the"H" state after the 24 V signal is disconnected. Contact Inovance for technical support. |
| E150.2 | STO activated | OV/UV of the 5V power supply is detected. | OV/UV of 5 V power supply | Restore the 5 V power supply to normal state. Contact Inovance for technical support. |
| E150.3 | STO activated | The input circuit of STO works improperly. | The input circuit of STO works improperly. | Fix the input circuit fault. Contact Inovance for technical support. |

| Fault code | Status | Description | Cause | Solution |
|------------|---------------|---|--|---|
| E150.4 | STO activated | | The buffer circuit of STO works improperly | Fix the buffer circuit fault. Contact Inovance for technical support. |
| E150.5 | STO activated | Ine STO terminal input is subject to noise. | The STO terminal input is in poor contact, which may | Check whether the input wiring of the STO terminal is normal and whether the external 24 V input voltage is stable. |

- For a motor with brake, if either STO1 or STO2 closes, the drive will be disabled within 30 ms (STO response time).
- For a motor without brake, if either STO1 or STO2 closes, the drive will be disabled within 5 ms (STO response time).

EDM signal DO output

When the 24 V voltage of STO1 and STO2 is cut off, the EDM DO signal is active. Otherwise, the EDM DO signal is inactive.


In this case, both STO1 and STO2 are filtered signals. When EDM is active, the PWM signal is blocked by the servo drive.

| Signal Name | Symbol | Optocoupler logic | | | |
|--------------|--------|-------------------|-----|-----|-----|
| Safety input | STO1 | ON | ON | OFF | OFF |
| Salety Input | STO2 | ON | OFF | ON | OFF |
| EDM output | EDM | OFF | OFF | OFF | ON |

Application Example

Example 1:

Emergency button (dual-contact) Class 3 ISO13849



7.3 Fault Reset

The exceptional operation refers to the durations of power-on and initialization, and how to return from the STO state.

- The PWM buffer is disabled as the enable terminal is pulled up during power-on, so the PWM signal is inhibited.
- The PWM buffer is disabled as the enable terminal is pulled up during initialization
 of the MCU, so the PWM signal is inhibited. Such condition is cleared and servo
 drive works normally after initialization is done.
- When all of the following conditions are met, the servo system that enters the safe state through the STO function can be back to normal with the safe state cleared after auto-reset of the drive.
 - The input state of the STO request must be "high".
 - The servo ON or servo RUN command must be inactive.
 - No dangerous faults exist.




Figure 7-2 Return condition of external STO request state

Note

[1]: The servo ON command is a servo-enabled command, not an internal servo-enabled state.

When STO_IN (STO1 or STO2 input) is restored to 24 V, the EDM and servo ready signals are immediately reset to 0. When both STO1 and STO2 are restored to 24 V at the same time, the servo ready output signal and the servo operation signal are activated after 400 ms. When the drive operates, the PWM drive signal is outputted.





Figure 7-3 Servo drive reset sequence diagram

7.4 Safety Function Response Time

The STO function prevents movement of the motor by two redundant external hardware signals (STO1 and STO2) that block the PWM signals from being outputted to the power layer of the servo drive. STO1 and STO2 input signals must be both active to allow the servo drive to operate normally.

If either one or both signals are set to "Low" level, the PWM signals will be blocked within 30 $\,\mathrm{ms^{[1]}}$.



Note

[1]: The typical response time is 30 ms. The maximum response time is 100 ms.

8 Commissioning and Operation

8.1 Pre-operation Inspection

Check the following items before operating the servo drive and the servo motor.

Table 8-1 Pre-operation checklist

| No. | ltem | Compli ance |
|-----|---|----------------|
| | Wiring | |
| 1 | The power input terminals (L1C, L2C, L1, L2, L3, R, S, T) of the servo drive are connected properly. | |
| 2 | The main circuit cables (U, V, W) of the motor are connected to the U/V/W terminals of the drive correctly. | |
| 3 | No short circuit exists in the power input terminals (L1, L2, L3, R, S, T) or main circuit output terminals (U, V, W) of the servo drive. | |
| 4 | The control signal cables, such as the brake signal cable and overtravel protection signal cable, are connected properly. | |
| 5 | The servo drive and servo motor are grounded properly. | |
| 6 | The stress suffered by the cable is within the specified range. | |
| 7 | All the wiring terminals are insulated properly. | |
| 8 | The encoder shield is reliably connected to the PE interface of the encoder. | |
| | Environment and Mechanical Conditions | |
| 1 | There are no unwanted objects (such as cable terminals and metal chippings) that may cause short circuit of the signal cable and power cable inside or outside the servo drive. | |
| 2 | The servo drive and the external regenerative resistor are placed on incombustible objects. | |
| 3 | The motor is installed properly. The motor shaft is connected to the machine securely. | |
| 4 | The motor and the machine it is connected to are in good condition and ready to run. | |

8.2 Trial Run

Safety functions triggered locally (H20.01=0)

1. Ensure that the wiring of the DI and DO of the safety module is correct. The DO requires an external 24V input voltage.

- Use the software tool to configure the functions of DI and DO, for example, set DI1 to "1: STO".
- 3. Control the DI input voltage, observe whether the DO state changes normally and whether the servo drive reports any fault.
 - For example, disconnect the 24V input voltage of DI1 assigned with the STO function and observe whether the STO state indicated by DO1 is active. Then restore the 24V input voltage of DI1 and observe whether the STO state output by DO1 is inactive.
- 4. The DI of the safety module adopts dual-channel (A&B) control. The safety function can be executed when either of the two channels is active. The safety module monitors whether there is discrepancy at the two input signals. If the discrepancy lasts for a period of time exceeding the preset allowed time, the safety module outputs the corresponding fault information.

Safety functions triggered through FSoE (H20.01=1)

- 1. Ensure that the wiring of the safety PLC and the servo drive is correct.
- Beckhoff EL1904 module supports up to four channels of safety input, and the EL2904 module supports up to four channels of safety state output. Configure the RPDO corresponding to the input signal of the EL1904 and the TPDO corresponding to the output signal of the EL2904.
 - For example, configure one channel of the EL1904 to STO PRDO and one channel of the EL2904 to STO TPDO.
- Control ON and OFF of the input signal of the EL1904, observe whether the output signal of the EL2904 changes normally, and whether the servo drive reports any fault.

For example, turn off the 24V input voltage corresponding to the STO of the EL1904 module and the drive enters the STO state, then observe whether the STO output state of the EL2904 module is active. Then restore the 24V input voltage and the drive exits the STO state, and observe whether the STO output state is inactive.

Note

In the above example, an Ack signal is not required for the drive to exit the STO state by default. As long as the STO command is canceled, the drive automatically exits the STO state.

8.3 Verification and Validation

Overview

This chapter describes verification and validation of the implemented safety functionality.

Verification and validation produce documented proof of the compliance of the implementation with specified safety requirements.

Basic requirements

- Technical staff must be trained to understand the requirements and principles of designing and operating safety-related systems.
- Person performing the maintenance must be trained to understand the requirements and principles of designing and operating safety-related systems.
- Operators must be trained to understand the requirements and principles of designing and operating safety-related systems.
- The safety-related circuit on the control board that fails to operate must be replaced with a new one as it is not repairable.

Commissioning Checklist

• Start-up test and validation

IEC 61508, EN/IEC 62061 and EN ISO 13849 require the final assembler of the equipment to verify the operation of the safety function through acceptance testing. This acceptance test is described in the drive manual. The testing of optional safety features is described in the corresponding manuals.

The acceptance test must be performed:

- at initial start-up of the safety function
- after any changes related to the safety function (wiring, components, settings and so on).
- after any maintenance work related to the safety function.

The acceptance test of the safety function must be carried out by an authorized person with expertise and knowledge of the safety function. The test must be documented and signed by the test staff.

Signed acceptance test reports must be stored in the logbook of the machine. The report shall include documentation of start-up activities and test results, references to failure reports and resolution of failures. Any new acceptance tests performed due to changes or maintenance need to be logged into the logbook.

Checklist

| No. | ltem | |
|------|--|--|
| 110. | | |
| 1 | Ensure that the drive runs and stops freely during commissioning. | |
| 2 | Stop the drive (if running), switch the input power supply off and isolate the drive from the power line by a circuit breaker. | |
| 3 | Check the STO circuit connections based on the circuit diagram. | |
| 4 | Check that the shield of the STO input cable is grounded to the drive frame. | |

| No. | ltem | Compli ance |
|-----|--|----------------|
| 5 | Turn off the circuit breaker and switch the power supply on. | |
| 5.1 | Test the STO signal #1 when the motor stops: Set STO1 and STO2 to "H". Send a stop command to the drive (if running) and wait until the motor shaft is at standstill. Awake the STO function by de-energizing (low state or open-circuit) the STO input signal #1 and send a start command to the drive. Ensure that the motor stays at a standstill and the keypad of the drive displays "E150.1". | |
| 5.2 | Set STO1 to "H" and disable the ON/RUN command of the drive. Then, reset the drive automatically and enable ON/RUN command of the drive. Finally, check whether the motor runs normally. | |
| 5.3 | Test the STO signal #2 when the motor stops: Set STO1 and STO2 to "H". Send a stop command to the drive (if running) and wait until the motor shaft is at standstill. Awake the STO function by de-energizing (low state or open-circuit) the STO input signal 2 and send a start command to the drive. Ensure that the motor stays at a standstill and the keypad of the drive displays "E150.1". | |
| 5.4 | Set STO2 to "H" and disable the ON/RUN command of the drive. Then, reset the drive automatically and enable ON/RUN command of the drive. Finally, check whether the motor runs normally. | |
| 6.1 | Test the STO channel 1 when the motor is running: Set STO1 and STO2 to "H". Start the drive and ensure the motor is running. Awake the STO function by de-energizing (low state or open-circuit) the STO input signal 1. Ensure that the motor stops and the drive trips. Reset the fault and try to start the drive. Ensure that the motor stays at a standstill and the keypad of the drive displays "E150.1". | |
| 6.2 | Set STO1 to "H" and disable the ON/RUN command of the drive. Then, reset the drive automatically and enable ON/RUN command of the drive. Finally, check whether the motor runs normally. | |
| 6.3 | Test the STO channel 2 when the motor is running: Set STO1 and STO2 to "H". Start the drive and ensure the motor is running. Awake the STO function by de-energizing (low state or open-circuit) the STO input signal 2. Ensure that the motor stops and the drive trips. Reset the fault and try to start the drive. Ensure that the motor stays at a standstill and the keypad of the drive displays "E150.1". | |

| No. | ltem | |
|-----|--|------|
| NO. | iteiii | ance |
| 6.4 | Set STO2 to "H" and disable the ON/RUN command of the drive. Then, reset the drive automatically and enable ON/RUN command of the drive. Finally, check whether the motor runs normally. | |
| 7 | Document and sign the acceptance test report which verifies that the safety function is safe and acceptable for operation. | |

Verifying the achieved SIL/PL level

Verification of the functional safety system demonstrates and ensures that the implemented safety system meets the requirements specified for the system in the safety requirements specification phase.

The most convenient way to verify the required SIL/PL level reached with the implemented system is to use a specific safety calculator software.

Validation procedure

Inovance ensures that the functionality of all the required safety functions has been appropriately verified and validated.



- The system must not be considered safe until all safety functions are validated.
- The acceptance test must be performed to each safety function.

The acceptance test using the start-up checklists described below must be performed:

- at initial start-up of the safety function
- after any changes related to the safety function (wiring, components, settings, and so on.)
- after any maintenance work related to the safety function. The acceptance test must include at least the following steps:
 - 1. having an acceptance test plan
 - 2. testing all commissioned functions for proper operation
 - 3. testing all used inputs for proper operation
 - 4. testing all used outputs for proper operation
 - 5. documenting all acceptance tests performed
 - testing person signing and archiving the acceptance test report for further reference.

Acceptance test reports

You must store the signed acceptance test reports in the logbook of the machine. The report must include, as required by the referred standards:

- description of the safety application (including a figure)
- a description and revisions of safety components that are used in the safety application
- a list of all safety functions that are used in the safety application
- a list of all safety related parameters and their values (the drive STO has no safety-related parameters, but listing the non-safety related parameter and its setting is recommended)
- documentation of start-up activities, references to failure reports and resolution of failures
- the test results for each safety function, checksums, date of the tests and confirmation by the test personnel.

You must store any new acceptance test reports performed due to changes or maintenance in the logbook of the machine.

Competence

The acceptance test of the safety function must be carried out by a competent person with expertise and knowledge of the safety function as well as functional safety, as required by IEC 615081 clause 6. The test procedures and report must be documented and signed by this person.

Validation checklists for start-up

Validation of the FSoE connection

- 1. Make sure that the EtherCAT communication is enabled.
- 2. Make sure that the FSoE address of the safety drive in the network is unique.
- 3. Make sure that the safety functions are configured to be triggered through FSoE.
- 4. Make sure that the FSoE-related PDOs on the master side are configured correctly.
- 5. Make sure the FSoE watchdog time is configured correctly.
- 6. Make sure that the FSoE SRA parameters are configured correctly.
- 7. Make sure that no faults or warnings are displayed on the operation panel.

Note

FSoE certification is in progress.

Validation of safety functions

Once the system is fully configured and wired for the safety functions, and the startup safety check has been done, you must do the following functional test procedure for each safety function:

- Have the system at the Operational state when the safety function is requested.
- Make sure that the acknowledgment method has been configured as suitable for the application (for example, manual or automatic acknowledgment).
- Activate the safety function by requesting it with the designated trigger device.
- Verify that the desired functionality takes place.
- Document the test results to the acceptance test report.
- Sign and file the acceptance test report.

9 Troubleshooting

9.1 Fault and Alarm Levels

Faults and alarms of the servo drive are divided into three levels based on severity: No. 1 > No. 2 > No. 3, as shown below.

- No. 1 non-resettable fault
- No. 1 resettable fault
- No. 2 resettable fault
- No. 3 resettable alarm

Note

"Resettable" means the keypad stops displaying the fault/alarm once a "Reset signal" is input.

Operating procedure:

- To stop the keypad from displaying the fault/alarm, set H0d.01 (Fault reset) to 1
 or activate the DI assigned with DI function 2 (FunIN.2: ALM- RST, fault and alarm
 reset).
- To reset No. 1 and No. 2 faults, switch off the S-ON signal, and then set H0d.01 to 1 or activate the DI assigned with DI function 2.
- To reset No. 3 alarms, set H0d.01 to 1 or activate the DI assigned with DI function
 2.

Note

- Some faults and alarms can be reset only after the fault causes are rectified by modifying the settings. However, a reset operation does not necessarily activate the modifications to settings.
- For modifications activated at next power-on (R, S, T/L1C, L2C), perform a power cycle.
- For modifications activated after stop, switch off the S-ON signal. The servo drive can operate normally only after modifications are activated.

9.2 List of Fault and Alarm Codes

The servo drive can output the fault/alarm code of the highest level.

No. 1 non-resettable faults:

Table 9–1 List of No. 1 non-resettable faults

| Fault Code | Fault subcode | Fault Name | Fault level | Resettable | Error code (603Fh) | Aux. Code (203Fh) |
|---------------|---------------|--|-------------|------------|-----------------------|----------------------|
| E101 | E101.3 | CRC error during safety parameter initialization | No. 1 | No | 0x0101 | 0x31010101 |
| | E101.4 | Error in upper and lower limits verification during safety parameter initialization | No. 1 | No | 0x0101 | 0x41010101 |
| | E101.5 | Address error in read/write operation after the number of parameters changes | No. 1 | No | 0x0101 | 0x51010101 |
| E104 | E104.5 | Number of interrupts in the safety module FPGA incorrect | No. 1 | No | 0x0104 | 0x51040104 |
| | E104.6 | Safety module FPGA interrupt timed out | No. 1 | No | 0x0104 | 0x61040104 |
| E145 | E145.0 | Safety module chip diagnosis failure | No. 1 | No | 0x0145 | 0x01450145 |
| | E145.1 | Safety module program execution exception | No. 1 | No | 0x0145 | 0x11450145 |
| F154 | E154.0 | Speed-related functions enabled for non-safety encoder | No. 1 | No | 0x0154 | 0x01540154 |
| | E154.1 | Incorrect selection of safety function trigger mode | No. 1 | No | 0x0154 | 0x11540154 |
| | E740.0 | Encoder communication timeout | No. 1 | No | 0x7305 | 0x07400740 |
| E740 | E740.2 | Encoder communication error | No. 1 | No | 0x7305 | 0x27400740 |
| | E740.3 | Absolute encoder single- turn calculation error | No. 1 | No | 0x7305 | 0x37400740 |
| | E740.6 | Encoder write error | No. 1 | No | 0x7305 | 0x67400740 |
| | E740.9 | Encoder data transmission delay too long | No. 1 | No | 0x7305 | 0x97400740 |

| Fault Code | Fault subcode | Fault Name | Fault level | Resettable | Error code (603Fh) | Aux. Code (203Fh) |
|---------------|---------------|--|-------------|------------|-----------------------|----------------------|
| | E750.0 | Deviation of master QEP and subdivision quadrant too large (over 2 pulses) | No. 1 | No | 0x0750 | 0x07500750 |
| | E750.1 | Difference between safety encoder master and slave positions too large | No. 1 | No | 0x0750 | 0x17500750 |
| | E750.2 | QEP difference between encoder master and slave too large | No. 1 | No | 0x0750 | 0x27500750 |
| E750 | E750.3 | Difference between safety encoder master and slave analog values too large | No. 1 | No | 0x0750 | 0x37500750 |
| | E750.4 | Encoder chip power supply diagnosis exception | No. 1 | No | 0x0750 | 0x47500750 |
| | E750.5 | Encoder master and slave serial number not match | No. 1 | No | 0x0750 | 0x57500750 |
| | E750.6 | Encoder chip diagnosis exception | No. 1 | No | 0x0750 | 0x67500750 |
| | E750.7 | Encoder SPI communication error, no response from slave | No. 1 | No | 0x0750 | 0x77500750 |
| | E751.0 | Safety module encoder CRC check error | No. 1 | No | 0x0751 | 0x07510751 |
| E751 | E751.1 | Excessive deviation between speeds calculated by MCU1 and MCU2 of safety module | No. 1 | No | 0x0751 | 0x17510751 |
| | E751.2 | Safety module position 1 & 2 check error | No. 1 | No | 0x0751 | 0x27510751 |
| | E751.3 | Safety encoder version CRC error | No. 1 | No | 0x0751 | 0x37510751 |

No. 1 resettable faults

Table 9–2 List of No. 1 resettable faults

| Fault code | Fault subcode | Fault name | Fault level | Resettable | Error code (603Fh) | Aux. code (203Fh) |
|------------|---------------|---|-------------|------------|-----------------------|----------------------|
| | E124.0 | Different DIs assigned with the same function | No. 1 | Yes | 0x0124 | 0x01240124 |
| | E124.1 | Safety DI1 input circuit diagnosis exception | No. 1 | Yes | 0x0124 | 0x11240124 |
| | E124.2 | Safety DI2 input circuit diagnosis exception | No. 1 | Yes | 0x0124 | 0x21240124 |
| E124 | E124.3 | Safety DI3 input circuit diagnosis exception | No. 1 | Yes | 0x0124 | 0x31240124 |
| | E124.4 | Safety DI4 input circuit diagnosis exception | No. 1 | Yes | 0x0124 | 0x41240124 |
| | E124.5 | Safety DI5 input circuit diagnosis exception | No. 1 | Yes | 0x0124 | 0x51240124 |
| E125 | E125.0 | SSM assigned with non- safety DO serial number | No. 1 | Yes | 0x0125 | 0x01250125 |
| | E125.1 | Safety DO1 output circuit diagnosis exception | No. 1 | Yes | 0x0125 | 0x11250125 |
| | E125.2 | Safety DO2 output circuit diagnosis exception | No. 1 | Yes | 0x0125 | 0x21250125 |
| | E125.4 | Safety DO4 output circuit diagnosis exception | No. 1 | Yes | 0x0125 | 0x41250125 |
| | E125.5 | Safety DO5 output circuit diagnosis exception | No. 1 | Yes | 0x0125 | 0x51250125 |
| | E134.1 | Discrepancy at two input signals of safety DI1 | No. 1 | Yes | 0x0134 | 0x11340134 |
| | E134.2 | Discrepancy at two input signals of DI2 | No. 1 | Yes | 0x0134 | 0x21340134 |
| E134 | E134.3 | Discrepancy at two input signals of DI3 | No. 1 | Yes | 0x0134 | 0x31340134 |
| | E134.4 | Discrepancy at two input signals of DI4 | No. 1 | Yes | 0x0134 | 0x41340134 |
| | E134.5 | Discrepancy at two input signals of DI5 | No. 1 | Yes | 0x0134 | 0x51340134 |
| E135 | E135.0 | Chip 3.3V signal diagnosis exception | No. 1 | Yes | 0x0135 | 0x01350135 |

| Fault code | Fault subcode | Fault name | Fault level | Resettable | Error code (603Fh) | Aux. code (203Fh) |
|------------|---------------|---|-------------|------------|-----------------------|----------------------|
| | E150.0 | STO safety state applied | No. 1 | Yes | 0x0150 | 0x01500150 |
| | E150.1 | STO input state exception | No. 1 | Yes | 0x0150 | 0x11500150 |
| | E150.2 | Buffer 5 V voltage detection exception | No. 1 | Yes | 0x0150 | 0x21500150 |
| E150 | E150.3 | STO input circuit hardware diagnosis failure | No. 1 | Yes | 0x0150 | 0x31500150 |
| | E150.4 | PWM Buffer hardware diagnosis failure | No. 1 | Yes | 0x0150 | 0x41500150 |
| | E150.5 | STO input signal interference | No. 1 | Yes | 0x0150 | 0x51500150 |
| E151 | E151.0 | SCI communication exception between servo drive and safety module | No. 1 | Yes | 0x0151 | 0x01510151 |
| E131 | E151.1 | SCI communication exception between two MCUs of the safety module | No. 1 | Yes | 0x0151 | 0x11510151 |
| | E152.0 | Failure of parameter verification between two MCUs of the safety module | No. 1 | Yes | 0x0152 | 0x01520152 |
| E152 | E152.1 | Timeout for sending CRC between two MCUs of the safety module | No. 1 | Yes | 0x0152 | 0x11520152 |
| | E152.2 | Timeout for safety module to get initial servo parameters | No. 1 | Yes | 0x0152 | 0x21520152 |
| | E160.0 | SLS1 limit violated | No. 1 | Yes | 0x0160 | 0x01600160 |
| E160 | E160.1 | SLS2 limit violated | No. 1 | Yes | 0x0160 | 0x11600160 |
| 2100 | E160.2 | SLS3 limit violated | No. 1 | Yes | 0x0160 | 0x21600160 |
| | E160.3 | SLS4 limit violated | No. 1 | Yes | 0x0160 | 0x31600160 |
| E165 | E165.0 | SDIp exception | No. 1 | Yes | 0x0165 | 0x01650165 |
| | E165.1 | SDIn exception | No. 1 | Yes | 0x0165 | 0x11650165 |
| | E170.0 | SS1 deceleration ramp exception | No. 1 | Yes | 0x0170 | 0x01700170 |
| E170 | E170.1 | SS2 deceleration ramp exception | No. 1 | Yes | 0x0170 | 0x11700170 |
| | E170.2 | SOS speed or position exceeds limit | No. 1 | Yes | 0x0170 | 0x21700170 |
| E631 | E631.0 | SBC brake circuit diagnosis exception | No. 1 | Yes | 0x0631 | 0x06310631 |

No. 2 resettable faults

Table 9-3 List of No. 2 resettable faults

| Fault code | Fault subcode | Fault name | Fault level | Resettable | Error code (603Fh) | Aux. code (203Fh) |
|------------|---------------|---|-------------|------------|-----------------------|----------------------|
| | EE17.0 | Unexpected FSoE command | No. 2 | Yes | 0x0E17 | 0x0E170E17 |
| | EE17.1 | Unknown FSoE command | No. 2 | Yes | 0x0E17 | 0x1E170E17 |
| | EE17.2 | FSoE invalid connection ID | No. 2 | Yes | 0x0E17 | 0x2E170E17 |
| | EE17.3 | FSoE CRC error | No. 2 | Yes | 0x0E17 | 0x3E170E17 |
| | EE17.4 | FSoE watchdog expired | No. 2 | Yes | 0x0E17 | 0x4E170E17 |
| | EE17.5 | FSoE invalid slave address | No. 2 | Yes | 0x0E17 | 0x5E170E17 |
| | EE17.6 | Invalid FSoE safety data | No. 2 | Yes | 0x0E17 | 0x6E170E17 |
| EE17 | EE17.7 | Invalid FSoE communication parameter length | No. 2 | Yes | 0x0E17 | 0×7E170E17 |
| | EE17.8 | Invalid FSoE communication parameter data | No. 2 | Yes | 0x0E17 | 0x8E170E17 |
| | EE17.9 | Invalid FSoE application program parameter length | No. 2 | Yes | 0x0E17 | 0x9E170E17 |
| | EE17.A | Invalid FSoE application program parameter data | No. 2 | Yes | 0x0E17 | 0xAE170E17 |

No. 3 resettable alarms

Table 9-4 Resettable alarm list

| Alarm code | Alarm subcode | Name | Fault level | Resettable | Error code (603Fh) | Aux. Code (203Fh) |
|------------|---------------|--|-------------|------------|-----------------------|----------------------|
| E108 | E108.5 | Safety module EEPROM- write timed out | No. 3 | Yes | 0x0108 | 0x51080108 |
| | E108.6 | Safety module EEPROM- read timed out | No. 3 | Yes | 0x0108 | 0x61080108 |
| | E108.7 | Safety module EEPROM- write check error | No. 3 | Yes | 0x0108 | 0x71080108 |
| | E108.8 | Safety module EEPROM- read check error | No. 3 | Yes | 0x0108 | 0x81080108 |
| E115 | E115.0 | SSM parameter setting exception alarm | No. 3 | Yes | 0x0115 | 0x011150115 |
| E116 | E116.0 | SLS overspeed alarm | No. 3 | Yes | 0x0116 | 0x011160116 |
| | E116.1 | SDI tolerance violation alarm | No. 3 | Yes | 0x0116 | 0x111160116 |

9.3 Solutions to Faults

• E101.3: CRC error during safety parameter initialization Cause:

The CRC value of the safety parameters is abnormal, which generally occurs after software update.

| Cause | Check Method | Solution |
|--|--|---|
| 1. The software is updated. | Check whether the software is updated. | Restore safety parameters to default settings. |
| 2. The voltage of the control circuit power supply drops instantaneously. | Check whether the control circuit (L1C, L2C) is in the process of power-off or instantaneous power failure occurs. Measure whether the input voltage of the control circuit cable on the non-drive side is within the following range:220 V servo drive: Effective value: 220 V to 240 V Allowable deviation: -10% to +10% (198 V to 264 V)380 V servo drive: Effective value: 380 V to 440 V Allowable deviation: -10% to +10% (342 V to 484 V) | Restore safety parameters to default settings and write parameters again. Increase the power supply capacity or replace the power supply with a power supply of higher capacity. Restore the safety parameters to default settings and write the parameters again. |
| 3. Instantaneous power failure occurs when saving parameters. | Check whether instantaneous power failure occurs when saving parameters. | Power on again, restore the safety parameters to default settings and write parameters again. |
| 4. The number of write operations within a certain period of time exceeds the limit. | Check whether parameters are updated frequently through the host controller. | Change the parameter writing method and write parameters again. |
| 5. The safety module has failed. | If the fault persists though parameters are restored to default settings and the servo drive is powered off and on repeatedly, the safety module is faulty. | Replace the safety module. |

 E101.4: Error in upper and lower limits verification during safety parameter initialization
 Cause:

- $1. \ The \ total \ number \ of \ the \ safety \ parameters \ changes, \ which \ generally \ occurs \ after \ software \ update.$
- 2. Values of the safety parameters exceed the limit, which generally occurs after software update.

| Cause | Check Method | Solution |
|--|---|---|
| 1. The software is updated. | Check whether the software is updated. | Restore safety parameters to default settings. |
| 2. The voltage of the control circuit power supply drops instantaneously. | Check whether the control circuit (L1C, L2C) is in the process of power-off or instantaneous power failure occurs. Measure whether the input voltage of the control circuit cable on the non-drive side is within the following range:220 V servo drive: Effective value: 220 V to 240 V Allowable deviation: -10% to +10% (198 V to 264 V)380 V servo drive: Effective value: 380 V to 440 V Allowable deviation: -10% to +10% (342 V to 484 V) | Restore safety parameters to default settings and write parameters again. Increase the power supply capacity or replace the power supply with a power supply of higher capacity. Restore the safety parameters to default settings and write the parameters again. |
| 3. Instantaneous power failure occurs when saving parameters. | Check whether instantaneous power failure occurs when saving parameters. | Power on again, restore the safety parameters to default settings and write parameters again. |
| 4. The number of write operations within a certain period of time exceeds the limit. | Check whether parameters are updated frequently through the host controller. | Change the parameter writing method and write parameters again. |
| 5. The safety module has failed. | If the fault persists though parameters are restored to default settings and the servo drive is powered off and on repeatedly, the safety module is faulty. | Replace the safety module. |

• E101.5: Address error in read/write operation after the number of parameters changes

Cause:

The total number of the safety parameters changes, which generally occurs after software update.

| Cause | Check Method | Solution |
|----------------------------------|--|--|
| 1. The software is updated. | Check whether the software is updated. | Restore safety parameters to default settings. |
| 2. The safety module has failed. | If the fault persists though parameters are restored to default settings and the servo drive is powered off and on repeatedly, the safety module is faulty. | Replace the safety module. |

 E104.5: The number of interrupts in the safety module FPGA is abnormal Cause:

The number of interrupts detected in 1 ms is less than four.

| Cause | Check Method | Solution |
|--|---|-----------------------------|
| 1. A FPGA error occurs. | | |
| 2. The interrupt pin includes dry joint. | Frequent power-off/on operations can lead to this | Replace the servo drive and |
| 3. The connection between the servo drive and the safety module is abnormal. | fault. | safety module. |

• E104.6: Safety module FPGA interrupt timed out Cause:

The FPGA interrupt is running longer than the interrupt scheduling time.

| Cause | Check Method | Solution |
|-------------------------------|--|--|
| The safety module has failed. | Frequent power-off/on operations can lead to this fault. | Replace the servo drive and safety module. |

• E124.0: Different DIs assigned with the same function Cause:

The function numbers of the safety DI terminals are duplicated.

| Cause | Check Method | Solution |
|---|------------------------|-----------------------------------|
| One DI function cannot be reused by two or more DI terminals. | number is selected for | Ensure that the number is unique. |

• E124.1: DI1 input circuit diagnosis exception Cause:

Send a diagnostic signal to DI1 to check whether the feedback signal is correct.

| Cause | Check Method | Solution |
|---|--|---|
| The MCU sent a diagnostic signal. The feedback signal is incorrect. | Check whether the DI1 circuit is normal. Disconnect and then reconnect the 24 V input voltage of DI1, and observe whether the input signal of DI1 changes (You can sample and analyze the input signal of DI1 through the oscilloscope in the software tool). | If the DI1 circuit is abnormal, shield DI1 by setting its function number to 0. If it cannot be shielded, it is recommended to replace the safety control board. |

• E124.2: Safety DI2 input circuit diagnosis exception Cause:

Send a diagnostic signal to DI2 to check whether the feedback signal is correct.

| Cause | Check Method | Solution |
|---|--|---|
| The MCU sent a diagnostic signal. The feedback signal is incorrect. | Check whether the DI2 circuit is normal. Disconnect and then reconnect the 24 V input voltage of DI2, and observe whether the input signal of DI2 changes (You can sample and analyze the input signal of DI2 through the oscilloscope in the software tool). | If the DI2 circuit is abnormal, shield DI2 by setting its function number to 0. If it cannot be shielded, it is recommended to replace the safety control board. |

• E124.3: Safety DI3 input circuit diagnosis exception Cause:

Send a diagnostic signal to DI3 to check whether the feedback signal is correct.

| Cause | Check Method | Solution |
|---|--|---|
| The MCU sent a diagnostic signal. The feedback signal is incorrect. | Check whether the DI3 circuit is normal. Disconnect and then reconnect the 24 V input voltage of DI3, and observe whether the input signal of DI3 changes (You can sample and analyze the input signal of DI3 through the oscilloscope in the software tool). | If the DI3 circuit is abnormal, shield DI3 by setting its function number to 0. If it cannot be shielded, it is recommended to replace the safety control board. |

• E124.4: Safety DI4 input circuit diagnosis exception Cause:

Send a diagnostic signal to DI4 to check whether the feedback signal is correct.

| Cause | Check Method | Solution |
|---|--|---|
| The MCU sent a diagnostic signal. The feedback signal is incorrect. | Check whether the DI4 input circuit is normal. Disconnect and then reconnect the 24 V input voltage of DI4, and observe whether the input signal of DI4 changes (You can sample and analyze the input signal of DI4 through the oscilloscope in the software tool). | If the DI4 circuit is abnormal, shield DI4 by setting its function number to 0. If it cannot be shielded, it is recommended to replace the safety control board. |

 E124.5: Safety DI5 input circuit diagnosis exception Cause:

Send a diagnostic signal to DI5 to detect whether the feedback signal is correct.

| Cause | Check Method | Solution |
|---|--|---|
| The MCU sent a diagnostic signal. The feedback signal is incorrect. | Check whether the DI5 input circuit is normal. Disconnect and then reconnect the 24 V input voltage of DI5, and observe whether the input signal of DI5 changes (You can sample and analyze the input signal of DI5 through the oscilloscope in the software tool). | If the DI5 circuit is abnormal, shield DI5 by setting its function number to 0. If it cannot be shielded, it is recommended to replace the safety control board. |

• E125.0: SSM assigned with non-safety DO serial number Cause:

Check whether SSM is assigned to DO3 and DO6.

| Cause | Check Method | Solution |
|--|----------------------------|---|
| The SSM cannot use non-safety DO as signal output. | numbers of DO3 and DO6 are | Do not assign the function numbers of DO3 and DO6 as SSM functions. |

E125.1: DO1 output circuit diagnosis exception
 Cause:

When DO1 is active, the MCU sends a diagnostic pulse to DO1 to detect whether the AD sampling value of the feedback signal is below 0.3 V.

| Cause | Check Method | Solution |
|---|---|--|
| After the MCU sends a diagnostic pulse to DO1, the feedback voltage received by the MCU is not below 0.3 V. | Execute fault reset to check whether the fault can be cleared. If the fault persists, check whether there is leakage current in the DO1 output circuit. | Shield DO1, and the safety module no longer detects whether there is a leakage current risk in DO1. |

 E125.2: DO2 output circuit diagnosis exception Cause:

When DO2 is active, the MCU sends a diagnostic pulse to DO2 to detect whether the AD sampling value of the feedback signal is below 0.3 V.

| Cause | Check Method | Solution |
|---|---|--|
| After the MCU sends a diagnostic pulse to DO2, the feedback voltage received by the MCU is not below 0.3 V. | Execute fault reset to check whether the fault can be cleared. If the fault persists, check whether there is leakage current in the DO2 output circuit. | Shield DO2, and the safety module no longer detects whether there is a leakage current risk in DO2. |

 E125.4: DO4 output circuit diagnosis exception Cause:

When DO4 is active, the MCU sends a diagnostic pulse to DO4 to detect whether the AD sampling value of the feedback signal is below 0.3 V.

| Cause | Check Method | Solution |
|---|---|--|
| After the MCU sends a diagnostic pulse to DO4, the feedback voltage received by the MCU is not below 0.3 V. | Execute fault reset to check whether the fault can be cleared. If the fault persists, check whether there is leakage current in the DO4 output circuit. | Shield DO4, and the safety module no longer detects whether there is a leakage current risk in DO4. |

 E125.5: DO5 output circuit diagnosis exception Cause:

When DO5 is active, the MCU sends a diagnostic pulse to DO5 to detect whether the AD sampling value of the feedback signal is below 0.3 V.

| Cause | Check Method | Solution |
|---|---|--|
| After the MCU sends a diagnostic pulse to DO5, the feedback voltage received by the MCU is not below 0.3 V. | Execute fault reset to check whether the fault can be cleared. If the fault persists, check whether there is leakage current in the DO5 output circuit. | Shield DO5, and the safety module no longer detects whether there is a leakage current risk in DO5. |

• E134.1: Discrepancy at two input signals of DI1 Cause:

Check whether the DI1 input signal exceeds the value of H20.14.

| Cause | Check Method | Solution |
|---|--|--|
| The fault code is reported when the difference between two inputs of DI1 exceeds the value of H20.14. | Observe whether the difference lasts longer than the setpoint of H20.14. | Ensure the difference does not last longer than the value of H20.14. |

• E134.2: Discrepancy at two input signals of DI2 Cause:

Check whether the DI2 input signal exceeds the value of H20.15.

| Cause | Check Method | Solution |
|---|--|--|
| The fault code is reported when the difference between two inputs of DI2 exceeds the value of H20.15. | Observe whether the difference lasts longer than the setpoint of H20.15. | Ensure the difference does not last longer than the value of H20.15. |

E134.3: Discrepancy at two input signals of DI3
 Cause:

Check whether the DI3 input signal exceeds the value of H20.16.

| Cause | Check Method | Solution |
|---|--|--|
| The fault code is reported when the difference between two inputs of DI3 exceeds the value of H20.16. | Observe whether the difference lasts longer than the setpoint of H20.16. | Ensure the difference does not last longer than the value of H20.16. |

• E134.4: Discrepancy at two input signals of DI4 Cause:

Check whether the DI4 input signal exceeds the value of H20.17.

| Cause | Check Method | Solution |
|---|--|--|
| The fault code is reported when the difference between two inputs of DI4 exceeds the value of H20.17. | Observe whether the difference lasts longer than the setpoint of H20.17. | Ensure the difference does not last longer than the value of H20.17. |

• E134.5: Discrepancy at two input signals of DI5 Cause:

Check whether the DI5 input signal exceeds the value of H20.18.

| Cause | Check Method | Solution |
|---|--|--|
| The fault code is reported when the difference between two inputs of DI5 exceeds the value of H20.18. | Check whether the difference lasts longer than the setpoint of H20.18. | Ensure the difference does not last longer than the value of H20.18. |

 E135.0: Chip 3.3 V signal diagnosis error Cause:

The two chips diagnose whether the supply voltage of each other is within the allowed range of $3.0\,\mathrm{V}$ to $3.6\,\mathrm{V}$.

| Cause | Check Method | Solution |
|---|---|----------------------------|
| The chip voltage is out of the range of 3.0 V to 3.6 V. | Check whether the power supply voltage of the chip is normal. | Replace the safety module. |

 E145.0: Safety module chip diagnosis failure Cause:

The chip diagnosis of the safety module failed.

| Cause | Check Method | Solution |
|--|--|--|
| 1. The CPU diagnosis of the chip failed. | Frequent power-off/on operations can lead to this fault. | Replace the servo drive and safety module. |
| 2. The RAM diagnosis of the chip failed. | | |
| 3. The FLASH diagnosis of the chip failed. | | |
| 4. The software program has stack overflow problems. | | |

• E145.1: Safety module program execution exception Cause:

The internal program execution of the safety module is abnormal and the 16 kHz interrupt function is not executed.

| Cause | Check Method | Solution |
|--|---|-------------------|
| The internal program execution of the safety module is abnormal and the 16 kHz interrupt function is not executed. | The fault still exists after power off and restart. | Contact Inovance. |

• E150.0: STO safety state applied Cause:

The STO input protection applies (safety state).

| Cause | Check Method | Solution |
|--|---|--|
| One or two 24 V inputs are disconnected simultaneously, triggering the STO function. | Check whether the STO function is activated. | There is no need to take any corrective actions. After the STO terminal is back to normal, clear the fault using the fault reset function. |
| | 2. Check whether the STO power supply is normal. | Check whether the 24 V power supply for the STO is stable. Tighten the cables that are loose or disconnected. |
| | 3. The fault persists after preceding causes are rectified. | Replace the servo drive. |

• E150.1: STO input state abnormal Cause:

The single-channel input of STO is ineffective.

| Cause | Check Method | Solution |
|--|--|---|
| 1. STO input power supply is abnormal. | Check whether the STO power supply is normal. | Check whether the 24 V power supply for the STO is stable. Tighten the cables that are loose or disconnected. |
| 2. STO input resistor is abnormal. | After STO is triggered, only one STO signal is sent to MCU after the 24 V power supply is cut off due to input resistor drift. | Replace the servo drive. |
| 3. The STO fails. | The fault persists after preceding causes are rectified. | Replace the servo drive. |

• E150.2: Buffer 5 V voltage detection error Cause:

The MCU monitors the 5 V power supply of the PWM Buffer to detect whether overvoltage or undervoltage occurs. If the voltage is abnormal, E150.2 occurs.

| Cause | Check Method | Solution |
|----------------------------|--|--------------------------|
| the STO Buffer is abnormal | Check whether the fault can be removed by a restart. If not, the 5V voltage supplied to the Buffer is abnormal. | Replace the servo drive. |

 E150.3: STO input circuit hardware diagnosis failure Cause:

Short circuit occurs on the optocoupler in the upstream hardware circuit of STO.

| Cause | Check Method | Solution |
|-------|--|--------------------------|
| | The fault persists and the keypad displays E150.3 after restart. | Replace the servo drive. |

 E150.4: PWM buffer hardware detection failure Cause:

An error occurs on the PWM Buffer integrated circuit during initialization detection upon power-on (the PWM signal cannot be blocked).

| Cause | Check Method | Solution |
|--------------------------------|--|--------------------------|
| STO Buffer power-on test error | The fault persists and the keypad displays E150.4 after restart. | Replace the servo drive. |

• E150.5: STO input signal interference Cause:

The STO signal is being disturbed, and the noise filtering condition defined by H0A.73 is not met.

| Cause | Check Method | Solution |
|---|--|---|
| The STO terminal is in poor contact or the external 24 V input voltage is unstable, which may lead to malfunction of STO. | Check whether the 24 V input voltage of the STO terminal is unstable, leading to frequent restart. | Replace the 24 V power supply to ensure the STO terminal input voltage is stable. |

 E151.0: SCI communication exception between servo drive and safety module Cause:

The NXP chip diagnoses in real time whether the heartbeat of the InoBus communication with the main MCU is normal.

| Cause | Check Method | Solution |
|--------------------------|------------------------------|------------------------------|
| The heartbeat detection | Check whether the hardware | Ensure that the physical |
| between the servo drive | connection between the | connection between the |
| and the safety module is | servo drive and the board is | board and the servo drive is |
| abnormal. | normal. | normal. |

 E151.1: SCI communication exception between two MCUs of the safety module Cause:

SCI communication exception between two MCUs of the safety module

| Cause | Check Method | Solution |
|--|--------------|--|
| The internal RS232 data interaction and communication of the safety board is faulty. | - | Detect whether interference near the drive affects RS232 communication transmission. If the problem persists after the power supply is restarted, contact Inovance. |

• E152.0: Failure of parameter verification between two MCUs of the safety module Cause:

The CRC values of the safety parameters read from the EEPROM by the dual MCUs of the safety module are inconsistent.

| Cause | Check Method | Solution |
|--|--|---|
| 1. The software is updated. | Check whether the software is updated. | Restore safety parameters to default settings. |
| 2. The voltage of the control circuit power supply drops instantaneously. | Check whether the control circuit (L1C, L2C) is in the process of power-off or instantaneous power failure occurs. Measure whether the input voltage of the control circuit cable on the non-drive side is within the following range:220 V servo drive: Effective value: 220 V to 240 V Allowable deviation: -10% to +10% (198 V to 264 V)380 V servo drive: Effective value: 380 V to 440 V Allowable deviation: -10% to +10% (342 V to 484 V) | Restore safety parameters to default settings and write parameters again. Increase the power supply capacity or replace the power supply with a power supply of higher capacity. Restore the safety parameters to default settings and write the parameters again. |
| 3. Instantaneous power failure occurs when saving parameters. | Check whether instantaneous power failure occurs when saving parameters. | Power on again, restore the safety parameters to default settings and write parameters again. |
| 4. The number of write operations within a certain period of time exceeds the limit. | Check whether parameters are updated frequently through the host controller. | Change the parameter writing method and write parameters again. |
| 5. The safety module has failed. | If the fault persists though parameters are restored to default settings and the servo drive is powered off and on repeatedly, the safety module is faulty. | Replace the safety module. |

 E152.1: Timeout for sending CRC between two MCUs of the safety module Cause:

When the two MCUs of the safety module are powered on for communication, the sending of the CRC times out.

| Cause | Check Method | Solution |
|--|---|---|
| 1. The communication between MCU1 and MCU2 of the safety module is disturbed. | Check for interference around the safety module. | Reduce interference around the safety module. |
| 2. The safety module has failed. | Check whether replacing the safety module solves the problem. | Replace the safety module. |

E152.2: Timeout for safety module to get initial servo parameters
 Cause:

When the safety module and the servo drive are powered on for communication, the security module has timed out to obtain the initial parameters of the servo drive.

| Cause | Check Method | Solution |
|---|---|--|
| 1. The communication between the safety module and the servo drive is disturbed. | Check whether the connection between the safety module and the servo drive is normal. | Connect the safety module and servo drive correctly. |
| 2. The safety module has failed. | Check whether replacing the safety module solves the problem. | Replace the safety module. |

 E154.0: Speed-related functions enabled for non-safety encoder Cause:

The speed-related safety functions are enabled when a non-safety encoder is used, or when a safety encoder is used but H00.00 is not set to 14102.

| Cause | Check Method | Solution |
|----------------------------------|---|-----------------------|
| 1. A non-safety encoder is used. | Check whether the encoder used is a non-safety encoder. | Use a safety encoder. |
| 2. H00.00 is not set to 14102. | Check whether H00.00 is set to 14102. | Set H00.00 to 14102. |

| Cause | Check Method | Solution |
|---|--|---|
| 3. When a non-safety encoder is used, the DI is set to speed-related functions. | When a non-safety encoder is used, check whether the DI is set to speed-related functions. | When a non-safety encoder is used, set the DI to functions not related to speed. |
| 4. When a non-safety encoder is used, the DI is set to SS1 and the monitoring mode is set to SS1-r. | When a non-safety encoder is used, check whether the DI is set to SS1 and the monitoring mode is set to SS1-r. | When a non-safety encoder is used and the DI is set to SS1, set the monitoring mode to SS1-t. |

 E154.1: Incorrect selection of safety function trigger mode Cause:

For non-EtherCAT models, the safety function is triggered through FSoE mode.

| Cause | Check Method | Solution |
|--|---|--|
| For non-EtherCAT models, the safety function trigger mode is selected as FSoE trigger | Check whether the servo drive is a EtherCAT model. Check whether the safety function trigger mode is selected as FSoE trigger. | For non-EtherCAT models, select the safety function trigger mode as local trigger. |

• E160.0: SLS1 exceeded Cause:

The speed feedback real-time value exceeds the limit value of SLS1 after SLS1 monitoring is active.

| Cause | Check Method | Solution |
|---|----------------------------|--|
| The speed feedback real- time value exceeds the limit value of SLS1 after SLS1 monitoring is active. | fault record to see if the | Control the motor speed so that it does not exceed the limit value of SLS1 after SLS1 monitoring is active. |

• E160.1: SLS2 exceeded Cause:

The speed feedback real-time value exceeds the limit value of SLS2 after SLS2 monitoring is active.

| Cause | Check Method | Solution |
|---|--|--|
| The speed feedback real- time value exceeds the limit value of SLS2 after SLS2 monitoring is active. | When the stop mode upon SLS fault is STO, check the fault record to see if the corresponding speed exceeds the limit value of SLS2 when the SLS2 fault occurs. | Control the motor speed so that it does not exceed the limit value of SLS2 after SLS2 monitoring is active. |

• E160.2: SLS3 exceeded

Cause:

The speed feedback real-time value exceeds the limit value of SLS3 after SLS3 monitoring is active.

| Cause | Check Method | Solution |
|---|--|---|
| The speed feedback real- time value exceeds the limit value of SLS3 after SLS3 monitoring is active. | When the stop mode upon SLS fault is STO, check the fault record to see if the corresponding speed exceeds the limit value of SLS3 when the SLS3 fault occurs. | Control the motor speed so that it does not exceed the limit value of SLS3 after SLS3 monitoring is active. |

• E160.3: SLS4 exceeded Cause:

The speed feedback real-time value exceeds the limit value of SLS4 after SLS4 monitoring is active.

| Cause | Check Method | Solution |
|---|--|--|
| The speed feedback real- time value exceeds the limit value of SLS4 after SLS4 monitoring is active. | When the stop mode upon SLS fault is STO, check the fault record to see if the corresponding speed exceeds the limit value of SLS4 when the SLS4 fault occurs. | Control the motor speed so that it does not exceed the limit value of SLS4 after SLS4 monitoring is active. |

• E165.0: SDIp exception

Cause:

The motor cannot move in the positive direction or the positive movement exceeds the limit.

| Cause | Check Method | Solution |
|--|--|---|
| The motor moves in the positive direction when not allowed to do so, or the positive movement exceeds the limit. | When the stop mode upon SDI fault is STO, check the fault record to see if the positive rotation speed at the time of fault exceeds the zero speed window of SDI or if the positive rotation position exceeds the zero position window of SDI. | When positive movement is prohibited, ensure that the motor does not exceed the allowable conditions for positive movement. |

• E165.1: SDIn exception

Cause:

The motor cannot move in the negative direction or the negative movement exceeds the limit.

| Cause | Check Method | Solution |
|--|--|---|
| The motor moves in the negative direction when not allowed to do so, or the negative movement exceeds the limit. | When the stop mode upon SDI fault is STO, check the fault record to see if the negative rotation speed at the time of fault exceeds the zero speed window of SDI or if the negative rotation position exceeds the zero position window of SDI. | When negative movement is prohibited, ensure that the motor does not exceed the allowable conditions for negative movement. |

• E170.0: SS1 deceleration ramp exception Cause:

After SS1 deceleration ramp monitoring is started, the actual deceleration ramp exceeds the preset monitoring threshold.

| Cause | Check Method | Solution |
|--|---|---|
| The deceleration and monitoring threshold are not properly set, and the actual deceleration ramp exceeds the monitoring threshold. | Check whether the preset deceleration is within the monitoring threshold range. | Reasonably set the SS1 deceleration and ramp monitoring threshold to ensure that the deceleration is within the monitoring threshold range. |

• E170.1: SS2 deceleration ramp exception Cause:

After SS2 deceleration ramp monitoring is started, the actual deceleration ramp exceeds the preset monitoring threshold.

| Cause | Check Method | Solution |
|--|---|---|
| The deceleration and monitoring threshold are not properly set, and the actual deceleration ramp exceeds the monitoring threshold. | Check whether the preset deceleration is within the monitoring threshold range. | Reasonably set the SS2 deceleration and ramp monitoring threshold to ensure that the deceleration is within the monitoring threshold range. |

• E170.2: SOS speed or position exceeds limit Cause:

In the SOS state, the actual speed or position change exceeds the preset monitoring threshold.

| Cause | Check Method | Solution |
|---|---|---|
| 1. The delay from SS2 to SOS is set too short, as a result the position and speed monitoring to start before the motor stops. | Check whether the delay from SS2 to SOS is set properly. | Reasonably set the delay from SS2 to SOS. |
| 2. The speed and position monitoring threshold settings of SOS are unreasonable. | Check whether the speed and position monitoring thresholds of the SOS are properly set. | Reasonably set the speed and position monitoring thresholds of SOS. |
| 3. The load is too large, resulting in insufficient motor output to maintain the position. | Check whether the motor model is proper. | Select a proper motor model. |

• E631.0: SBC brake circuit diagnosis exception Cause:

In the SOS state, the actual speed or position change exceeds the preset monitoring threshold.

| Cause | Check Method | Solution |
|---|--|---|
| 1. The SBC circuit is abnormal when the board card is powered on. | Check whether the 24 V voltage of the SBC is normal. | Ensure that the 24 V voltage of the SBC is normal. |
| 2. The brake is abnormal during SBC brake release. | The SBC brake circuit is faulty. | In case of the SBC circuit hardware failure, it is recommended to return it to the factory for maintenance. |

• E740.0: Encoder communication timeout Cause:

Communication timeout occurs on the absolute encoder.

| Cause | Check Method | Solution |
|---|--|---|
| The encoder cable is connected loosely. | 1. Check the encoder cable connection. 2. Check whether vibration on site is too strong, which loosens the encoder cable and even damages the encoder. 3. Replace with a new encoder cable. If the fault no longer occurs after cable replacement, it indicates the original encoder cable is damaged. | Check whether the encoder version (H00.04) is set properly. Check whether the servo drive software version (H01.00). Check the encoder cable connections. Replace the servo motor. |

• E740.2: Encoder communication error Cause:

A communication error occurs on the RX side of the encoder.

| Cause | Check Method | Solution |
|--|--|--|
| 1. The encoder is wired improperly. | Check the wiring of the encoder. | Connect the encoder cables according to the correct wiring diagram. |
| 2. The encoder cable is connected loosely. | Check whether vibration on site is too strong, which loosens the encoder cable and even damages the encoder. | Re-connect encoder cables and ensure encoder terminals are connected securely. |

| | | 2.1.1 |
|---|--|--|
| Cause | Check Method | Solution |
| 3. The encoder Z signal is being disturbed. | Check the field cable layout:Check whether ambient devices are generating disturbance and whether multiple disturbance sources such as variable-frequency devices are present inside the cabinet. Make the drive stay in "rdy" state and rotate the motor shaft counterclockwise (CCW) manually. Then observe whether the value of H0b.17 (Electrical angle) increases/decreases smoothly. Turning one circle corresponds to five 0°–360° (for Z series motor). For X series motor). For X series motors, turning one circle corresponds to four 0–360°. If H0b.17 changes abnormally when you rotate the motor shaft manually, the encoder is faulty. If no alarm is reported during motor shaft rotating but an alarm is reported during servo drive running, interference may exist. | It is recommended to use the cables provided by Inovance. If a customized cable is used, check whether this cable is a shielded twisted pair cable that complies with the specifications. Route the motor cables and encoder cables through different routes. Ensure the servo motor and servo drive are grounded properly. Check whether the connectors at both ends of the encoder are in good contact and whether any pin retracts. |
| 4. The encoder is faulty. | Replace with a new encoder cable. If the fault no longer occurs after cable replacement, it indicates the original encoder cable is damaged. Keep the motor in a certain position, power on the system several times and observe the change of H0b.17 (Electrical angle). The electrical angle deviation should be within ±30° when the motor position does not change. | Use a new encoder cable. If the fault persists after the encoder cable is replaced, the encoder may be faulty. In this case, replace the servo motor. |

| Cause | Check Method | Solution |
|---|---|---|
| 5. T2 interpolator does not support software reset. | If H00.04 starts with 208, the T2 interpolator applies. | Power on and off again. If the fault persists, continue troubleshooting based on steps 1 to 4. |

• E740.3: Absolute encoder single-turn calculation error Cause:

The encoder is faulty.

| Cause | Check Method | Solution |
|------------------------|---|--|
| The encoder is faulty. | Replace with a new encoder cable. If the fault no longer occurs after cable replacement, it indicates the original encoder cable is damaged. Keep the motor in a fixed position, restart several times and observe the change of the electrical angle H0b.17 upon each restart, which should be within ±30°. | 1. Check whether the encoder version (H00.04) is proper. 2. Check whether the encoder cable is proper. 3. Replace the motor. |

• E740.6: Encoder data write error Cause:

The attempt to write the encoder data fails.

| Cause | Check Method | Solution |
|---|---|--|
| An error occurs when writing the position offset after angle auto-tuning. | Replace with a new encoder cable. If the fault no longer occurs after cable replacement, it indicates the original encoder cable is damaged. Keep the motor in a fixed position, restart several times and observe the change of the electrical angle H0b.17 upon each restart, which should be within $\pm 30^\circ$. | Use a new encoder cable. If the fault persists after the encoder cable is replaced, the encoder may be faulty. In this case, replace the servo motor. |

• E740.9: Encoder data transmission delay too long Cause:

The set encoder data transmission delay exceeds one current cycle.

| Cause | Check Method | Solution |
|---|-------------------------|--|
| 1. H01.59 is set to an excessively high value. | Check whether the fault | Reduce the value of H01.59. |
| 2. The number of encoder data bits is too long. | persists after restart. | Replace with an encoder with lower number of bits. |

E750.0: Deviation of master QEP and subdivision quadrant too large (over 2 pulses)
 Cause:

Deviation of master QEP and subdivision quadrant too large (over 2 pulses).

| Cause | Check Method | Solution |
|--|---|-------------------|
| The encoder disk is contaminated or other photoelectric devices are disturbed. | Check whether the fault persists after restart. | Contact Inovance. |

 E750.1: Difference between safety encoder master and slave positions too large Cause:

Difference between safety encoder master and slave positions too large

| Cause | Check Method | Solution |
|--|---|-------------------|
| Difference between safety encoder master and slave positions too large | Check whether the fault persists after restart. | Contact Inovance. |

 E750.2: QEP difference between encoder master and slave too large Cause:

The difference between QEP counts of the master and slave is greater than 2.

| Cause | Check Method | Solution |
|--|---|-------------------------------|
| Board-level signal interference, encoder disk contamination, chip peripherals exception. | Check the encoder surroundings for interference source. | Replace the motor or encoder. |

 E750.3: Difference between safety encoder master and slave analog values too large

Cause:

Difference between safety encoder master and slave sampled analog values too large

| Cause | Check Method | Solution |
|---|---|-------------------|
| Difference between safety encoder master and slave sampled analog values too large | Check whether the fault persists after restart. | Contact Inovance. |

 E750.4: Encoder chip power supply diagnosis exception Cause:

LDO or battery voltage is lower than 3.1 V.

| Cause | Check Method | Solution |
|--|--|-------------------------------|
| The external power supply of the encoder is under voltage, the LDO device is damaged, and the battery voltage is low | Check whether the battery is correctly connected. Check whether the encoder is powered normally. | Replace the motor or encoder. |

• E750.5: Encoder master and slave serial numbers not match Cause:

SN counts of the master and slave are not equal.

| Cause | Check Method | Solution |
|---|---|-------------------------------|
| The chip runs abnormally, and the master and slave do not exchange data normally. | Check whether the chip is abnormal due to too high ambient temperature. | Replace the motor or encoder. |

 E750.6: Encoder chip diagnosis exception Cause:

The flash, RAM, and chip of the master or slave are diagnosed faulty.

| Cause | Check Method | Solution |
|----------------|---|-------------------------------|
| Chip exception | Check whether the chip is abnormal due to too high ambient temperature. | Replace the motor or encoder. |

 E750.7: Encoder SPI communication error, no response from the slave Cause:

The slave failed to receive the command word from the master, or the master failed to receive the reply frame from the slave.

| Cause | Check Method | Solution |
|---|---|-------------------------------|
| Board-level communication interference causes internal CRC failure, peripheral abnormality, and so on. | Check whether the chip is abnormal due to too high ambient temperature. | Replace the motor or encoder. |

• E751.0: Safety module encoder CRC error Cause:

1. The SN increment received by the safety module is abnormal.

2. The CRC value calculated by the safety module is inconsistent with the received CRC value.

| Cause | Check Method | Solution |
|--|---|--|
| 1. The encoder cable is abnormal. | Check whether the encoder cables are normal. | Check whether encoder cables are connected properly. |
| 2. The communication with encoder suffers from interference. | Check for interference around the encoder cables. | Check whether the servo drive and motor are properly grounded, and you can put a magnetic ring on the encoder to reduce the interference. Replace the motor or encoder. |

 E751.1: Excessive deviation between speeds calculated by MCU1 and MCU2 of safety module

Cause:

The deviation between the speeds calculated by MCU1 and MCU2 exceeds the threshold.

| Cause | Check Method | Solution |
|--|---|---|
| 1. The communication between MCU1 and MCU2 of the safety module is disturbed. | Check for interference around the safety module. | Reduce interference around the safety module. |
| 2. The safety module has failed. | Check whether replacing the safety module solves the problem. | Replace the safety module. |

 E751.2: Safety module position 1 & 2 check error Cause:

The deviation between position 1 and position 2 received by the safety module exceeds the threshold.

| Cause | Check Method | Solution |
|-------------------------------|--|-----------------------------|
| The safety encoder is faulty. | Check whether replacing the safety encoder solves the problem. | Replace the safety encoder. |

- E751.3: Safety encoder version number CRC error Cause:
 - The safety encoder software version is not 264xx.
 - The CRC value of the safety encoder version number is abnormal.

| Cause | Check Method | Solution |
|--|--|---|
| The safety encoder version (H00.04) is not 264xx. | Check whether the fault persists after restart. | Contact Inovance. |
| The CRC value of the safety encoder version number is wrong. | Check the wiring. After power on and off for multiple times, if the fault persists, the encoder is faulty. | Check the wiring. After power on and off for multiple times, if the fault persists, replace the encoder. |

• EE17.0: FSoE unexpected command Cause:

In the current state of FSoE communication, this command should not appear.

| Cause | Check Method | Solution |
|--|-------------------------------------|--|
| 1. In the reset state, the slave has received the Connection, Parameter, ProcessData, FailSafeData commands. | | |
| 2. In the Session state, the slave has received the Parameter, ProcessData, FailSafeData commands. | | |
| 3. In the Connection state, the slave has received ProcessData and FailSafeData commands. | The keypad displays the fault code. | Check whether the command sent by the safety master is wrong. Check whether the safety |
| 4. In the Parameter state, the slave has received the Connection command. | | PDO data has been modified. |
| 5. In the Data state, the slave has received the Connection and Parameter commands. | | |
| 6. In Session, Connection, and Parameter states, the number of safety PDUs sent is 0. | | |

• EE17.1: Unknown FSoE command Cause:

Unspecified command word appeared in FSoE communication.

| Cause | Check Method | Solution |
|--|-------------------------------------|---|
| The slave has received commands other than reset, Session, Connection, Parameter, ProcessData, and FailSafeData. | The keypad displays the fault code. | Check whether the command sent by the safety master is wrong. Check whether the safety PDO data has been modified. |

 EE17.2: FSoE invalid connection ID Cause:

The ID of the connection established by the FSoE does not match the ID received.

| Cause | Check Method | Solution |
|--|-------------------------------------|---|
| In Connection, Parameter, ProcessData, FailSafeData states, the connection ID is incorrect. | The keypad displays the fault code. | Check whether the connection ID sent by the safety master is wrong. Check whether the safety PDO data has been modified. |

• EE17.3: FSoE CRC error Cause:

The CRC value of the FSoE data frame does not match the calculated value.

| Cause | Check Method | Solution |
|---|-------------------------------------|---|
| The CRC value received by the slave is inconsistent with the CRC value calculated by itself. | The keypad displays the fault code. | Check whether the CRC sent by the safety master is wrong. Check whether the safety PDO data has been modified. |

• EE17.4: FSoE watchdog expired Cause:

No data frame was received within the FSoE communication cycle.

| Cause | Check Method | Solution |
|---|-------------------------------------|---|
| The slave failed to receive a data frame within the specified time. | The keypad displays the fault code. | Check whether the safety master sends any data. Check whether the watchdog is working properly. Check whether the connection is disconnected. |

• EE17.5: Invalid FSoE slave address Cause:

The FSoE communication address does not meet the requirements.

| Cause | Check Method | Solution |
|--|-------------------------------------|--|
| In the Connection state, the received slave address is inconsistent. | The keypad displays the fault code. | Check whether the slave address sent from the safety master is correct. Check whether the address of the slave is set correctly. |

• EE17.6: Invalid FSoE safety data Cause:

The FSoE communication parameters are incorrect or the connection fails. In this case, the safety data is invalid.

| Cause | Check Method | Solution |
|---|-------------------------------------|--|
| In the Connection and Parameter state, the safety data received by the slave is invalid. | The keypad displays the fault code. | Check whether the data sent by the safety master is wrong. Check whether the safety data has been modified. |

 EE17.7: Invalid FSoE communication parameter length Cause:

The length and value of the FSoE communication parameters are out of the specified range.

| Cause | Check Method | Solution |
|--|-------------------------------------|---|
| The length of the parameters received by the slave is inconsistent with that set by the slave. | The keypad displays the fault code. | Check whether the length of data sent by the safety master is wrong. Check whether the data has been modified. |

 EE17.8: FSoE invalid communication parameter data Cause:

FSoE communication parameter data is out of range.

| Cause | Check Method | Solution |
|--|-------------------------------------|--|
| The watchdog time settings received by the slave are improper. | The keypad displays the fault code. | Check whether the data sent by the safety master is wrong. Check whether the data has been modified. |

 EE17.9: Invalid FSoE application program parameter length Cause:

The length of the FSoE communication application parameters does not match the preset value.

| Cause | Check Method | Solution |
|--|-------------------------------------|--|
| The length of the application parameters received by the slave is inconsistent with that set by the slave. | The keypad displays the fault code. | Check whether the data sent by the safety master is wrong. Check whether the data has been modified. |

 EE17.A: FSoE invalid application parameter data Cause:

The FSoE communication application program parameter data is out of the range.

| Cause | Check Method | Solution |
|---|-------------------------------------|---|
| The application parameters received by the slave are incorrect. | The keypad displays the fault code. | Check whether the data sent by the safety master is wrong. Check whether the data has been modified. |

9.4 Solutions to Alarms

• E108.5: Parameter-write timeout Cause:

The maximum allowable time has been exceeded when writing safety module parameters to EEPROM.

| Cause | Check Method | Solution |
|--------------|---|---|
| EEPROM error | Power off and restart the drive to check whether parameter modification is activated. | Power off and restart the drive, then try to modify parameters again. Replace the safety module. |

• E108.6: Parameter-read timeout Cause:

The maximum allowable time has been exceeded when reading safety module parameters from EEPROM.

| Cause | Check Method | Solution |
|--------------|---|---|
| EEPROM error | Power off and restart the drive to check whether parameter modification is activated. | Power off and restart the drive, then try to modify parameters again. Replace the safety module. |

• E108.7: Parameter-write error Cause:

When the safety module function is written to EEPROM, it is read again from EEPROM and compared with the value to be written. The comparison does not match.

| Cause | Check Method | Solution |
|--|--------------------------|---|
| An error occurs when writing parameters to EEPROM. | safety module parameters | If the fault remains, it is recommended to replace the safety module. |

 E108.8: Safety module EEPROM read check error Cause:

When the safety module reads data from EEPROM, the check on the data being read fails.

| Cause | Check Method | Solution |
|--|---|--|
| When the safety module reads data from EEPROM, the check on the data being read fails. | Modify a certain parameter, power off and on the servo drive again and check whether the modification is saved. | If the modification is not saved and the fault persists after the servo drive is powered off and on repeatedly, replace the servo drive. |

- E115.0: SSM parameter setting error alarm Cause:
 - 1. The lower limit of SSM is equal to or higher than the upper limit.
 - 2. The SSM hysteresis is equal to or higher than the difference between the upper limit and lower limit.

| Cause | Check Method | Solution |
|---|--|--|
| 1. The lower limit of SSM is equal to or higher than the upper limit. | Local mode: • Check whether the value of H20.71 is higher than or equal to the value of H20.70. • Check whether the value of H20.72 is higher than or equal to the difference between H20.70 and H20.71. | Set SSM parameters properly. The upper limit of SSM is higher than the lower limit. |
| 2. The SSM hysteresis is equal to or higher than the difference between the upper limit and lower limit. | FSoE module: • Check whether the value of 66E4h is higher than or equal to the value of 66E2. • Check whether the value of H20.72 is higher than or equal to the difference between 66E2 and 66E4. | The SSM hysteresis is lower than the difference between the SSM upper limit and lower limit. |

• E116.0: SLS overspeed warning

Cause:

The speed limit is exceeded during SLS speed limit monitoring.

| Cause | Check Method | Solution |
|--|------------------------------|---|
| The speed limit is exceeded during SLS speed limit monitoring. | the correctionaling cheed of | Control the motor speed so that it does not exceed the SLS limit. |

• E116.1: SDI out of tolerance alarm Cause:

The limit is exceeded during SDI direction monitoring.

| Cause | Check Method | Solution |
|---|--|--|
| The limit is exceeded during SDI direction monitoring. An alarm is issued if either the zerospeed window or zero position window exceeds the limit. | Check the fault log to see if the corresponding speed of E116.1 alarm code exceeds the SDI zero-speed window or the motor rotational direction exceeds the zero position window allowed by SDI. | Control the motor speed so that it does not exceed the limit of SDI. |

10 List of Parameters

10.1 Parameter Group H02

| Param. | Communi cation Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|--|---------|------|----------------|-----------------------------|
| H02.02 | 2002-03h | Rotation direction selection | 0: Counterclockwise (CCW) as forward direction 1: Clockwise (CW) as forward direction | 0 | - | At stop | " H02_en.02" on page 221 |
| H02.11 | 2002-0Ch | Motor speed threshold at brake output OFF in rotation state | 20 to 3000 | 30 | RPM | Real time | " H02_en.11" on page 221 |
| H02.12 | 2002-0Dh | Delay from S- ON OFF to brake output OFF in rotation state | 1 to 65535 | 500 | ms | Real time | " H02_en.12" on page 221 |

10.2 Parameter Group H0A

| Param. | Communi cation Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|------------------|-------------|---------|------|----------------|-----------------------------|
| H0A.73 | 200A-4Ah | STO 24 V | 1 to 5 | 5 | ms | Real time | " H0A_en.73" on page 222 |
| | | filter time | | | | | on page 222 |
| H0A.74 | 200A-4Bh | Tolerance filter | 1 to 1000 | 100 | ms | Real time | " H0A_en.74" |
| | | time for two | | | | | on page 222 |
| | | inconsistent | | | | | |
| | | STO channels | | | | | |
| H0A.75 | 200A-4Ch | Servo OFF | 0 to 25 | 20 | ms | Real time | " H0A_en.75" |
| | | delay after STO | | | | | on page 222 |
| | | triggered | | | | | |

10.3 Parameter Group H20

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|------------------------|----------------------------|---------|------|----------------|--------------|
| H20.00 | 2020 to | Functional | 0.00 to 655.35 | 0.00 | - | N/A | " H20_en.00" |
| | 01h | safety | | | | | on page 223 |
| | | module | | | | | |
| | | software | | | | | |
| | | version | | | | | |
| H20.01 | 2020-02h | Safety | 0: Triggered by local mode | 0 | - | At stop | " H20_en.01" |
| | | function | 1: Triggered by FSoE mode | | | | on page 223 |
| | | trigger | | | | | |
| | | mode | | | | | |
| H20.02 | 2020-03h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.02" |
| | | module DI1 function | 1: STO | | | | on page 223 |
| | | selection | 2: SBC 3: SS1 | | | | |
| | | Selection | 4: SS2 | | | | |
| | | | 5: SLS1 | | | | |
| | | | 6: SLS2 | | | | |
| | | | 7: SLS3 | | | | |
| | | | 8: SLS4 | | | | |
| | | | 9: SDIp | | | | |
| | | | 10: SDIn | | | | |
| | | | 11: Ack | | | | |
| H20.03 | 2020-04h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.03" |
| | | module DI2 | 1: STO | | | | on page 224 |
| | | function | 2: SBC | | | | |
| | | selection | 3: SS1 | | | | |
| | | | 4: SS2 | | | | |
| | | | 5: SLS1 | | | | |
| | | | 6: SLS2 | | | | |
| | | | 7: SLS3 | | | | |
| | | | 8: SLS4 | | | | |
| | | | 9: SDIp | | | | |
| | | | 10: SDIn | | | | |
| | | | 11: Ack | | | | |
| H20.04 | 2020-05h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.04" |
| | | module DI3 | 1: STO | | | | on page 224 |
| | | function | 2: SBC | | | | |
| | | selection | 3: SS1 | | | | |
| | | | 4: SS2 | | | | |
| | | | 5: SLS1 | | | | |
| | | | 6: SLS2 | | | | |
| | | | 7: SLS3 | | | | |
| | | | 8: SLS4 | | | | |
| | | | 9: SDIp 10: SDIn | | | | |
| | | | 11: Ack | | | | |
| | | | II. ACK | | | | |

| Param. nication Name Value Range Default | Unit | | |
|--|------|----------------|--------------|
| Address | 0 | Change Mode | Page |
| H20.05 2020-06h Safety 0: Inactive 0 | - | At stop | " H20_en.05" |
| module DI4 1: STO | | | on page 225 |
| function 2: SBC | | | |
| selection 3: SS1 | | | |
| 4: SS2 5: SLS1 | | | |
| 6: SLS2 | | | |
| 7: SLS3 | | | |
| 8: SLS4 | | | |
| 9: SDIp | | | |
| 10: SDIn | | | |
| 11: Ack | | | |
| H20.06 2020-07h Safety 0: Inactive 0 | - | At stop | " H20_en.06" |
| module DI5 1: STO function 2: SBC | | | on page 225 |
| selection 3: SS1 | | | |
| 4: SS2 | | | |
| 5: SLS1 | | | |
| 6: SLS2 | | | |
| 7: SLS3 | | | |
| 8: SLS4 | | | |
| 9: SDIp 10: SDIn | | | |
| 11: Ack | | | |
| H20.08 2020-09h Safety 1 to 500 5 | ms | At stop | " H20_en.08" |
| module DI1 | | | on page 226 |
| noise | | | |
| reduction | | | |
| filter time | | | |
| H20.09 2020-0Ah Safety 1 to 500 5 module DI2 | ms | At stop | " H20_en.09" |
| noise | | | on page 226 |
| reduction | | | |
| filter time | | | |
| H20.10 2020 to Safety 1 to 500 5 | ms | At stop | " H20_en.10" |
| 0Bh module DI3 | | | on page 227 |
| noise | | | |
| reduction | | | |
| | | At ator | "1120 on 11" |
| H20.11 2020-0Ch Safety 1 to 500 5 module DI4 | ms | At stop | " H20_en.11" |
| noise | | | on page 227 |
| reduction | | | |
| filter time | | | |

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|---|---|---------|------|----------------|-----------------------------|
| H20.12 | 2020-0Dh | Safety module DI5 noise reduction filter time | 1 to 500 | 5 | ms | At stop | " H20_en.12" on page 227 |
| H20.14 | 2020-0Fh | Safety module DI1 allowable discrepancy time | 5 to 60000 | 10 | ms | At stop | " H20_en.14" on page 228 |
| H20.15 | 2020 to 10h | Safety module DI2 allowable discrepancy time | 5 to 60000 | 10 | ms | At stop | " H20_en.15" on page 228 |
| H20.16 | 2020 to 11h | Safety module DI3 allowable discrepancy time | 5 to 60000 | 10 | ms | At stop | " H20_en.16" on page 228 |
| H20.17 | 2020 to 12h | Safety module DI4 allowable discrepancy time | 5 to 60000 | 10 | ms | At stop | " H20_en.17" on page 229 |
| H20.18 | 2020-13h | Safety module DI5 allowable discrepancy time | 5 to 60000 | 10 | ms | At stop | " H20_en.18" on page 229 |
| H20.20 | 2020 to 15h | Safety module DO1 function selection | 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active | 0 | - | At stop | " H20_en.20" on page 229 |

| | Commu | | | | | Change | |
|--------|---------------------|---|--|---------|------|---------|-----------------------------|
| Param. | nication Address | Name | Value Range | Default | Unit | Mode | Page |
| H20.21 | 2020-16h | Safety module DO2 function selection | 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active | 0 | - | At stop | " H20_en.21" on page 230 |
| H20.22 | 2020-17h | Safety module DO3 function selection | 14: SS2-r Active 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 13: SS1-r Active | 0 | - | At stop | " H20_en.22" on page 231 |
| H20.23 | 2020-18h | Safety module DO4 function selection | 0: Inactive 1: STO Active 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active | 0 | - | At stop | " H20_en.23" on page 231 |

| H20.24 2020-19h Safety module DO5 1: STO Active | | Commu | | | | | Change | |
|--|----------|---------------------|------------|------------------|---------|------|---------|--------------|
| module DO5 | Param. | nication Address | Name | Value Range | Default | Unit | _ | Page |
| function 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active 14: SS2-r Active 16: STO Active 16: STO Active 17: STO Active 18: STO | H20.24 | 2020-19h | Safety | 0: Inactive | 0 | - | At stop | " H20_en.24" |
| Selection 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active 14: SS2-r Active 16: STO Active 16: STO Active 17: STO Active 18: SS2 Active 18: SLS4 Active 1 | | | module DO5 | 1: STO Active | | | | on page 232 |
| ### 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active 14: SS2-r Active 15: STO Active 16: STO Active 17: STO Active 18: SS2 Active 19: SBC Active 19: STO Active 19: STO Active 19: STO Active 19: STO Active 19: SS2 Active 19: SS2 Active 19: SS3 Active 19: SS4 Active 19: SS5 Ac | | | function | 2: SBC Active | | | | |
| 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active 14: SS2-r Active 16: STO Active 17: STO Active 18: STO Active 19: STO Active | | | selection | 3: SS1 Active | | | | |
| 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active 14: SS2-r Active 15: STO Active 16: STO Active 17: STO Active 18: SS2 Active 19: SSE Active 19: STO Active 19: STO Active 19: STO Active 19: STO Active 19: SSE Active 19: SSE Active 19: SSE Active 19: SSE Active 19: SLS3 Active 19: SLS3 Active 19: SLS3 Active 19: SLS3 Active 19: SLS4 Active | | | | 4: SS2 Active | | | | |
| 7: SLS3 Active 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active 14: SS2-r Active 0 - At stop "H20_en.2 on page 23 o | | | | 5: SLS1 Active | | | | |
| 8: SLS4 Active 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active H20.25 2020-1Ah Safety | | | | 6: SLS2 Active | | | | |
| 9: SDIp Active 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active H20.25 2020-1Ah Safety 0: Inactive 0 - At stop "H20_en.2 on page 23 o | | | | 7: SLS3 Active | | | | |
| 10: SDIn Active 11: SOS Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active H20.25 2020-1Ah Safety module DO6 function selection 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active | | | | 8: SLS4 Active | | | | |
| 11: SOS Active 12: SSM Active 13: SS1-r Active 14: SS2-r Active H20.25 2020-1Ah Safety 0: Inactive 0 - At stop "H20_en.2 on page 23 | | | | 9: SDIp Active | | | | |
| 12: SSM Active 13: SS1-r Active 14: SS2-r Active 14: SS2-r Active 14: SS2-r Active 15: STO Active 16: STO Active 16: STO Active 17: STO Active 17: STO Active 18: SS2 Active 18: SS3 Activ | | | | 10: SDIn Active | | | | |
| 13: SS1-r Active 14: SS2-r Active | | | | 11: SOS Active | | | | |
| 14: SS2-r Active 0 | | | | 12: SSM Active | | | | |
| H20.25 2020-1Ah Safety | | | | 13: SS1-r Active | | | | |
| module DO6 function 2: SBC Active 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active | | | | 14: SS2-r Active | | | | |
| function 2: SBC Active selection 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active | H20.25 | 2020-1Ah | Safety | 0: Inactive | 0 | - | At stop | " H20_en.25" |
| selection 3: SS1 Active 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active | | | module DO6 | 1: STO Active | | | | on page 233 |
| 4: SS2 Active 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active | | | function | 2: SBC Active | | | | |
| 5: SLS1 Active 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active | | | selection | 3: SS1 Active | | | | |
| 6: SLS2 Active 7: SLS3 Active 8: SLS4 Active | | | | 4: SS2 Active | | | | |
| 7: SLS3 Active 8: SLS4 Active | | | | 5: SLS1 Active | | | | |
| 8: SLS4 Active | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| 9: SDIp Active | | | | · · | | | | |
| 10: SDIn Active | | | | | | | | |
| 11: SOS Active | | | | | | | | |
| 13: SS1-r Active | | | | | | | | |
| 14: SS2-r Active | | | | | | | | |
| | H20.28 | 2020-1Dh | | -30000 to +30000 | -30 | ms | At stop | " H20_en.28" |
| | | | | | | | | on page 233 |
| delay | | | delay | | | | | |
| | H20.29 | 2020-1Eh | | · · | 1 | - | At stop | " H20_en.29" |
| | | | stop mode | | | | | on page 233 |
| controller | <u> </u> | | | | | | | |
| | H20.30 | 2020-1Fh | | 60 to 6000 | 1000 | rpm | At stop | " H20_en.30" |
| | | | · · | | | | | on page 234 |
| stop | | | | | | | | |
| reference | | | | | | | | |
| speed | | | speed | | | | | |
| H20.31 2020-20h SS1/SS2 1 to 65535 500 ms At stop "H20_en.3" | H20.31 | 2020-20h | SS1/SS2 | 1 to 65535 | 500 | ms | At stop | " H20_en.31" |
| ramp-to- | | | ramp-to- | | | | | on page 234 |
| stop | | | | | | | | |
| deceleration | | | | | | | | |
| time | | | time | | | | | |
| H20.32 2020-21h SS1monitor 0:SS1-t 0 - At stop "H20_en.3" | H20.32 | 2020-21h | SS1monitor | 0:SS1-t | 0 | - | At stop | " H20_en.32" |
| mode 1:SS1-r on page 23 | L | | mode | 1:SS1-r | | | | on page 234 |

| | Commu | | | | | | |
|--------|---------------------|---|----------------------|---------|------------------|----------------|-----------------------------|
| Param. | nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
| H20.33 | 2020-22h | SS1 trigger- to-STO delay/SS2 trigger-to- | 0 to 65535 | 1000 | ms | At stop | " H20_en.33" on page 235 |
| H20.34 | 2020-23h | STO delay SS1/SS2 zero speed threshold | 1 to 6000 | 10 | rpm | At stop | " H20_en.34" on page 235 |
| H20.35 | 2020-24h | SS1/SS2 zero speed window time | 0 to 65535 | 0 | ms | At stop | " H20_en.35" on page 235 |
| H20.36 | 2020-25h | SS1/SS2 ramp monitor start delay | 5 to 65535 | 10 | ms | At stop | " H20_en.36" on page 236 |
| H20.37 | 2020-26h | SS1/SS2 ramp monitor reference speed | 60 to 6000 | 1000 | rpm | At stop | " H20_en.37" on page 236 |
| H20.38 | 2020-27h | SS1/SS2 ramp deceleration monitoring time | 1 to 65535 | 65535 | ms | At stop | " H20_en.38" on page 236 |
| H20.41 | 2020-2Ah | SS1/SS2 ramp limit trigger-to- alarm time | 0 to 65535 | 5 | ms | At stop | " H20_en.41" on page 237 |
| H20.42 | 2020-2Bh | SS1/SS2 ramp monitor stop speed | 0 to 6000 | 1 | RPM | At stop | " H20_en.42" on page 237 |
| H20.43 | 2020-2Ch | SS2 monitor mode | 0: SS2-t 1: SS2-r | 0 | - | At stop | " H20_en.43" on page 237 |
| H20.44 | 2020-2Dh | SOS speed change threshold | 1 to 6000 | 10 | rpm | At stop | " H20_en.44" on page 238 |
| H20.45 | 2020-2Eh | SOS position change threshold | 1 to 536870912 | 932067 | Encod er unit | At stop | " H20_en.45" on page 238 |

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|--|------------------|---------|------|----------------|-----------------------------|
| H20.47 | 2020-30h | SOS overthres hold-to- alarm time | 0 to 65535 | 5 | ms | At stop | " H20_en.47" on page 238 |
| H20.48 | 2020-31h | SLS switchover delay 1 | 0 to 65535 | 100 | ms | At stop | " H20_en.48" on page 239 |
| H20.49 | 2020-32h | SLS switchover delay 2 | 0 to 65535 | 100 | ms | At stop | " H20_en.49" on page 239 |
| H20.50 | 2020-33h | SLS switchover delay 3 | 0 to 65535 | 100 | ms | At stop | " H20_en.50" on page 239 |
| H20.51 | 2020-34h | SLS switchover delay 4 | 0 to 65535 | 100 | ms | At stop | " H20_en.51" on page 240 |
| H20.52 | 2020–35 h | SLS speed limit threshold 1 | 0 to 6000 | 1000 | rpm | At stop | " H20_en.52" on page 240 |
| H20.53 | 2020-36h | SLS speed limit threshold 2 | 0 to 6000 | 1000 | rpm | At stop | " H20_en.53" on page 240 |
| H20.54 | 2020-37h | SLS speed limit threshold 3 | 0 to 6000 | 1000 | rpm | At stop | " H20_en.54" on page 240 |
| H20.55 | 2020-38h | SLS speed limit threshold 4 | 0 to 6000 | 1000 | rpm | At stop | " H20_en.55" on page 241 |
| H20.56 | 2020-39h | SLS speed limit active filter 1 | 0 to 65535 | 100 | ms | At stop | " H20_en.56" on page 241 |
| H20.57 | 2020-3Ah | SLS speed limit active filter 2 | 0 to 65535 | 100 | ms | At stop | " H20_en.57" on page 241 |
| H20.58 | 2020-3Bh | SLS speed limit active filter 3 | 0 to 65535 | 100 | ms | At stop | " H20_en.58" on page 241 |
| H20.59 | 2020-3Ch | SLS speed limit active filter 4 | 0 to 65535 | 100 | ms | At stop | " H20_en.59" on page 242 |
| H20.60 | 2020-3Dh | SDI fault response mode | 0:STO 1:SS1-t | 0 | - | At stop | " H20_en.60" on page 242 |
| H20.70 | 2020-47h | SSM upper limit threshold | -6000 to +6000 | 200 | rpm | At stop | " H20_en.70" on page 242 |

| Param. | Commu nication Address | Name | Value Range | Default | Unit | Change Mode | Page |
|--------|------------------------------|---------------------------------|------------------|---------|------------------|----------------|-----------------------------|
| H20.71 | 2020 to 48h | SSM lower limit threshold | -6000 to +6000 | -200 | rpm | At stop | " H20_en.71" on page 243 |
| H20.72 | 2020-49h | SSM hysteresis threshold | 0 to 6000 | 10 | rpm | At stop | " H20_en.72" on page 243 |
| H20.74 | 2020-4Bh | SDI zero position window | 1 to 536870912 | 932067 | Encod er unit | At stop | " H20_en.74" on page 243 |
| H20.76 | 2020-4Dh | SDI zero speed window | 0 to 3000 | 10 | rpm | At stop | " H20_en.76" on page 244 |
| H20.77 | 2020-4Eh | SDI delay time | 0 to 65535 | 0 | ms | At stop | " H20_en.77" on page 244 |
| H20.78 | 2020-4Fh | SDI fault response mode | 0:STO 1:SS1-t | 0 | - | At stop | " H20_en.78" on page 244 |

10.4 Parameters in Group 6000

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change mode | Page |
|--------------|------------------------------|---|----------|---------|------|----------------|-------------------------------|
| 6620.01 h | 6620-01h | Low 8 bits of safety control word | 0 to 255 | 0 | - | N/A | " 6620_en.01h" on page 245 |
| 6620.02 h | 6620-02h | High 8 bits of safety control word | 0 to 255 | 0 | = | N/A | " 6620_en.02h" on page 245 |
| 6621.01 h | 6621-01h | Low 8 bits of safety status word | 0 to 255 | 0 | - | N/A | " 6621_en.01h" on page 246 |
| 6621.02 h | 6621-02h | High 8 bits of safety status word | 0 to 255 | 0 | = | N/A | " 6621_en.02h" on page 247 |
| 6630h | 6630h | Restart Ack reset signal | 0 to 1 | 0 | - | Real time | " 6630h" on page 248 |
| 6632h | 6632h | Fault state | 0 to 1 | 0 | - | Real time | " 6632h" on page 249 |
| 6640h | 6640h | STO signal | 0 to 1 | 0 | - | Real time | " 6640h" on page 249 |

| | _ | | | | | | |
|--------------|------------------------------|-------------------------------------|-----------------|---------|-------------------------|----------------|-------------------------------|
| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change mode | Page |
| 6641h | 6641h | STO reset mode | 0 to 1 | 0 | - | Real time | " 6641h" on page 249 |
| 6650.01 h | 6650-01h | SS1 signal | 0 to 1 | 0 | - | Real time | " 6650_en.01h" on page 250 |
| 6651.01 h | 6651-01h | SS1 trigger- to-STO delay | 0 to 65535 | 1000 | ms | Real time | " 6651_en.01h" on page 250 |
| 6653.01 h | 6653-01h | SS1 zero speed threshold | 1 to 6000 | 10 | rpm | Real time | " 6653_en.01h" on page 250 |
| 6654.01 h | 6654-01h | SS1 zero speed window time | 0 to 65535 | 0 | ms | Real time | " 6654_en.01h" on page 251 |
| 6656.01 h | 6656-01h | SS1 deceleration limit | 0 to 4294967295 | 15 | Encod er unit/ s² | Real time | " 6656_en.01h" on page 251 |
| 6657.01 h | 6657-01h | SS1 ramp monitor start delay | 0 to 65535 | 10 | ms | Real time | " 6657_en.01h" on page 251 |
| 6660h | 6660h | SBC signal | 0 to 1 | 0 | - | Real time | " 6660h" on page 252 |
| 6668.01 h | 6668-01h | SOS signal | 0 to 1 | 0 | - | Real time | " 6668_en.01h" on page 252 |
| 666A.01 h | 666A-01h | SOS zero position threshold | 0 to 536870912 | 932067 | Encod er unit | Real time | " 666A_en.01h" on page 252 |
| 666C.01 h | 666C-01h | SOS zero speed threshold | 0 to 6000 | 10 | rpm | Real time | " 666C_en.01h" on page 253 |
| 6670.01 h | 6670-01h | SS2 signal | 0 to 1 | 0 | - | Real time | " 6670_en.01h" on page 253 |
| 6671.01 h | 6671-01h | SS2 trigger- to-STO delay | 0 to 65535 | 10 | ms | Real time | " 6671_en.01h" on page 253 |
| 6672.01 h | 6672-01h | SS2 zero speed window time | 0 to 65535 | 0 | ms | Real time | " 6672_en.01h" on page 254 |
| 6674.01 h | 6674-01h | SS2 deceleration limit | 0 to 4294967295 | 15 | Encod er unit/ s² | Real time | " 6674_en.01h" on page 254 |
| 6675.01 h | 6675-01h | SS2 ramp monitor start delay | 0 to 65535 | 10 | ms | Real time | " 6675_en.01h" on page 254 |

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change mode | Page |
|--------------|------------------------------|---------------------------------------|------------|---------|------|----------------|-------------------------------|
| 6676.01 h | 6676-01h | SS2 reset mode | 0 to 1 | 0 | - | Real time | " 6676_en.01h" on page 255 |
| 6690.01 h | 6690-01h | SLS1 signal | 0 to 1 | 0 | - | Real time | " 6690_en.01h" on page 255 |
| 6690.02 h | 6690-02h | SLS2 signal | 0 to 1 | 0 | - | Real time | " 6690_en.02h" on page 255 |
| 6690.03 h | 6690-03h | SLS3 signal | 0 to 1 | 0 | - | Real time | " 6690_en.03h" on page 256 |
| 6690.04 h | 6690-04h | SLS4 signal | 0 to 1 | 0 | - | Real time | " 6690_en.04h" on page 256 |
| 6691.01 h | 6691-01h | SLS switchover delay 1 | 0 to 65535 | 100 | ms | Real time | " 6691_en.01h" on page 257 |
| 6691.02 h | 6691-02h | SLS switchover delay 2 | 0 to 65535 | 100 | ms | Real time | " 6691_en.02h" on page 257 |
| 6691.03 h | 6691-03h | SLS switchover delay 3 | 0 to 65535 | 100 | ms | Real time | " 6691_en.03h" on page 257 |
| 6691.04 h | 6691-04h | SLS switchover delay 4 | 0 to 65535 | 100 | ms | Real time | " 6691_en.04h" on page 258 |
| 6693.01 h | 6693-01h | SLS speed limit threshold 1 | 0 to 6000 | 1000 | rpm | Real time | " 6693_en.01h" on page 258 |
| 6693.02 h | 6693-02h | SLS speed limit threshold 2 | 0 to 6000 | 1000 | rpm | Real time | " 6693_en.02h" on page 258 |
| 6693.03 h | 6693-03h | SLS speed limit threshold 3 | 0 to 6000 | 1000 | rpm | Real time | " 6693_en.03h" on page 259 |
| 6693.04 h | 6693-04h | SLS speed limit threshold 4 | 0 to 6000 | 1000 | rpm | Real time | " 6693_en.04h" on page 259 |
| 6694.01 h | 6694-01h | SLS speed limit active filter 1 | 0 to 65535 | 10 | ms | Real time | " 6694_en.01h" on page 259 |
| 6694.02 h | 6694-02h | SLS speed limit active filter 2 | 0 to 65535 | 10 | ms | Real time | " 6694_en.02h" on page 259 |
| 6694.03 h | 6694-03h | SLS speed limit active filter 3 | 0 to 65535 | 10 | ms | Real time | " 6694_en.03h" on page 260 |

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change mode | Page |
|--------------|------------------------------|---------------------------------------|----------------|---------|------------------|----------------|-------------------------------|
| 6694.04 h | 6694-04h | SLS speed limit active filter 4 | 0 to 65535 | 10 | ms | Real time | " 6694_en.04h" on page 260 |
| 66D0h | 66D0h | SDIp signal | 0 to 1 | 0 | - | Real time | " 66D0h" on page 260 |
| 66D1h | 66D1h | SDIn signal | 0 to 1 | 0 | - | Real time | " 66D1h" on page 261 |
| 66D3h | 66D3h | SDI zero position window | 0 to 536870912 | 932067 | Encod er unit | Real time | " 66D3h" on page 261 |
| 66D5h | 66D5h | SDI zero speed window | 0 to 3000 | 10 | rpm | Real time | " 66D5h" on page 262 |
| 66E0.01 h | 66E0-01h | SSM state | 0 to 1 | 0 | - | N/A | " 66E0_en.01h" on page 262 |
| 66E2.01 h | 66E2-01h | SSM upper limit threshold | -6000 to +6000 | 200 | rpm | Real time | " 66E2_en.01h" on page 262 |
| 66E4.01 | 66E4-01h | SSM lower | -6000 to +6000 | -200 | rpm | Real time | " 66E4_en.01h" |
| h | | limit threshold | | | | | on page 262 |
| E600.01 h | E600-01h | FSoE slave command | 0 to 255 | 0 | - | N/A | " E600_en.01h" on page 263 |
| E600.02 h | E600-02h | FSoE slave connection ID | 0 to 65535 | 0 | - | N/A | " E600_en.02h" on page 263 |
| E600.03 | E600-03h | FSoE slave CRC value | 0 to 65535 | 0 | - | N/A | " E600_en.03h" on page 263 |
| E601.01 h | E601-01h | FSoE connection status | 0 to 1 | 0 | - | N/A | " E601_en.01h" on page 264 |
| E700.01 h | E700-01h | FSoE master command | 0 to 255 | 0 | - | Real time | " E700_en.01h" on page 264 |
| E700.02 h | E700-02h | FSoE master connection ID | 0 to 65535 | 0 | - | Real time | " E700_en.02h" on page 264 |
| E700.03 | E700-03h | FSoE master CRC value | 0 to 65535 | 0 | - | Real time | " E700_en.03h" on page 264 |
| E901.01 | E901-01h | FSoE version | 0 to 65535 | 0 | - | N/A | " E901_en.01h" on page 265 |
| E901.02 h | E901-02h | FSoE safety address | 0 to 65535 | 0 | - | N/A | " E901_en.02h" on page 265 |
| E901.03 h | E901-03h | FSoE connection ID | 0 to 65535 | 0 | - | N/A | " E901_en.03h" on page 265 |

| Param. | Commu nication Address | Name | Setpoint | Default | Unit | Change mode | Page |
|--------------|------------------------------|---|------------|---------|------|----------------|-------------------------------|
| E901.04 h | E901-04h | Watchdog time | 0 to 65535 | 0 | = | N/A | " E901_en.04h" on page 265 |
| E901.06 h | E901-06h | Connection type | 0 to 65535 | 0 | - | N/A | " E901_en.06h" on page 266 |
| E901.07 h | E901-07h | Communica tion parameter length | 0 to 65535 | 0 | - | N/A | " E901_en.07h" on page 266 |
| E901.08 h | E901-08h | Application layer parameter length | 0 to 65535 | 0 | - | N/A | " E901_en.08h" on page 266 |
| E901.09 h | E901-09h | SRA CRC | 0 to 65535 | 0 | i e | N/A | " E901_en.09h" on page 267 |
| F980.01 h | F980-01h | FSoE address | 0 to 255 | 0 | =1 | N/A | " F980_en.01h" on page 267 |

Description of Parameters 11

11.1 H02 Basic Control Parameters

Rotation direction selection H02.02

2002-03h Hex: Effective Upon the next power-on

mode:

Min.: 0 Unit: Max.: 1 Data Type: UInt16 Default: 0 Change: At stop

Value Range:

0: Counterclockwise (CCW) as forward direction

1: Clockwise (CW) as forward direction

Description

Defines the forward direction of the motor when viewed from the motor shaft side.

H02.11 Motor speed threshold at brake output OFF in rotation state

2002-0Ch Real time Hex: Effective

mode:

rpm

Real-time

20 Min.: Unit: Max.: 3000 Data Type: UInt16 Default: 30 Change:

Value Range: 20 to 3000

Description

Defines the motor speed threshold when brake (BK) output is OFF in the rotation state.

H02.12 Delay from S-ON OFF to brake output OFF in rotation state

Hex: 2002-0Dh Effective Real time

mode:

Min.: 1 Unit: ms Max.: 65535 Data Type: UInt16 500 Default: Change: Real-time

Value Range:

1 to 65535

Description

Defines the delay from the moment the S-ON signal is OFF to the moment the brake (BK) output is OFF in the rotation state.

11.2 HOA Fault and Protection Parameters

H0A.73 STO 24 V disconnection filter time

Hex: 200A-4Ah Effective Real time mode:

Min.: 1 Unit: ms

Max: 5 Data Type: Ulnt16

Max.: 5 Data Type: UInt16
Default: 5 Change: Real-time

Value Range:

1 to 5

Description

Defines the filter time from the moment when STO2 is disconnected from the 24 V power supply to the moment when the STO status is displayed or E150.0 is reported.

H0A.74 Filter time for two inconsistent STO channels

Hex: 200A-4Bh Effective Real time

mode:

Min.:1Unit:msMax.:1000Data Type:UInt16Default:100Change:Real-time

Value Range: 1ms to 1000ms Description

Defines the filter time from the moment when STO2 is input with different voltage to the moment when E150.1 is reported.

H0A.75 Servo OFF delay after STO triggered

Hex: 200A-4Ch Effective Real time mode: Min.: 0 Unit: ms Max.: 25 Data Type: UInt16 Default: 20 Real-time Change:

Value Range: 0ms to 25ms

Description

Defines filter time from the moment when the STO status is displayed or E150.0/ E150.1 is reported to the moment when the servo drive is off.

11.3 H20 Functional Safety Parameters

H20.00 Safety module software version

Hex: 2020-01h Effective

mode: Unit:

Min.: 0.00 Unit: Max.: 655.35 Data Type: UInt16

Default: 0.00 Change: Unchangeable

Value Range: 0.00 to 655.35 Description

Displays the software version of the safety module and consists of two decimal

places.

H20.01 Safety function trigger selection

Hex: 2020-02h Effective Upon the next power-on

mode:

Min.: 0 Unit:

Max.: 1 Data Type: UInt16
Default: 0 Change: At stop

Value Range:
0: Local trigger
1: FSoE trigger
Description

Sets the trigger of the safety function.

H20.02 Safety module DI1 function selection

Hex: 2020-03h Effective Upon the next power-on

mode:

 Min.:
 0
 Unit:

 Max.:
 11
 Data Type:
 Ulnt16

 Default:
 0
 Change:
 At stop

Value Range:

0: Inactive

1: STO

2: SBC

3: SS1

4: SS2

5: SLS1

6: SLS2

7: SLS3

8: SLS4

9: SDIp

10: SDIn

11: Ack

Description

Assigns function to DI1 terminal of the safety module.

H20.03 Safety module DI2 function selection

| Hex: | 2020-04h | Effective | Upon the next power-on |
|----------|----------|------------|------------------------|
| | | mode: | |
| Min.: | 0 | Unit: | - |
| Max.: | 11 | Data Type: | UInt16 |
| Default: | 0 | Change: | At stop |

Value Range:

0: Inactive

1: STO

2: SBC

3: SS1

4: SS2

5: SLS1

6: SLS2

7: SLS3

8: SLS4

9: SDIp

10: SDIn

11: Ack

Description

Assigns function to DI2 terminal of the safety module.

H20.04 Safety module DI3 function selection

| Hex: | 2020-05h | Effective | Upon the next power-on |
|-------|----------|------------|------------------------|
| | | mode: | |
| Min.: | 0 | Unit: | - |
| Max.: | 11 | Data Type: | UInt16 |

Default: 0 Change: At stop

Value Range:

0: Inactive

1: STO

2: SBC

3: SS1

4: SS2

5: SLS1

6: SLS2

7: SLS3

8: SLS4

9: SDIp

10: SDIn

11: Ack

Description

Assigns function to DI3 terminal of the safety module.

H20.05 Safety module DI4 function selection

Hex: 2020-06h Effective Upon the next power-on

mode:

Min.: 0 Unit:

Max.: 11 Data Type: UInt16
Default: 0 Change: At stop

Value Range:

0: Inactive

1: STO

2: SBC

3: SS1

4: SS2

5: SLS1

6: SLS2

7: SLS3

8: SLS4

9: SDIp

10: SDIn

11: Ack

Description

Assigns function to DI4 terminal of the safety module.

H20.06 Safety module DI5 function selection

Hex: 2020-07h Effective Upon the next power-on

mode:

Min.: 0 Unit:

Max.: 11 Data Type: UInt16
Default: 0 Change: At stop

Value Range:

0: Inactive

1: STO

2: SBC

3: SS1

4: SS2

5: SLS1

6: SLS2

7: SLS3

8: SLS4

9: SDIp

10: SDIn

11: Ack

Description

Assigns function to DI5 terminal of the safety module.

H20.08 Safety module DI1 noise reduction filter time

Hex: 2020-09h Effective Upon the next power-on

mode:

Min.:1Unit:msMax.:500Data Type:Ulnt16Default:5Change:At stop

Value Range:

1 to 500

Description

Sets the noise filter time of DI1 of the safety module. Only when the signal change of DI1 is above the filter time continuously, the safety module performs the corresponding safety function.

H20.09 Safety module DI2 noise reduction filter time

Hex: 2020-0Ah Effective Upon the next power-on

mode:

Min.:1Unit:msMax.:500Data Type:UInt16Default:5Change:At stop

Value Range:

1 to 500

Sets the noise filter time of DI2 of the safety module. Only when the signal change of DI2 is continuously maintained above the filter time, the safety module performs the corresponding safety function.

H20.10 Safety module DI3 noise reduction filter time

Hex: 2020-0Bh Effective Upon the next power-on

mode:

Min.:1Unit:msMax.:500Data Type:UInt16Default:5Change:At stop

Value Range:

1 to 500

Description

Sets the noise filter time of DI3 of the safety module. Only when the signal change of DI3 is continuously maintained above the filter time, the safety module performs the corresponding safety function.

H20.11 Safety module DI4 noise reduction filter time

Hex: 2020-0Ch Effective Upon the next power-on

mode:

Min.:1Unit:msMax.:500Data Type:UInt16Default:5Change:At stop

Value Range:

1 to 500

Description

Sets the noise filter time of DI4 of the safety module. Only when the signal change of DI4 is continuously maintained above the filter time, the safety module performs the corresponding safety function.

H20.12 Safety module DI5 noise reduction filter time

Hex: 2020-0Dh Effective Upon the next power-on

mode:

 Min.:
 1
 Unit:
 ms

 Max.:
 500
 Data Type:
 UInt16

 Default:
 5
 Change:
 At stop

Value Range:

1ms to 500ms

Sets the noise filter time of DI5 of the safety module. Only when the signal change of DI5 is continuously maintained above the filter time, the safety module performs the corresponding safety function.

H20.14 Safety module DI1 allowable discrepancy time

Hex: 2020-0Fh Effective Upon the next power-on

mode:

Min.:5Unit:msMax.:60000Data Type:UInt16Default:10Change:At stop

Value Range:

5ms to 60000ms

Description

If the discrepancy at two input signals of DI1 lasts for a period of time exceeding the time set by this parameter, fault E134.1 is reported.

H20.15 Safety module DI2 allowable discrepancy time

Hex: 2020-10h Effective Upon the next power-on

mode:

Min.:5Unit:msMax.:60000Data Type:UInt16Default:10Change:At stop

Value Range:

5ms to 60000ms

Description

If the discrepancy at two input signals of DI2 lasts for a period of time exceeding the time set by this parameter, fault E134.2 is reported.

H20.16 Safety module DI3 allowable discrepancy time

Hex: 2020-11h Effective Upon the next power-on mode:

Min.: 5 Unit: ms

May 60000 Pate Type: Ulat16

Max.: 60000 Data Type: UInt16
Default: 10 Change: At stop

Value Range:

5ms to 60000ms

Description

If the discrepancy at two input signals of DI3 lasts for a period of time exceeding the time set by this parameter, fault E134.3 is reported.

H20.17 Safety module DI4 allowable discrepancy time

Hex: 2020-12h Effective Upon the next power-on

mode:

Min.:5Unit:msMax.:60000Data Type:UInt16Default:10Change:At stop

Value Range:

5ms to 60000ms

Description

If the discrepancy at two input signals of DI4 lasts for a period of time exceeding the time set by this parameter, fault E134.4 is reported.

H20.18 Safety module DI5 allowable discrepancy time

Hex: 2020-13h Effective Upon the next power-on

mode:

Min.:5Unit:msMax.:60000Data Type:Ulnt16Default:10Change:At stop

Value Range:

5ms to 60000ms

Description

If the discrepancy at two input signals of DI5 lasts for a period of time exceeding the time set by this parameter, fault E134.5 is reported.

H20.20 Safety module DO1 function selection

Hex: 2020-15h Effective Upon the next power-on

mode:

 Min.:
 0
 Unit:

 Max.:
 14
 Data Type:
 Ulnt16

 Default:
 0
 Change:
 At stop

Value Range:

- 0: Inactive
- 1: STO Active
- 2: SBC Active
- 3: SS1 Active
- 4: SS2 Active
- 5: SLS1 Active
- 6: SLS2 Active
- 7: SLS3 Active
- 8: SLS4 Active
- 9: SDIp Active
- 10: SDIn Active
- 11: SOS Active
- 12: SSM Active
- 13: SS1-r Active
- 14: SS2-r Active

Assigns function to DO1 terminal of the safety module.

H20.21 Safety module DO2 function selection

Hex: 2020-16h Effective Upon the next power-on mode:

Min.: 0 Unit:
Max.: 14 Data Type: UInt16

Change: At stop

Value Range:

- 0: Inactive
- 1: STO Active
- 2: SBC Active
- 3: SS1 Active
- 4: SS2 Active
- 5: SLS1 Active
- 6: SLS2 Active
- 7: SLS3 Active
- 8: SLS4 Active
- 9: SDIp Active
- 10: SDIn Active
- 11: SOS Active
- 12: SSM Active
- 13: SS1-r Active
- 14: SS2-r Active

Description

Assigns function to DO2 terminal of the safety module.

H20.22 Safety module DO3 function selection

Hex: 2020-17h Effective Upon the next power-on

mode:

Min.: 0 Unit:

Max.: 14 Data Type: UInt16
Default: 0 Change: At stop

Value Range:

0: Inactive

1: STO Active

2: SBC Active

3: SS1 Active

4: SS2 Active

5: SLS1 Active

6: SLS2 Active

7: SLS3 Active

8: SLS4 Active

9: SDIp Active

10: SDIn Active

11: SOS Active

13: SS1-r Active

14: SS2-r Active

Description

Assigns function to DO3 terminal of the safety module.

This DO is a non-safety DO circuit and cannot be configured with SSM function.

H20.23 Safety module DO4 function selection

Hex: 2020-18h Effective Upon the next power-on

mode:

 Min.:
 0
 Unit:

 Max.:
 14
 Data Type:
 Ulnt16

 Default:
 0
 Change:
 At stop

Value Range:

- 0: Inactive
- 1: STO Active
- 2: SBC Active
- 3: SS1 Active
- 4: SS2 Active
- 5: SLS1 Active
- 6: SLS2 Active
- 7: SLS3 Active
- 8: SLS4 Active
- 9: SDIp Active
- 10: SDIn Active
- 11: SOS Active
- 12: SSM Active
- 13: SS1-r Active
- 14: SS2-r Active

Assigns function to DO4 terminal of the safety module.

H20.24 Safety module DO5 function selection

| Hex: | 2020-19h | Effective | Upon the next power-on |
|----------|----------|------------|------------------------|
| | | mode: | |
| Min.: | 0 | Unit: | - |
| Max.: | 14 | Data Type: | UInt16 |
| Default: | 0 | Change: | At stop |

Value Range:

- 0: Inactive
- 1: STO Active
- 2: SBC Active
- 3: SS1 Active
- 4: SS2 Active
- 5: SLS1 Active
- 6: SLS2 Active
- 7: SLS3 Active
- 8: SLS4 Active
- 9: SDIp Active
- 10: SDIn Active
- 11: SOS Active
- 11.0007101170
- 12: SSM Active
- 13: SS1-r Active
- 14: SS2-r Active

Description

Assigns function to DO5 terminal of the safety module.

H20.25 Safety module DO6 function selection

Hex: 2020-1Ah Effective Upon the next power-on

mode:

Min.: 0 Unit:

Max.: 14 Data Type: UInt16
Default: 0 Change: At stop

Value Range:

0: Inactive

1: STO Active

2: SBC Active

3: SS1 Active

4: SS2 Active

5: SLS1 Active

6: SLS2 Active

7: SLS3 Active

8: SLS4 Active

9: SDIp Active

10: SDIn Active

11: SOS Active

13: SS1-r Active

14: SS2-r Active

Description

Assigns function to DO6 terminal of the safety module.

This DO is a non-safety DO circuit and cannot be configured with SSM function.

H20.28 STO trigger-to-SBC active delay time

Hex: 2020-1Dh Effective Upon the next power-on

mode:

 Min.:
 -30000
 Unit:
 ms

 Max.:
 30000
 Data Type:
 Ulnt16

 Default:
 -30
 Change:
 At stop

Value Range:

-30000ms to 30000ms

Description

Sets the delay time from the triggering of the STO function to output of the active SBC state. This parameter can be used to set the sequence of activation of STO and SBC.

H20.29 SS1/SS2 stop mode

Hex: 2020-1Eh Effective Upon the next power-on

mode:

Min.: 0 Unit: -

Max.:1Data Type:UInt16Default:1Change:At stop

Value Range:

0: Stop according to ramp1: Stop by host controller

Description

Sets the stop mode for SS1/SS2.

H20.30 SS1/SS2 ramp-to-stop reference speed

Hex: 2020-1Fh Effective Upon the next power-on

mode:

Min.:60Unit:RPMMax.:6000Data Type:Ulnt16Default:1000Change:At stop

Value Range:

60 rpm to 6000 rpm

Description

Sets the reference speed for deceleration to stop. The deceleration is equal to reference speed/deceleration time.

H20.31 SS1/SS2 ramp-to-stop deceleration time

Hex: 2020-20h Effective Upon the next power-on

mode:

Min.:1Unit:msMax.:65535Data Type:UInt16Default:500Change:At stop

Value Range:

1ms to 65535ms

Description

Sets the time required to decelerate from the reference speed to 0. The deceleration is equal to reference speed/deceleration time.

H20.32 SS1/SS2 monitor mode

Hex: 2020-21h Effective Upon the next power-on

mode:

Min.: 0 Unit:
Max.: 1 Data Type: UInt16

Default: 0 Change: At stop

Value Range:

0:SS1-t 1:SS1-r

Sets the monitoring mode for SS1.

H20.33 SS1 trigger-to-STO delay time/SS2 trigger-to-STO delay time

Hex: 2020-22h Effective Upon the next power-on

mode:

Min.:0Unit:msMax.:65535Data Type:UInt16Default:1000Change:At stop

Value Range:

0ms to 65535ms

Description

After SS1 is triggered, the drive enters the STO state after a period of time exceeding the value set by this parameter has elapsed.

After SS2 is triggered, the drive enters the SOS state after a period of time exceeding the value set by this parameter has elapsed.

H20.34 SS1/SS1 zero speed threshold

Hex: 2020-23h Effective Upon the next power-on

mode:

Min.:1Unit:RPMMax.:6000Data Type:UInt16Default:10Change:At stop

Value Range:

1rpm to 6000rpm

Description

During SS1 deceleration, if the speed falls below the the value set by this parameter for a period of time exceeding the zero speed threshold time, the drive enters the STO state.

During SS2 deceleration, if the speed falls below the the value set by this parameter for a period of time exceeding the zero speed threshold time, the drive enters the SOS state.

H20.35 SS1/SS2 zero speed threshold time

Hex: 2020-24h Effective Upon the next power-on

mode:

 Min.:
 0
 Unit:
 ms

 Max.:
 65535
 Data Type:
 Ulnt16

 Default:
 0
 Change:
 At stop

Value Range:

0ms to 65535ms

During SS1 deceleration, if the speed falls below the zero speed threshold for a period of time exceeding the value set by this parameter, the drive enters the STO state.

During SS2 deceleration, if the speed falls below the zero speed threshold for a period of time exceeding the value set by this parameter, the drive enters the SOS state.

H20.36 SS1/SS2 ramp monitor start delay time

Hex: 2020-25h Effective Upon the next power-on

mode:

 Min.:
 5
 Unit:
 ms

 Max.:
 65535
 Data Type:
 UInt16

 Default:
 10
 Change:
 At stop

Value Range:

5ms to 65535ms

Description

After SS1 is triggered, the speed ramp monitoring starts after a period of time set by this parameter has elapsed, which is only valid in SS1-r mode.

After SS2 is triggered, the speed ramp monitoring starts after a period of time set by this parameter has elapsed, which is only valid in SS2-r mode.

H20.37 SS1/SS2 ramp monitor reference speed

Hex: 2020-26h Effective Upon the next power-on

mode:

 Min.:
 60
 Unit:
 RPM

 Max.:
 6000
 Data Type:
 UInt16

 Default:
 1000
 Change:
 At stop

Value Range:

60 rpm to 6000 rpm

Description

Sets the reference speed for calculating the range of ramp monitoring. Speed ramp monitoring threshold is equal to reference speed/ramp deceleration monitor time.

H20.38 SS1/SS2 ramp deceleration monitor time

Hex: 2020-27h Effective Upon the next power-on

mode:

 Min.:
 1
 Unit:
 ms

 Max.:
 65535
 Data Type:
 UInt16

 Default:
 65535
 Change:
 At stop

Value Range:

1ms to 65535ms

Description

sets the time required to decelerate from the reference speed to 0 during ramp monitoring. Speed ramp monitoring threshold is equal to reference speed/ramp deceleration monitor time.

H20.41 SS1/SS2 ramp limit trigger-to-alarm time

Hex: 2020-2Ah Effective Upon the next power-on

mode:

Min.:0Unit:msMax.:65535Data Type:UInt16Default:5Change:At stop

Value Range:

0ms to 65535ms

Description

During the deceleration process of SS1, if the motor speed exceeds the ramp monitoring limit for a period of time exceeding the value set by this parameter, a fault is reported and the drive enters the STO state.

During the deceleration process of SS2, if the motor speed exceeds the ramp monitoring limit for a period of time exceeding the value set by this parameter, a fault is reported and the drive enters the STO state.

H20.42 SS1/SS2 ramp monitor stop speed

Hex: 2020-2Bh Effective Upon the next power-on

mode:

Min.:0Unit:RPMMax.:6000Data Type:UInt16Default:1Change:At stop

Value Range:

Orpm to 6000rpm

Description

During the deceleration process of SS1, when the motor speed falls below the value set by this parameter, the ramp monitoring is stopped.

During the deceleration process of SS2, when the motor speed falls below the value set by this parameter, the ramp monitoring is stopped.

H20.43 SS2 monitor mode

Hex: 2020-2Ch Effective Upon the next power-on

mode:

Min.: 0 Unit: -

Value Range:

0:SS2-t 1:SS2-r **Description**

Sets the monitoring mode for SS2.

H20.44 SOS speed change threshold

Hex: 2020-2Dh Effective Upon the next power-on

mode:

Min.:1Unit:RPMMax.:6000Data Type:UInt16Default:10Change:At stop

Value Range: 1rpm to 6000rpm

Description

Sets the maximum allowable difference between motor speed and 0 rpm in SOS state.

H20.45 SOS position change threshold

Hex: 2020-2Eh Effective Upon the next power-on

mode:

 Min.:
 1
 Unit:
 Encoder unit

 Max.:
 536870912
 Data Type:
 Ulnt16

 Default:
 932067
 Change:
 At stop

Value Range: 1 to 536870912

Description

Sets the maximum allowable variation of position feedback in SOS state.

H20.47 SOS overthreshold-to-alarm time

Hex: 2020-30h Effective Upon the next power-on

mode:

Min.:0Unit:msMax.:65535Data Type:UInt16Default:5Change:At stop

Value Range: 0ms to 65535ms

In the SOS state, if the speed feedback or position feedback exceeds the threshold for a period of time exceeding the value set by this parameter, a fault will be reported.

H20.48 SLS1 switchover delay

Hex: 2020-31h Effective Upon the next power-on

mode:

Min.:0Unit:msMax.:65535Data Type:UInt16Default:100Change:At stop

Value Range:

0ms to 65535ms

Description

Sets the delay time from activation of SLS1 request command to activation of SLS1 monitoring.

H20.49 SLS2 switchover delay

Hex: 2020-32h Effective Upon the next power-on

mode:

Min.:0Unit:msMax.:65535Data Type:Ulnt16Default:100Change:At stop

Value Range: 0ms to 65535ms

Description

Sets the delay time from activation of SLS2 request command to activation of SLS2 monitoring.

H20.50 SLS3 switchover delay

Hex: 2020-33h Effective Upon the next power-on

mode:

Min.:0Unit:msMax.:65535Data Type:UInt16Default:100Change:At stop

Value Range:

0ms to 65535ms

Description

Sets the delay time from activation of SLS3 request command to activation of SLS3 monitoring.

H20.51 SLS4 switchover delay

Hex: 2020-34h Effective Upon the next power-on

mode:

Min.:0Unit:msMax.:65535Data Type:UInt16Default:100Change:At stop

Value Range: 0ms to 65535ms

Description

Sets the delay time from activation of SLS4 request command to activation of SLS4 monitoring.

H20.52 SLS1 threshold

Hex: 2020-35h Effective Upon the next power-on

mode:

Min.:0Unit:RPMMax.:6000Data Type:Ulnt16Default:1000Change:At stop

Value Range: 0rpm to 6000rpm

Description

Sets the speed threshold for SLS1 monitoring.

H20.53 SLS2 threshold

Hex: 2020-36h Effective Upon the next power-on

mode:

 Min.:
 0
 Unit:
 RPM

 Max.:
 6000
 Data Type:
 Ulnt16

 Default:
 1000
 Change:
 At stop

Value Range: 0rpm to 6000rpm

Description

Sets the speed threshold for SLS2 monitoring.

H20.54 SLS3 threshold

Hex: 2020-37h Effective Upon the next power-on

mode:

 Min.:
 0
 Unit:
 RPM

 Max.:
 6000
 Data Type:
 Ulnt16

 Default:
 1000
 Change:
 At stop

Value Range:

0rpm to 6000rpm

Description

Sets the speed threshold for SLS3 monitoring.

H20.55 SLS4 threshold

Hex: 2020-38h Effective Upon the next power-on

mode:

Min.:0Unit:RPMMax.:6000Data Type:UInt16Default:1000Change:At stop

Value Range: Orpm to 6000rpm

Description

Sets the speed threshold for SLS4 monitoring.

H20.56 SLS1 filter time

Hex: 2020-39h Effective Upon the next power-on

mode:

Min.:0Unit:msMax.:65535Data Type:UInt16Default:100Change:At stop

Value Range: 0ms to 65535ms

Description

Sets the filtering time for determining that the motor speed is within the SLS1 limit.

H20.57 SLS2 filter time

Hex: 2020-3Ah Effective Upon the next power-on

mode:

 Min.:
 0
 Unit:
 ms

 Max.:
 65535
 Data Type:
 Ulnt16

 Default:
 100
 Change:
 At stop

Value Range:

0ms to 65535ms

Description

Sets the filtering time for determining that the motor speed is within the SLS2 limit.

H20.58 SLS3 filter time

Hex: 2020-3Bh Effective Upon the next power-on

mode:

Min.:0Unit:msMax.:65535Data Type:UInt16Default:100Change:At stop

Value Range: 0ms to 65535ms

Description

Sets the filtering time for determining that the motor speed is within the SLS3 limit.

H20.59 SLS4 filter time

Hex: 2020-3Ch Effective Upon the next power-on

mode:

 Min.:
 0
 Unit:
 ms

 Max.:
 65535
 Data Type:
 UInt16

 Default:
 100
 Change:
 At stop

Value Range: 0ms to 65535ms

Description

Sets the filtering time for determining that the motor speed is within the SLS4 limit.

H20.60 SLS fault response mode

Hex: 2020-3Dh Effective Upon the next power-on

mode:

Min.: 0 Unit:

Max.: 1 Data Type: UInt16
Default: 0 Change: At stop

Value Range:

0:STO 1:SS1-t

Description

Sets the mode for stopping the motor when its speed exceeds the speed limit after the SLS monitoring takes effect.

H20.70 SSM upper limit

Hex: 2020-47h Effective Upon the next power-on

mode:

 Min.:
 -6000
 Unit:
 RPM

 Max.:
 6000
 Data Type:
 Int16

 Default:
 200
 Change:
 At stop

Value Range:

-6000 rpm to +6000 rpm

Upper limit for SSM monitoring

H20.71 SSM lower limit

Hex: 2020-48h Effective Upon the next power-on

mode:

 Min.:
 -6000
 Unit:
 RPM

 Max.:
 6000
 Data Type:
 Int16

 Default:
 -200
 Change:
 At stop

Value Range:

-6000 rpm to +6000 rpm

Description

Lower limit for SSM monitoring

H20.72 SSM hysteresis threshold

Hex: 2020-49h Effective Upon the next power-on

mode:

Min.:0Unit:RPMMax.:6000Data Type:UInt16Default:10Change:At stop

Value Range: 0rpm to 6000rpm

Description

Sets the hysteresis threshold of SSM monitoring to avoid the SSM output jumping too frequently when the speed fluctuates near the upper or lower threshold.

H20.74 SDI zero position threshold

Hex: 2020-4Bh Effective Upon the next power-on

mode:

Min.:1Unit:Encoder unitMax.:536870912Data Type:Ulnt32Default:932067Change:At stop

Value Range:

1 to 536870912

Description

Sets the position threshold for stopping the monitoring.

(Position window for stop position)

H20.76 SDI zero speed threshold

Hex: 2020-4Dh Effective Upon the next power-on

mode:

Min.:0Unit:RPMMax.:3000Data Type:Ulnt16Default:10Change:At stop

Value Range:

0rpm to 3000rpm

Description

Sets the speed threshold for stopping the monitoring.

(Velocity window for n=0)

H20.77 SDI delay time

Hex: 2020-4Eh Effective Upon the next power-on

mode:

Min.:0Unit:msMax.:65535Data Type:Ulnt16Default:0Change:At stop

Value Range:

0ms to 65535ms

Description

Sets the delay time from activation of SDI command to activation of SDI monitoring.

H20.78 SDI fault response mode

Hex: 2020-4Fh Effective Upon the next power-on

mode:

Min.: 0 Unit: -

Max.: 1 Data Type: UInt16
Default: 0 Change: At stop

Value Range:

0:STO 1:SS1-t

Description

Sets the mode for stopping the motor when it runs in the forbidden direction after the SDI monitoring takes effect.

11.4 6000h Object Dictionary

6620.01h Safety control word low 8 bits

Hex: 6620-01h Effective

mode:

Min.: 0 Unit:

Max.: 255 Data Type: UInt8

Default: 0 Change: Unchangeable

Value Range:

0 to 255

Description

Reflects the current state of the RPDO control command issued by the host controller.

| Variable PDO | Description |
|--------------|--|
| bit0 | Displays STO command state 0: STO trigger command present 1: No STO trigger command |
| bit1 | Displays SS1 command state 0: SS1 trigger command present 1: No SS1 trigger command |
| bit2 | Displays SS2 command state 0: SS2 trigger command present 1: No SS2 trigger command |
| bit3 | Displays SOS command state 0: SOS trigger command present 1: No SOS trigger command |
| bit5 | Displays SDIp command state 0: SDIp trigger command present 1: No SDIp trigger command |
| bit6 | Displays SDIn command state 0: SDIn trigger command present 1: No SDIn trigger command |
| bit7 | Displays Ack fault state 0: No Ack command 1: Ack command present |

Safety control word high 8 bits 6620.02h

Hex: 6620-02h Effective mode: Min.: 0 Unit:

255 Data Type: UInt8 Max.:

Default: Change: Unchangeable

Value Range:

0 to 255

Description

Reflects the current state of the RPDO control command issued by the host controller.

| Variable PDO | Description |
|--------------|--|
| bit0 | Displays reset command state 0: No reset command 1: Reset command present |
| bit1 | Displays SBC command state 0: SBC trigger command present 1: No SBC trigger command |
| bit2 | Displays SLS1 command state 0: SLS1 trigger command present 1: No SLS1 trigger command |
| bit3 | Displays SLS2 command state 0: SLS2 trigger command present 1: No SLS2 trigger command |
| bit4 | Displays SLS3 command state 0: SLS3 trigger command present 1: No SLS3 trigger command |
| bit5 | Displays SLS4 command state 0: SLS4 trigger command present 1: No SLS4 trigger command |

6621.01h Safety status word low 8 bits

Hex: 6621-01h Effective - mode:

mode:

Min.: 0 Unit: Max.: 255 Data Type: U

Max.: 255 Data Type: UInt8
Default: 0 Change: Unchangeable

Value Range:

0 to 255

Reflects the current TPDO state uploaded by the safety module.

| Variable PDO | Description |
|--------------|--|
| bit0 | Displays STO state 0: Non-STO state 1: STO state |
| bit1 | Displays SSM state 0: The speed is within SSM limit range 1: The speed is out of SSM limit range |
| bit3 | Displays SOS state 0: Non-SOS state 1: SOS state |
| bit5 | Displays SDIp state 0: Motor is not in forward motion 1: Motor is in forward motion |
| bit6 | Displays SDIn state 0: Motor is not in reverse motion 1: Motor is in reverse motion |
| bit7 | Displays safety function fault state 0: Normal 1: Faulty |

6621.02h Safety status word high 8 bits

Hex: 6621-02h Effective -

mode:

Min.: 0 Unit:

Max.: 255 Data Type: UInt8

Default: 0 Change: Unchangeable

Value Range:

0 to 255

Reflects the current TPDO state uploaded by the safety module.

| Variable PDO | Description |
|--------------|---|
| bit0 | Displays reset state 0: Non-reset state 1: Reset state |
| bit1 | Displays SBC state 0: Non-SBC state 1: SBC state |
| bit2 | Displays SLS1 state 0: Non-SLS1 state 1: SLS1 state |
| bit3 | Displays SLS2 state 0: Non-SLS2 state 1: SLS2 state |
| bit4 | Displays SLS3 state 0: Non-SLS3 state 1: SLS3 state |
| bit5 | Displays SLS4 state 0: Non-SLS4 state 1: SLS4 state |
| bit7 | Displays FSoE connection status 0: Connection is normal 1: Connection is abnormal |

6630h Restart Ack signal

| Hex: | 6630h | Effective | Real time |
|----------|-------|------------|-----------|
| | | mode: | |
| Min.: | 0 | Unit: | - |
| Max.: | 1 | Data Type: | Boolean |
| Default: | 0 | Change: | Real-time |

Value Range:

0 to 1

Description

| Variable PDO | Description |
|--------------|---|
| RPDO | Executes reset command 0: Do not trigger reset 1: Trigger reset |
| TPDO | Displays reset state 0: Non-reset state 1: Reset state |

6632h Fault state

Hex: 6632h Effective Real time

mode:

Min.: 0 Unit: -

Max.: 1 Data Type: Boolean
Default: 0 Change: Real-time

Value Range:

0 to 1

Description

| Variable PDO | Description |
|--------------|--|
| TPDO | Displays fault state 0: Non-faulty 1: Faulty |

6640h STO signal

Hex: 6640h Effective Real time

mode:

Min.: 0 Unit: -

Max.:1Data Type:BooleanDefault:0Change:Real-time

Value Range:

0 to 1

Description

| Variable PDO | Description |
|--------------|---|
| RPDO | Executes STO command 0: Trigger STO 1: Do not trigger STO |
| TPDO | Displays STO state 0: Non-STO state 1: STO state |

6641h STO reset mode selection

Hex: 6641h Effective Real time

mode:

Min.: 0 Unit: Max.: 1 Data Type: Boolean

Default: 0 Change: Real-time

Value Range:

0 to 1

Description

Select the STO reset mode.

| Var | iable SDO | Description | |
|-----|-----------|--|--|
| | SDO | STO reset mode selection 0: Restart Ack signal is not required 1: Restart Ack signal is required | |

6650.01h SS1 signal

Hex: 6650-01h Effective Real time

mode:

Min.: 0 Unit: Max.: 1 Data Type: Boolean

Default: 0 Data Type: Boolean Change: Real-time

Value Range:

0 to 1

Description

| Variable PDO | Description |
|--------------|---|
| RPDO | Executes SS1 command 0: Trigger SS1 1: Do not trigger SS1 |
| TPDO | Displays SS1 state 0: Non-SS1 state 1: SS1 state |

6651.01h SS1 trigger-to-STO delay time

Hex: 6651-01h Effective At stop

mode:

Min.:0Unit:msMax.:65535Data Type:UInt16Default:1000Change:Real-time

Value Range:

0ms to 65535ms

Description

After SS1 is triggered, OD Index STO state after a period of time exceeding the value set by this parameter has elapsed.

6653.01h SS1 zero speed threshold

Hex: 6653-01h Effective At stop

mode:

Min.: 1 Unit: RPM
Max.: 6000 Data Type: UInt32

Default: 10 Change: Real-time

Value Range:

1rpm to 6000rpm

Description

During SS1 deceleration, if the speed falls below the the value set by this parameter for a period of time exceeding the zero speed threshold time, the drive enters the STO state.

6654.01h SS1 zero speed threshold time

| Hex: | 6654-01h | Effective | At stop |
|------|----------|-----------|---------|
| | | 1 | |

mode:

Min.: 0 Unit: ms

Max.: 65535 Data Type: UInt16

Default: 0 Change: Real-time

Value Range:

0ms to 65535ms

Description

During SS1 deceleration, if the speed falls below the zero speed threshold for a period of time exceeding the value set by this parameter, the drive enters the STO state.

6656.01h SS1 deceleration limit

Hex: 6656-01h Effective At stop

mode:

Min.: 0 Unit: Encoder unit/s²

Max.: 4294967295 Data Type: UInt32
Default: 15 Change: Real-time

Value Range:

0 encoder unit/s²–4294967295 encoder unit/s²

Description

Sets the minimum deceleration threshold for SS1 when ramp monitoring is performed.

6657.01h SS1 ramp monitor start delay time

Hex: 6657-01h Effective At stop

mode:

Min.:0Unit:msMax.:65535Data Type:Ulnt16Default:10Change:Real-time

Value Range:

0ms to 65535ms

Description

After SS1 is triggered, the speed ramp monitoring starts after a period of time set by this parameter has elapsed, which is only valid in SS1-r mode.

6660h SBC signal

Hex: 6660h Effective Real time

mode:

Min.: 0 Unit:

Max.: 1 Data Type: Boolean Default: 0 Change: Real-time

Value Range:

0 to 1

Description

| Variable PDO | Description |
|--------------|--|
| RPDO | Executes SBC command 0: SBC active 1: SBC deselected |
| TPDO | Displays SBC state 0: Normal state 1: SBC state |

6668.01h SOS signal

Hex: 6668-01h Effective Real time

mode:

Min.: 0 Unit: -

Max.: 1 Data Type: Boolean
Default: 0 Change: Real-time

Value Range:

0 to 1

Description

| Variable PDO | Description |
|--------------|--|
| TPDO | Displays SOS state 0: Non-SOS state 1: SOS state |

666A.01h SOS zero position threshold

Hex: 666A-01h Effective At stop

mode:

Min.: 0 Unit: Encoder unit Max.: 536870912 Data Type: Ulnt32

Default: 932067 Change: Real-time

Value Range: 0 to 536870912

Description

Sets the maximum allowable variation of position feedback in SOS state.

666C.01h SOS zero speed threshold

Hex: 666C-01h Effective At stop

mode:

 Min.:
 0
 Unit:
 rpm

 Max.:
 6000
 Data Type:
 Ulnt32

 Default:
 10
 Change:
 Real time

Value Range: 0 to 6000 Description

Sets the maximum allowable difference between motor speed and 0 rpm in SOS state.

6670.01h SS2 signal

Hex: 6670-01h Effective Real time

mode:

Min.: 0 Unit:

Max.: 1 Data Type: Boolean Default: 0 Change: Real-time

Value Range:

0 to 1

Description

| Variable PDO | Description |
|--------------|---|
| RPDO | Executes SS2 command 0: Trigger SS2 1: Do not trigger SS2 |
| TPDO | Displays SS2 state 0: Non-SS2 state 1: SS2 state |

6671.01h SS2 trigger-to-STO delay time

Hex: 6671-01h Effective At stop

mode:

Min.: 0 Unit: ms

Max.: 65535 Data Type: UInt16

Default: 10 Change: Real-time

Value Range:

0ms to 65535ms

Description

After SS2 is triggered, the drive enters the SOS state after a period of time exceeding the value set by this parameter has elapsed.

6672.01h SS2 zero speed threshold time

Hex: 6672-01h Effective At stop

mode:

 Min.:
 0
 Unit:
 ms

 Max.:
 65535
 Data Type:
 UInt16

 Default:
 0
 Change:
 Real-time

Value Range:

0ms to 65535ms

Description

During SS2 deceleration, if the speed falls below the zero speed threshold for a period of time exceeding the value set by this parameter, the drive enters the SOS state.

6674.01h SS2 deceleration limit

Hex: 6674-01h Effective At stop

mode:

Min.: 0 Unit: Encoder unit/s²

Max.: 4294967295 Data Type: UInt32
Default: 15 Change: Real-time

Value Range:

0 encoder unit/s²–4294967295 encoder unit/s²

Description

Sets the minimum deceleration threshold for SS2 when ramp monitoring is performed.

6675.01h SS2 ramp monitor start delay time

Hex: 6675-01h Effective At stop

mode:

 Min.:
 0
 Unit:
 ms

 Max.:
 65535
 Data Type:
 UInt16

 Default:
 10
 Change:
 Real-time

Value Range:

0ms to 65535ms

Description

After SS2 is triggered, the speed ramp monitoring starts after a period of time set by this parameter has elapsed, which is only valid in SS2-r mode.

6676.01h SS2 reset mode selection

Hex: 6676-01h Effective At stop

mode:

Min.: 0 Unit: -

Max.: 1 Data Type: Boolean Default: 0 Change: Real-time

Value Range:

0 to 1

Description

| Variable SDO | Description |
|--------------|---|
| | SS2 reset mode 0: Restart Ack signal is not required upon SS2 reset 1: Restart Ack signal is required upon SS2 reset upon SS2 reset |

6690.01h SLS1 signal

Hex: 6690-01h Effective Real time

mode:

Min.: 0 Unit: -

Max.:1Data Type:BooleanDefault:0Change:Real-time

Value Range:

0 to 1

Description

| Variable PDO | Description |
|--------------|--|
| RPDO | Executes SLS1 command 0: SLS1 active 1: SLS1 deselected |
| TPDO | Displays SLS1 state 0: Normal state 1: SLS1 monitoring state |

6690.02h SLS2 signal

Hex: 6690-02h Effective Real time

mode:

Min.: 0 Unit:

Max.: 1 Data Type: Boolean Default: 0 Change: Real-time

Value Range:

0 to 1

Description

Displays SLS function state and executes SLS command.

| Variable PDO | Description |
|--------------|--|
| RPDO | Executes SLS2 command 0: SLS2 active 1: SLS2 deselected |
| TPDO | Displays SLS2 state 0: Normal state 1: SLS2 monitoring state |

6690.03h SLS3 signal

Hex: 6690-03h Effective Real time

mode:

Min.: 0 Unit:

Max.: 1 Data Type: Boolean Default: 0 Change: Real-time

Value Range:

0 to 1

Description

Displays SLS function state and executes SLS command.

| Variable PDO | Description |
|--------------|--|
| RPDO | Executes SLS3 command 0: SLS3 active 1: SLS3 deselected |
| TPDO | Displays SLS3 state 0: Normal state 1: SLS3 monitoring state |

6690.04h SLS4 signal

Hex: 6690-04h Effective Real time

mode:

Min.: 0 Unit:

Max.: 1 Data Type: Boolean Default: 0 Change: Real-time

Value Range:

0 to 1

Description

Displays SLS function state and executes SLS command.

| Variable PDO | Description |
|--------------|--|
| RPDO | Executes SLS4 command 0: SLS4 active 1: SLS4 deselected |
| TPDO | Displays SLS4 state 0: Normal state 1: SLS4 monitoring state |

6691.01h SLS1 switchover delay

Hex: 6691-01h Effective At stop

mode:

Min.: 0 Unit: ms Max.: 65535 Data Type: UInt16 100 Default: Real-time Change:

Value Range:

0ms to 65535ms

Description

Sets the delay time from activation of SLS1 request command to activation of SLS1 monitoring.

(Time delay to initiate SLS1 limits)

6691-02h

6691.02h SLS2 switchover delay

Hex:

Effective At stop mode: Min.: 0 ms Unit: Max.: 65535 Data Type: UInt16 Default: 100 Change: Real-time

Value Range:

0ms to 65535ms

Description

Sets the delay time from activation of SLS2 request command to activation of SLS2 monitoring.

6691.03h SLS3 switchover delay

Hex: 6691-03h Effective At stop mode: Min.: 0 Unit: ms Max.: 65535 Data Type: UInt16 Default: 100 Change: Real-time

Value Range:

0ms to 65535ms

Description

Sets the delay time from activation of SLS3 request command to activation of SLS3 monitoring.

6691.04h SLS4 switchover delay

Hex: 6691-04h Effective At stop

mode:

 Min.:
 0
 Unit:
 ms

 Max.:
 65535
 Data Type:
 UInt16

 Default:
 100
 Change:
 Real-time

Value Range:

0ms to 65535ms

Description

Sets the delay time from activation of SLS4 request command to activation of SLS4 monitoring.

6693.01h SLS1 threshold

Hex: 6693-01h Effective At stop

mode:

 Min.:
 0
 Unit:
 RPM

 Max.:
 6000
 Data Type:
 UInt32

 Default:
 1000
 Change:
 Real-time

Value Range: 0rpm to 6000rpm

Description

Sets the threshold for SLS1.

6693.02h SLS2 threshold

Hex: 6693-02h Effective At stop

mode:

Min.:0Unit:RPMMax.:6000Data Type:UInt32Default:1000Change:Real-time

Value Range:

0rpm to 6000rpm

Description

Sets the threshold for SLS2.

6693.03h SLS3 threshold

Hex: 6693-03h Effective At stop

mode:

 Min.:
 0
 Unit:
 RPM

 Max.:
 6000
 Data Type:
 UInt32

 Default:
 1000
 Change:
 Real-time

Value Range: 0rpm to 6000rpm Description

Sets the threshold for SLS3.

6693.04h SLS4 threshold

Hex: 6693-04h Effective At stop

mode:

Min.:0Unit:RPMMax.:6000Data Type:Ulnt32Default:1000Change:Real-time

Value Range: 0rpm to 6000rpm Description

Sets the threshold for SLS4.

6694.01h SLS1 filter time

Hex: 6694-01h Effective At stop

mode:

Min.:0Unit:msMax.:65535Data Type:UInt16Default:10Change:Real-time

Value Range: 0ms to 65535ms Description

Sets the filter time within SLS1 window (Time for speed within SLS1 window)

6694.02h SLS2 filter time

Hex: 6694-02h Effective At stop

mode:
Min.: 0 Unit:

Min.:0Unit:msMax.:65535Data Type:UInt16Default:10Change:Real-time

Value Range: 0ms to 65535ms

Description

Sets the filter time within SLS2 window

6694.03h SLS3 filter time

Hex: 6694-03h Effective At stop

mode:

 Min.:
 0
 Unit:
 ms

 Max.:
 65535
 Data Type:
 UInt16

 Default:
 10
 Change:
 Real-time

Value Range: 0ms to 65535ms Description

Sets the filter time within SLS3 window

6694.04h SLS4 filter time

Hex: 6694-04h Effective At stop

mode:

Min.: 0 Unit: ms

Max.: 65535 Data Type: UInt16

Default: 10 Change: Real-time

Value Range: 0ms to 65535ms Description

Sets the filter time within SLS4 window

66D0h SDIp signal

Hex: 66D0h Effective Real time

mode:

Min.: 0 Unit: -

Max.: 1 Data Type: Boolean Default: 0 Change: Real-time

Value Range:

0 to 1

Description

Displays the forward rotation state of the motor and issues the SDI forward command.

| Variable PDO | Description |
|--------------|--|
| RPDO | Executes SDIp monitoring function. 0: Forward rotation prohibited 1: Forward rotation allowed |
| TPDO | Indicates forward rotation state of the motor. 0: Motor is not in forward rotation 1: Motor is in forward rotation |

66D1h SDIn signal

Hex: 66D1h Effective Real time

mode:

0 Unit:

Max.: 1 Data Type: Boolean Default: 0 Change: Real-time

Value Range:

0 to 1

Min.:

Description

Displays the reverse rotation state of the motor and issues the SDI reverse command

| Variable PDO | Description |
|--------------|--|
| RPDO | Executes SDIn monitoring function. 0: Reverse direction is not allowed 1: Reverse direction is allowed |
| TPDO | Displays SDIn state 0: Motor is not running reversely 1: Motor is running reversely |

66D3h SDI zero position threshold

Hex: 66D3h Effective At stop

mode:

Min.: 0 Unit: Encoder unit
Max.: 536870912 Data Type: UInt32

Default: 932067 Change: Real-time

Value Range:

0 to 536870912

Description

Sets the position window for stopping the monitoring.

66D5h SDI zero speed threshold

Hex: 66D5h Effective At stop

mode:

Min.:0Unit:RPMMax.:3000Data Type:UInt32Default:10Change:Real-time

Value Range: 0rpm to 3000rpm Description

Zero speed threshold for SDI monitoring

66E0.01h SSM state

Hex: 66E0-01h Effective

mode:

Min.: 0 Unit: -

Max.: 1 Data Type: Boolean
Default: 0 Change: Unchangeable

Value Range:

0 to 1

Description

SSM can be implemented as a bit in the safety state.

| Variable PDO | Description |
|--------------|--|
| - | Displays SSM state 0: Motor speed out of SSM limit 1: Motor speed within SSM limit |

66E2.01h SSM upper limit

Hex: 66E2-01h Effective At stop

mode:

Min.: -6000 Unit: RPM
Max.: 6000 Data Type: Int32
Default: 200 Change: Real-time

Value Range:

-6000 rpm to +6000 rpm

Description

Upper limit for SSM monitoring

66E4.01h SSM lower limit

Hex: 66E4-01h Effective At stop

mode:

Min.: -6000 Unit: RPM

Max.: 6000 Data Type: Int32
Default: -200 Change: Real-time

Value Range:

-6000 rpm to +6000 rpm

Description

Lower limit for SSM monitoring

E600.01h FSoE slave command

Hex: E600-01h Effective

mode: Unit:

Min.: 0 Unit: Max.: 255 Data Type: UInt8

Default: 0 Change: Unchangeable

Value Range: 0 to 255 Description

FSoE slave command

E600.02h FSoE slave connection ID

Hex: E600-02h Effective -

mode:

Min.: 0 Unit: Max.: 65535 Data Type: UInt16

Default: 0 Change: Unchangeable

Value Range: 0 to 65535 Description

FSoE slave connection ID

E600.03h FSoE slave CRC value

Hex: E600-03h Effective -

mode:

Min.: 0 Unit:
Max.: 65535 Data Type: UInt16

Default: 0 Change: Unchangeable

Value Range: 0 to 65535 Description

FSoE slave CRC value

E601.01h FSoE connection status

Hex: E601-01h Effective

mode:

Min.: 0 Unit: Max.: 1 Data Type: Boolean

Default: 0 Change: Unchangeable

Value Range:

0 to 1

Description

| Variable PDO | Description |
|--------------|---------------------------------|
| | Displays FSoE connection status |
| TPDO | 0: Connection is normal. |
| | 1: Connection is abnormal. |

E700.01h FSoE master command

Hex: E700-01h Effective Real time

mode:

Min.: 0 Unit: Max.: 255 Data Type: UInt8
Default: 0 Change: Real-time

Value Range:

0 to 255 **Description**

FSoE master command

E700.02h FSoE master connection ID

Hex: E700-02h Effective Real time

mode:

Min.: 0 Unit: Max.: 65535 Data Type: UInt16
Default: 0 Change: Real-time

Value Range: 0 to 65535 Description

FSoE master connection ID

E700.03h FSoE master CRC value

Hex: E700-03h Effective Real time

mode:

Min.: 0 Unit: Max.: 65535 Data Type: UInt16

Default: 0 Change: Real-time

Value Range: 0 to 65535 Description

FSoE master CRC value

E901.01h FSoE version

Hex: E901-01h Effective -

mode:

Min.: 0 Unit: Max.: 65535 Data Type: UInt16

Default: 0 Change: Unchangeable

Value Range: 0 to 65535 Description

Supported FSoE version

E901.02h FSoE address

Hex: E901-02h Effective

mode:

Min.: 0 Unit: -

Max.: 65535 Data Type: UInt16

Default: 0 Change: Unchangeable

Value Range: 0 to 65535 **Description** FSoE address

E901.03h PSoE connection ID

Hex: E901-03h Effective

mode:

Min.: 0 Unit:

Max.: 65535 Data Type: UInt16

Default: 0 Change: Unchangeable

Value Range: 0 to 65535 **Description**

ID of connection between FSoE master and slave.

E901.04h Watchdog time

Hex: E901-04h Effective -

mode:

Min.: 0 Unit:

Max.: 65535 Data Type: UInt16

Default: Change: Unchangeable

Value Range: 0 to 65535 Description

Watchdog timeout

E901.06h **Connection type**

> F901-06h **Effective** Hex:

mode: Min.: Unit:

Max.: 65535 Data Type: UInt16

Unchangeable Default: Change:

Value Range: 0 to 65535

Description

0: Master connection 1: Slave connection

Communication parameter length E901.07h

> Hex: E901-07h Effective

mode: Min.: 0 Unit:

Max.: 65535 Data Type: UInt16

Default: Change: Unchangeable

Value Range: 0 to 65535 Description

The length of the communication parameters in the parameter set.

E901.08h Application layer parameter length

0

Hex: F901-08h Effective

> mode: Unit:

Min.: Max.: 65535 Data Type: UInt16

Default: Unchangeable Change:

Value Range: 0 to 65535 Description

The length of the application parameters in the parameter set.

E901.09h SRA CRC

Hex: E901-09h Effective -

mode: Unit:

Min.: 0 Unit: Max.: 65535 Data Type: UInt16

Default: 0 Change: Unchangeable

Value Range: 0 to 65535

Description

CRC checksum of safety-related application parameter sets.

F980.01h FSOE address

Hex: F980-01h Effective

mode:

Min.: 0 Unit: Max.: 255 Data Type: UInt16

Max.: 255 Data Type: UInt16
Default: 0 Change: Unchangeable

Value Range:

0 to 255

Description

FSoE slave address

12 Maintenance

12.1 Routine Maintenance Items

Standard operating conditions:

Average annual ambient temperature: 30° C Average load rate: < 80% Daily operating time: < 20 h

12.1.1Routine Checklist

Check the following items during routine inspection.

Table 12-1 Routine checklist

| No. | Routine Checklist | Checked |
|-----|--|---------|
| 1 | The ambient temperature and humidity are normal. There is no dust or unwanted objects in the servo drive. | |
| 2 | There is no abnormal vibration or noise. | |
| 3 | The voltage of the power supply is normal. | |
| 4 | There is no strange smell. | |
| 5 | There are no fibers adhered to the air inlet. | |
| 6 | There is no intrusion of unwanted object on the load end. | |

12.1.2Routine Cleaning List

Check the following items during routine cleaning.

Table 12-2 Routine cleaning list

| No. | Routine Cleaning List | Checked |
|-----|--|---------|
| 1 | Clean the dust on the equipment surface, especially the metallic dust. | |
| 2 | Keep the front end of the servo drive and the connectors clean. | |

Note

- Switch off the power supply before cleaning the equipment. Clean the equipment with a blower gun or a piece of dry cloth.
- To prevent equipment discoloration or damage, do not use gasoline, diluents, alcohol, or acidic/alkaline detergent for cleaning.

12.2 Regular Checklist

12.2.1Regular Checklist

Table 12-3 Regular checklist

| No. | Item | Checked |
|-----|--|---------|
| 1 | The screws used to fix the couplings between devices are in place. | |
| 2 | There is no sign of overtemperature. | |
| 3 | Terminal blocks are in good condition without sign of damage. | |
| 4 | The clamping units of terminal blocks are in place. | |

12.2.2Periodic Maintenance List

The electrical and electronic parts inside the servo drive may be mechanically worn out and degraded. To keep the servo drive and servo motor in good condition, perform parts replacement based on the replacement cycles listed in the following table. Contact Inovance or Inovance agent before replacement to double check whether the part needs to be replaced.

| Object | Type | Standard Replacement Interval | Remarks | | |
|--------|---|--|--|--|--|
| | Power bus capacitor | About 8 years (ambient temperature: 30°C; load rate: 80%; uptime per day: 20 hours; standard environment ^[1]) | | | |
| | Fan | 5 years (ambient temperature: 30°C; load rate: 80%; uptime per day: 20 hours; standard environment ^[1]) | The standard replacement interval is for reference only. If any device/component works improperly before the replacement interval expires, replace it immediately. | | |
| Drive | Control circuit aluminum electrolytic capacitor | About 10 years (ambient temperature: 30°C; load rate: 80%; uptime per day: 20 hours; standard environment ^[1]) | | | |
| | Pre-charge relay | 100000 operations (depending on the operating conditions) | | | |
| | Pre-charge resistor | 20000 operations (depending on the operating conditions) | | | |
| | Dynamic brake relay | About 1000 times (rated motor speed; interval: 5 min; inertia: 20 | replace it illinediately. | | |
| | Dynamic brake resistor | times) | | | |
| | Bearing | 3 to 5 years (20,000 h to 30,000 h) | | | |
| Motor | Oil seal | 5000 h | | | |
| | Encoder | 3 to 5 years (20,000 h to 30,000 h) | | | |
| | Absolute encoder battery | Depends on the operating condition See the operation instructions for the encoder battery for details. | | | |

Note

For standard environment, see section Requirements on Installation Environment in the relevant installation guide.

13 Certification and Standard Requirements

CE Certification

| Directive | Standard | | |
|------------------------------|-------------|--------------|--|
| | Servo drive | EN 61800-3 | |
| EMC Directive | | EN 61800-6-2 | |
| 2014/30/EU | Servo motor | EN 61800-6-4 | |
| | | EN 55011 | |
| Low Voltage | Servo drive | EN 61800-5-1 | |
| Directive 2014/35/EU | Servo motor | EN 60034-1 | |
| | | EN 60034-5 | |
| RoHS Directive 2011/65/EU | Servo drive | EN 50581 | |
| | Servo motor | LIN JUJOI | |

UL/cUL Certification

| Certification | Standard | | | |
|---------------|-------------|----------------------|--|--|
| | Servo drive | UL61800-5-1 | | |
| UL/cUL | Servo unive | C22.2 No.274-17 | | |
| Certification | Servo motor | UL 1004-1 | | |
| Certification | | UL 1004-6 | | |
| | | CSA C22.2 No. 100-14 | | |

Note

The product complies with the latest directives and standards of CE, UL/cUL certifications.

KC Certification

Note

SV680XXXXXX-PINT is not KC-certified.

| Certification | Standard | | |
|---------------------|-------------|---|--|
| KC Certification | Servo drive | KN 61800-3 (Ver 2014.06) (IEC 61800-3 Ver 2012.03) | |

Others

The SV680-INT series servo drive meets the requirements of EAC, UKCA and functional safety certification.

13.1 CE Certification



Figure 13-1 CE Marking

- The CE mark indicates compliance with the Low Voltage Directive LVD),
 Electromagnetic Compatibility (EMC), and Restriction of Hazardous Substances
 (RoHS) directives.
- The CE mark is required for engaging in commercial business (production, importation, and distribution) in Europe.
- The drive complies with LVD, EMC, and RoHS directives and carries the CE mark.
- Machines and devices integrated with this drive must also comply with CE requirements for distribution in Europe.
- The integrator who integrates this drive into other products and attaches CE mark to the final assembly has the responsibility of ensuring compliance with CE certification.

13.1.1Requirements for Compliance with EMC

The drive is applicable to the first environment and second environment and complies with EMC directive 2014/30/EU and standard EN 61800-3.

As required by EMC Directive 2014/30/EU and standard EN IEC 61800-3, install an EMC filter on the input side of the drive and use shielded cables on the output side. Ensure the filter is grounded properly and the shield of the output cable is grounded 360 degrees.



When applied in the first environment, the drive may generate radio interference.
 In addition to the CE compliance requirements described in this chapter, take additional measures, if necessary, to prevent the radio interference generated by the drive.

Introduction to EMC standards

Electromagnetic compatibility (EMC) describes the ability of electrical and electronic devices or systems to work properly in the electromagnetic environment without introducing electromagnetic interferences that disturb the operation of other local

devices or systems. In other words, EMC includes two aspects: 1) The electromagnetic interference generated by a device during normal operation cannot exceed a certain limit. 2) The device must have sufficient immunity to the electromagnetic interference in the environment.

EN 61800-3 defines the following two types of environments.

- First environment: Environment that includes domestic premises, and establishments directly connected without intermediate transformers to a lowvoltage power supply network which supplies buildings used for domestic purposes
- Second environment: Environment that includes all establishments other than those directly connected to a low-voltage power supply network which supplies buildings used for domestic purposes

Devices are divided into the following four categories based on the intended application environment.

- Category C1: a Power drive system (PDS) with the rated voltage less than 1000 V, intended for use in the first environment.
- Category C2 equipment: PDS with rated voltage less than 1000 V, which is neither a plug-in device nor a movable device and, when used in the first environment, is intended to be installed and commissioned only by professionals.
- Category C3 equipment: PDS with rated voltage less than 1000 V, intended for use in the second environment and not intended for use in the first environment.
- Category C4 equipment: PDS with rated voltage equal to or above 1000 V, or rated current equal to or above 400 A, or intended for use in complex systems in the second environment.

13.1.2Requirements for Compliance with LVD

The drive has been tested in accordance with EN61800-5-1 to determine compliance with LVD. Observe the following requirements to enable machines and devices integrated with this drive to comply with LVD.

Installation location

Install the drive in a place with overvoltage category III and pollution degree 1 or 2 as specified by EN61800-5-1.

Installation Environment

For requirements of the installation environment, see "4.2 Installation Environment" on page 56.

Protection

The drive must be installed in a fireproof cabinet with doors that provide effective electrical and mechanical protection. The installation must conform to local and regional laws and regulations and relevant IEC standards.

IP20-rated drives intended to be installed inside the cabinet must be installed in a structure that prevents intrusion of unwanted objects from the top and the front.

Main Circuit Cable Requirements

For wiring requirements of the main circuit terminals, see *SV680-INT Series Servo Drive Hardware Guide.*

Requirements of protective devices

To comply with EN 61800-5-1, install a fuse/circuit breaker on the input side of the drive to prevent accidents caused by short circuit in the internal circuit.

For recommended fuse and circuit breaker models, see *SV680-INT Series Servo Drive* Hardware Guide.

13.2 UL/cUL Certification



Figure 13-2 UL/cUL marking

The UL/cUL mark commonly applies to products sold in the United States and Canada. Products with UL/cUL mark have been inspected and assessed by the UL organization. To pass UL/cUL certification, main built-in components of electrical products must also be UL certified.

The drive has been tested in accordance with UL 61800–5–1 and CSA C22.2 No. 274-17 to determine compliance with UL/cUL standards. Observe the following requirements to enable machines and devices integrated with this drive to comply with UL/cUL standards.

Installation location

Install the drive in a place with overvoltage category III and pollution degree 1 or 2 as specified by UL61800–5–1.

Ambient temperature

According to the protection level, the ambient temperature must be maintained within the following range:

Ambient temperature for open-type drives: 0°C to 50°C.

Installation requirements

Installation requirements for open-type drives:

SV680-INT series servo drives are open-type drives that must be installed in a fireproof cabinet with the housing that provides effective electrical and mechanical protection. The installation must conform to local laws and regulations and related NEC requirements.

Main Circuit Cable Requirements



On-site installation of output terminals (such as $P\oplus$, C, and N Θ) is not allowed.

- Terminals P⊕, C, and NΘ are used to connect optional parts. Do not connect these terminals to an AC power supply.
- To protect the main circuit, separate and cover the surface that may come into contact with the main circuit.
- The control circuit is the internal safety extra-low voltage (SELV) circuit that must be strictly insulated and isolated from other circuits. Make sure that the control circuit is connected to the external SELV circuit.
- Prevent foreign matters from entering the wiring part of the terminal block.
- Do not solder the twisted conductors.
- The tightening torque may vary with terminals. Tighten terminal screws with the specified tightening torque. You can use the torque screwdriver, ratchet, or wrench.
- When using an electric screwdriver to tighten terminal screws, set a low speed to prevent damage to the terminal screws.
- Tighten the terminal screws with an angle not higher than 5°. Failure to comply may damage the terminal screws.

Wiring requirements of the control circuit

Observe the requirements in UL508 during wiring.

Cable requirements

Cable dimensions must be compliant with requirements in NEC (National Electric Code) and CEC (Canadian Electrical Code) Part I and local regulations.

• Use cables with copper conductors.

- The recommended cable for the main circuit is a class 2 600V indoor heat-resistant PVC cable with continuous maximum allowable temperature of 75 ° C. The following conditions are used as premises:
 - Ambient temperature: < 40°C.
 - Normal operating ratings

If the recommended cables for peripheral equipment or options are not suitable for the product, contact Inovance.

Cable selection

To comply with UL61800-5-1 and CSA C22.2 No. 274-17, power cables used for the drive must meet the following requirements:

- Compliant with NEC, Table 310-16 of NFPA70.
- Comprised of copper conductors with a rated temperature not lower than 75°C (167°F)
- Cable size must be 14AWG or higher.
- With a rated voltage not lower than the rated voltage of the servo drive
- It is recommended to use cables compliant with UL758 Style 2517 and Style 2586 as motor main circuit cables.

Requirements of protective devices

To comply with UL61800-5-1, install a fuse/circuit breaker on the input side of the drive to prevent accidents caused by short circuit in the internal circuit.

Install sufficient protective devices against short circuit in branch circuits according to applicable regulations and this guide. The drive is applicable to circuits with a rated breaking capacity lower than 5KA and 65 KA and a maximum voltage of 480 VAC (class 400 V).

Note

All breaker protective devices must be UL-certified.

For the SV680 drive applied in North America, the recommended protective devices are as follows:

| Drive Model | | Circuit breaker (A) | Class J fuse (A) | Recommended inverse time lag breaker ^[1] (A) | |
|--------------------|------|------------------------|------------------|---|--|
| Single-phase 200 V | | | | | |
| Size A | S1R6 | 15 | 6 | 40 | |
| SIZE A | S2R8 | 15 | 10 | 40 | |

Table 13–1 Recommended protective devices

| Drive Model | | Circuit breaker (A) | Class J fuse (A) | Recommended inverse time lag breaker ^[1] (A) |
|-------------|------|------------------------|------------------|---|
| Size C | S5R5 | 15 | 20 | 40 |
| Size C | S7R6 | 15 | 20 | 100 |
| Size D | S012 | 20 | 20 | 100 |
| | | Three-phase 2 | 00 V | |
| Size A | S1R6 | 15 | 6 | 40 |
| Size A | S2R8 | 15 | 6 | 40 |
| Size C | S5R5 | 15 | 15 | 40 |
| Size C | S7R6 | 15 | 15 | 100 |
| Size D | S012 | 20 | 20 | 100 |
| | S018 | 40 | 20 | 100 |
| Size E | S022 | 40 | 35 | 100 |
| | S027 | 40 | 40 | 100 |
| | | Three-phase 4 | 00 V | |
| Size C | 3R5 | 15 | 6 | 100 |
| Size C | 5R4 | 15 | 10 | 100 |
| Size D | T8R4 | 20 | 15 | 100 |
| Size D | T012 | 20 | 20 | 100 |
| | T017 | 40 | 35 | 100 |
| Size E | T021 | 40 | 35 | 100 |
| | T026 | 40 | 40 | 100 |

Note

[1]: It is recommended to use the inverse time circuit breaker for multiple servo drives connected in parallel.

13.3 KC Certification

Note

SV680XXXXXX-PINT is not KC-certified.



Figure 13-3 KC Certification Mark

The KC mark indicates compliance with ROK standards related to safety (KC) and EMC (KCC).

- The KC mark is required for engaging in commercial business (production, importation, and distribution) in the ROK.
- Machines and devices integrated with this drive must also comply with KC requirements for distribution in the ROK.
- The integrator who integrates this drive into other products and attaches KC mark to the final assembly has the responsibility of ensuring compliance with KC certification.
- Observe the following requirements to enable machines and devices integrated with this drive to comply with KC standards.



Appllicant Suzhou Inovance Technology Co., Ltd. AC Servo Drive Model SV680 series Made In China

Manufacturer

Suzhou Inovance Technology Co.,Ltd.

A급기기 (업무용 방송통신기자재) 이 기기는 업무용(A급) 전자파적합기기로서 판매자 또는 사용자는 이 점을 주의하시기 바라며,가정외의 지역에서 사용하는 것을 목적으로 합니다.

13.4 EAC Certification



The Eurasian Customs Union is an economic organization led by Russia, consisting of Russia, Kazakhstan, Belarus, Kyrgyzstan and Armenia. EAC-certified products can be exported directly to these five countries.

AC drives and motor products fall into the EAC DoC category, and are subject to EAC—Safety (CU TR 004/2011) LVE and EAC—EMC (CU TR 020/2011).

13.5 UKCA Certification



Products exported to Great Britain must carry a UKCA mark. However, the products with the CE mark can still be exported to the United Kingdom.

13.6 Functional Safety Certification



EC directives and standards

Low Voltage Directive 2014/35/EU Standard EN 61800-5-1

EMC Directive 2014/30/EU Standard EN 61800-3: 2018

Machinery Directive 2006/42/EC (Safety Functions) Standard IEC 61800-5-2

14 Appendix

14.1 Safety Module Working with Beckhoff Safety CPU Unit

The following is an example of the simple configuration for FSoE-triggered safety function, with a Beckhoff safety CPU and TwinCAT3 master.

Hardware


The Beckhoff safety CPU unit includes a logic sub-module EL6900, 4-channel DI sub-module EL1904, and 4-channel DO sub-module EL2904 which are connected to EtherCAT network through EtherCAT coupler EK1100. For FSoE network hardware wiring, see "5.3.1 FSoE Network Connection and Setting" on page 65.

The safety address must be set to the safety module and every module of the safety CPU unit. The safety address cannot be 0, and the safety address must be unique for every module of the system. You can set the safety address for the safety module through the knob.

Software

You can obtain TwinCAT3 at the official website of Beckhoff. The software version of TwinCAT must be 3.1.4024.1 or above when FSoE is used.


- 1. Copy the SV680N-INT EtherCAT configuration file (SV680_1Axis_04001_FSoE.xml) to the TwinCAT installation directory: TwinCAT\3.1\Config\lo\EtherCAT.
- 2. Open TwinCAT3 and Create a TwinCAT project.




Search for devices.

Devices , and click as shown below. 1. Select TwinCAT Project2 - TcXaeShell (Administrator) <u>F</u>ile <u>E</u>dit <u>V</u>iew <u>P</u>roject <u>B</u>uild <u>D</u>ebug TwinCAT TwinSAFE PLC Tea<u>m</u> Scope <u>T</u>ools <u>W</u>indow <u>H</u>elp G → O 👸 → 🛅 → 當 🗎 🚜 🖟 👸 🥠 → 🥂 → Release → TwinCAT RT (x64) → ▶ Attach... → Build 4024.12 (Loaded 🕶 🚅 🔛 🔟 🔯 🌠 🎉 🎉 🎉 TwinCAT Project2 🔹 <Local> ○ ○ ☆ ☆ · ○ · □ / ≯ -Search Solution Explorer (Ctrl+;) ٠ م Solution 'TwinCAT Project2' (1 project) ▲ I TwinCAT Project2 SYSTEM MOTION PLC SAFETY %- C++ ANALYTICS Devices **Mappings** Error List


2. Click "OK".



3. Click "OK".



4. Click "Yes".




5. Click "OK".



6. Click "No".




7. If device searching is done, the following devices should show: the SV680N-INT servo drive, safety module, Beckhoff EK1100, EL6900, EL1904 and EL2904, as shown below.



PDO Configuration


When using the FSoE function, you must check 0x170A and 0x1B0A for FSoE-specific PDO mapping in the PDO configuration, as shown in the following figure.




Safety hardware configuration

1. Create a safety project.

a. Right click "SAFETY" and select "Add New" Item.




b. In the pop-up dialog box, select "TwinCAT Safety Project Preconfigured In...",




Appendix


c. Click "OK".



2. Set EL6900 as the safety logic module, do as follows.

a. Click "Target System", then click after "Physical device" to add the hardware device.







b. Check the serial number and hardware address of the EL6900 module.

3.

a. Expand "TwinSafeGroup1", right-click on "Alias Device" and select "Import Alias-Device(s) from I/O-configuration".




b. In the pop-up dialog, click "Select All" and then "OK".




c. Add safety I/O module and safety module under "Alias Devices".

- SAFETY Safety Project References 🎏 Target System GVLs User FBs ■ TwinSafeGroup1 Alias Devices 🖳 Drive 1 (InoSV680N) - Module 1 (FSoE-Advanced).sds ErrorAcknowledgement.sds Run.sds Module 1 (FSOES).sds Term 5 (EL2904) - Module 1 (FSOES).sds TwinSafeGroup1.sal Safety Instance
- d. Check the FSoE address of the safety module and "Dip Switch" of the Beckhoff module.





Safety program configuration

1. Add a PLC project.



b. Select "Standard PLC Project", name the project as "twinsafe" and make the following statement in the main program area.






2. Add non-safety standard variables.

a. Right-click on "Alias Device" and select "Add multiple standard variables". MAIN.Run_Stop ■ SAFETY ■ Safety Safety Project References 📇 Target System GVLs 📜 User FBs minSafeGroup1 🔺 🚂 Alias D Add 📜 Driv Erro Scope to This Mur 🗊 New Solution Explorer View Ter Sort Alias Devices 🎁 Ter Add multiple standard variables TwinSa Import Alias-Device(s) from I/O-configuration Safety Instan %- C++ Entire Solution ▼ S 0 Errors 0 Warnings ANALYTICS

b. In the pop-up dialog, set the number of outputs to "2".



- c. Check that two variables are added.
 - SAFETY
 - Safety
 - Safety Project
 - References
 - 📅 Target System
 - GVLs
 - 🛺 User FBs
 - - ▲ Alias Devices
 - Com_err.sds
 - 🖳 Drive 1 (InoSV680N) Module 1 (FSoE-Advanced).sds
 - ErrorAcknowledgement.sds
 - FB_Err.sds
 Run.sds
 - 🎵 Term 4 (EL1904) Module 1 (FSOES).sds
 - 🛂 Term 5 (EL2904) Module 1 (FSOES).sds
 - 🛂 TwinSafeGroup1.sal
 - Safety Instance


Description

"Com_err.sds" Run_Stop ■ SAFETY Safety Com err ▲ Osafety Project FB err References END VAR 📅 Target System GVLs User FBs ■ TwinSafeGroup1 ▲ Mias Devices Drive 1 (InoSV680N) - Module 1 (FSoE-Advanced).sds ErrorAcknowledgement.sds Nun.sds Standard Out Va Goto Link Variable 🖳 Standard Out Va 1 Term 4 (EL1904) Take Name Over from linked Variable Term 5 (EL2904) Open TwinSafeGroup1.sa Scope to This Safety Instance % C++ New Solution Explorer View ANALYTICS ¥ Cut Ctrl+X X Delete Del Devices Solution Rename ■ Device 2 (EtherCAT) 🟥 Image Error List Properties Alt+Enter

d. Right-click on "Standard Out Var 1.sds" and select "Rename" to rename it to

e. Right-click on "Standard Out Var 2.sds" and select "Rename" to rename it to "FB_Err.sds".

IVIPALIVATURE_STOP




3. Write the safety program.


Image-Info

a. Double click "TwinSafeGroup1.sal" and use the safety function blocks on the $\,$


right side to write the safety logic.



b. For example, drag "safeOr" block from the right side to "Network1".




c. Four safety DI inputs are used to trigger the safety function. There are four safeOr




d. Define the pins as needed.


Network1



- 4. Link the safety program to the safety hardware.
 - a. Find "Variable Mapping".




b. Set In1 as shown below.




c. Set In2 to "InputChannel2", In3 to "InputChannel3", and In4 to "InputChannel4", respectively.

d. Set Out1 as shown below.




Use In1 to control the control word corresponding to STO and Out1 to indicate the state of In1.

- e. Set Out2 to "SS1 command" and "OutputChannel2", Out3 to "SS2 command" and "OutputChannel3", and Out4 to command corresponding to remaining bits of RPDO and "OutputChannel4", respectively.
- f. Add two more variables. Follow the steps below to add the first variable.




2). Click the bottom left button highlighted in red box, and in the pop-up dialog

select "Com_Err" and then click "OK".



3). Click the bottom right browse button highlighted in red box, and in the pop-up dialog select "Out" and then click "OK".




g. Follow the steps below to add the second variable.


1). Click and name the variable as "Com_Err".




2). Click the bottom left button highlighted in red box, and in the pop-up dialog select "FB_Err" and then click "OK".




3). Click the bottom right browse button highlighted in red box, and in the



- 5. Link the non-safety standard variables added in step 2 to the variables in the PLC program.
 - a. On the left side, double-click the variable "Com_err.sds". On the right side, click




b. On the left side, double-click the variable "ErrorAcknowledgement.sds". On the right side, click , and in the pop-up dialog, select the instance "Err_Ack" and




c. On the left side, double-click the variable "FB_Err.sds". On the right side, click


and in the pop-up dialog, select the instance "FB_err" and click "OK".




d. On the left side, double-click the variable "Run.sds". On the right side, click and in the pop-up dialog, select the instance "Run_Stop" and click "OK".



- 6. Verify the safety logic program.
 - a. Choose "TwinSAFE" > "Verify Safety Project".




b. After verification is complete, check whether there is an error and whether the message "Verification Process succeeded" appears in the lower left corner. The




7. Verify the safety logic program and hardware modules.


a. Choose "TwinSAFE" > "Verify Complete Safety Project".




b. After verification is complete, check whether there is an error and whether the message "Verification Process succeeded" appears in the lower left corner. The




- 8. Download the safety program.
 - a. Copy the Serial Number "211505".




b. Choose "TwinSAFE" > "Download Safety Project".




c. In the pop-up dialog, enter the Username (Administrator), Serial Number, and Password (TwinSAFE), then click "Next".



d. View the download result and click "Next".




e. Enter the password again and click "Finish".



f. After completing all the above configurations, you can activate the hardware configuration and carry out safety function test.


Safety Function Test

- 1. Click to activate the configuration and the controller turns to the running mode.
- 2. Click and then to execute the PLC program.
- 3. As the safety program is downloaded and run for the first time, the communication is re-established. A communication error prompt is displayed. In this case, the value of expression Com_err is "TRUE".




Set the value of Err_Ack to "TRUE" and then "FALSE".

| TwinCAT_Project2.tw | TwinCAT_Project2.twinsafe.MAIN | | | | | |
|---------------------|--------------------------------|-------|----------------|---------|---------|--|
| Expression | Туре | Value | Prepared value | Address | Comment | |
| Err_Ack | BOOL | FALSE | TRUE | %Q* | | |
| Run_Stop | BOOL | FALSE | | %Q* | | |
| Com_err | BOOL | TRUE | | %I* | | |
| FB_err | BOOL | FALSE | | %I* | | |




The communication error is cleared.

4. Run the safety program and set Run_Stop to "True".




5. Disconnect the safety DI1. The bit in RPDO corresponding to STO command changes to "0" and the STO function is triggered.




Restore the safety DI1. The bit in RPDO corresponding to STO command changes to


"1" and the STO function is deselected.



6. Disconnect the safety DI2. The bit in RPDO corresponding to SS1 command changes to "0" and the SS1 function is triggered.



Restore the safety DI2. The bit in RPDO corresponding to SS1 command changes to



Modifying the Safety Object Dictionary


▶ 🖷 InfoData

▲ II Term 2 (EK1100)


 When modifying the safety object dictionary, you need to find the corresponding safety module under "SAFETY" menu, and modify the corresponding object dictionary under the "Safety Parameters" tab.

Entire Solution

▼ | S 0 Errors | A 0 Warnings | 0 of 19 Messages



2. After the modification is completed, you need to download the safety program



14.2 DIDO Function Assignment

Table 14–1 DI Function Assignment

| Setpoint | Name | Function Name | Description |
|----------|-----------------|-------------------------|--|
| 01 | STO command | STO trigger command | 0: STO active |
| 01 | STO command | oro trigger communa | 1: STO deselected |
| 02 | SBC command | SBC trigger command | 0: SBC active |
| 02 | 3DC Command | SDC trigger command | 1: SBC deselected |
| 0.3 | SS1 command | and SS1 trigger command | 0: SS1 active |
| 05 | 331 Command | | 1: SS1 deselected |
| 04 SS | SS2 command | SS2 trigger command | 0: SS2 active |
| 04 | 552 COMMINANO | | 1: SS2 deselected |
| 05 | SLS1 command | SLS1 trigger command | 0: SLS1 active |
| 05 | SEST COMMINANT | | 1: SLS1 deselected |
| 06 | SLS2 command | SLS2 trigger command | 0: SLS2 active |
| | SESZ COMMUNIC | 3L32 trigger command | 1: SLS2 deselected |
| 07 | SLS3 command | SLS3 trigger command | 0: SLS3 active |
| 07 | SESS COMMINANCE | | 1: SLS3 deselected |
| 08 | SLS4 command | SLS4 trigger command | 0: SLS4 active |
| | | | 1: SLS4 deselected |
| 09 | SDIp command | SDIp trigger command | 0: Active, forward rotation prohibited |
| 09 | | John Mager Command | 1: Canceled, forward rotation allowed |

| | Setpoint | Name | Function Name | Description |
|----|-------------|---------------------|----------------------|--|
| | 10 | SDIn command | SDIn trigger command | 0: Active, reverse rotation prohibited |
| | 10 | 35111 Continuand | ob angger communa | 1: Canceled, reverse rotation allowed |
| | 11 | ACK command | ACK trigger command | 0: ACK deselected |
| 11 | ACK Command | ACK trigger command | 1: ACK active | |

Table 14–2 DO Function Assignment

| Setpoint | Name | Function Name | Description |
|----------|--------------|---------------|--|
| 01 | STO Active | STO active | 0: Normal state |
| 01 | STO Active | STO active | 1: STO state |
| 02 | SBC Active | SBC active | 0: Normal state |
| 02 | 3BC ACTIVE | SBC active | 1: SBC state |
| 03 | CC1 Active | SS1 active | 0: SS1 inactive |
| 03 | SS1 Active | 331 active | 1: SS1 stop state |
| 0.4 | CC2 4 1' | 000 1: | 0: SS2 inactive |
| 04 | SS2 Active | SS2 active | 1: SS2 stop state |
| | | | 0: Normal state |
| 05 | SLS1 Active | SLS1 active | 1: SLS1 monitoring state |
| | | | 0: Normal state |
| 06 | SLS2 Active | SLS2 active | 1: SLS2 monitoring state |
| | SLS3 Active | | 0: Normal state |
| 07 | | SLS3 active | 1: SLS3 monitoring state |
| | | | 0: Normal state |
| 08 | SLS4 Active | SLS4 active | 1: SLS4 monitoring state |
| | CDI- Ct-t | CDIt-t | 0: Inactive, motor is not rotating forward |
| 09 | SDIp Status | SDIp status | 1: Active, motor is rotating forward |
| | | | 0: Inactive, motor is not rotating reversely |
| 10 | SDIn Status | SDIn state | 1: Active, motor is rotating reversely |
| | SOS Active | | 0: SOS inactive |
| 11 | | SOS active | 1: SOS active |
| 12 | SSM Active | SSM active | 0: Out of SSM limit |
| 12 | SSM ACTIVE | SSM active | 1: Within SSM limit |
| 13 | SS1-r Active | SS1-r active | 0: SS1-r inactive |
| 13 | | 331-1 delive | 1: SS1-r active state |
| 14 | SS2-r Active | SS2-r active | 0: SS2-r inactive |
| 14 | | 332-1 active | 1: SS2-r active |

Note

The DI and DO functions can only be used in the local mode. The bus mode automatically shields the DI and DO functions, and will not diagnose whether the DI and DO hardware circuits fail.



Copyright © Shenzhen Inovance Technology Co., Ltd.

Shenzhen Inovance Technology Co., Ltd.

www.inovance.com

Add.: Inovance Headquarters Tower, High-tech Industrial Park, Guanlan Street, Longhua New District, Shenzhen 518000, P.R. China

Tel: (0755) 2979 9595 Fax: (0755) 2961 9897

Suzhou Inovance Technology Co., Ltd.

Suzhou www.inovance.com Tel: (0512) 66:

Add.: No.52, Tian'e Dang Road, Wuzhong District,
Suzhou 215104, P.R. China
Tel: (0512) 6637 6666 Fax: (0512) 6285 6720