



PS00016654A01

## GL20-8DAI/8DAV Analog Output Module User Guide

**Suzhou Inovance Technology Co., Ltd.**

Add.: No.52, Tian E Dang Road, Wuzhong District,  
Suzhou 215104, P.R. China

Tel: (0512) 6637 6666 Fax: (0512) 6285 6720

[www.inovance.com](http://www.inovance.com)





# Preface

## ■ Introduction

GL20-8DAI is a 8-channel analog current output module and GL20-8DAV is a 8-channel analog voltage output module. The resolution of GL20-8DAI and GL20-8DAV is 16-bit. GL20-8DAI and GL20-8DAV can be used together with AM300 and AM500 series products through GL20-RTU-ECT communication interface module.

This guide describes the product information, mechanical installation, and electrical installation.

## ■ Standards compliance

The following table lists the certifications, directives, and standards that the product may comply with. For details about the acquired certificates, see the certification marks on the product nameplate.

Certification	Directive		Standard
CE certification	EMC directive	2014/30/EU	<b>24 VDC models</b> EN 61131-2 <b>220 VAC models</b> EN 61131-2 EN 61000-3-2 EN 61000-3-3
	LVD	2014/35/EU	EN 61010-1 EN 61010-2-201
	RoHS directive	2011/65/EU amended by (EU) 2015/863	EN IEC 63000
UL/cUL	-	-	UL 61010-1 UL 61010-2-201 CAN/CSA-C22.2 No. 61010-1 CSA C22.2 NO. 61010-2-201
KCC	-	-	-
EAC certification	-	-	-

Certification	Directive		Standard
UKCA	Safety Regulations	Electrical Equipment (Safety) Regulations 2016	EN 61010-1 EN 61010-2-201
	EMC	Electromagnetic Compatibility Regulations 2016	<b>24 VDC models</b> EN 61131-2 <b>220 VAC models</b> EN 61131-2 EN 61000-3-2 EN 61000-3-3
	RoHS	Directive (RoHS) Regulations 2012	EN IEC 63000

## More Data

Data name	Code	Description
GL20-RTU-ECT Communication Interface Module User Guide	PS00004985	Presents product information, mechanical installation, and electrical installation of the product.
GL20-RTU-ECT32 Communication Interface Module User Guide	PS00013434	
GL20-8DAI/8DAV Analog Output Module User Guide	PS00016654	

## Revision history

Date	Version	Revision
March 2025	A01	<ul style="list-style-type: none"> <li>Modified "<a href="#">1.3 Technical Data</a>" on <a href="#">page 11</a>.</li> <li>Modified "<a href="#">1.4 Environmental Specifications</a>" on <a href="#">page 13</a>.</li> <li>Modified "<a href="#">3.3 Wiring of Terminals</a>" on <a href="#">page 25</a>.</li> </ul>
July, 2024	A00	Initial release

## ■ Access to the Guide

This guide is not delivered with the product. You can obtain the PDF version in the following ways

- Do keyword search under Service and Support at [www.inovance.com](http://www.inovance.com).
- Scan the QR code on the product with your smart phone.
- Scan the QR code below to install My Inovance app, where you can search for and download user guides.



## ■ Warranty disclaimer

Inovance provides warranty service within the warranty period (as specified in your order) for any fault or damage that is not caused by improper operation of the user. Maintenance will be charged after the warranty expires.

Within the warranty period, maintenance will be charged for the following damage:

- Damage caused by operations not following the instructions in the user guide
- Damage caused by fire, flood, or unusual voltage
- Damage caused by unintended use of the product
- Damage caused by use beyond the specified scope of application of the product
- Damage or secondary damage caused by force majeure (natural disaster, earthquake, and lightning strike)

The maintenance is charged according to the latest Price List of Inovance. If otherwise agreed upon, the terms and conditions in the agreement shall prevail.

For details, see Product Warranty Card.

# Fundamental Safety Instructions

## ■ Safety Precautions

1. Read and follow the safety instructions when installing, operating, and maintaining the equipment.
2. To ensure your safety and prevent damage to the equipment, follow the marks on the equipment and all the safety instructions in this guide.
3. "CAUTION", "WARNING", and "DANGER" items in this guide do not indicate all safety precautions that need to be followed; instead, they just supplement the safety precautions.
4. Use this product according to the designated environment requirements. Damage caused by improper use is not covered by warranty.
5. Inovance shall take no responsibility for any personal injury or property damage caused by improper use.

## ■ Safety Levels and Definitions



"DANGER" indicates that failure to comply with the notice can result in severe personal injury or even death.



"WARNING" indicates that failure to comply with the notice may result in severe personal injury or even death.



"CAUTION" indicates that failure to comply with the notice may result in minor or moderate personal injury or equipment damage. Keep this guide properly for future use and deliver it to the end user.

### Control System Design



- Provide a safety circuit outside the PLC so that the control system can still work safely once external power failure or PLC fault occurs.
- Add a fuse or circuit breaker because the module may smoke or catch fire due to long-time overcurrent caused by operation above rated current or load short-circuit.



- An emergency stop circuit, a protection circuit, a forward/reverse operation interlocked circuit, and an upper position limit and lower position limit interlocked circuit must be set in the external circuits of PLC to prevent damage to the equipment.
- To ensure safe operation, for the output signals that may cause critical accidents, use external protection circuit and safety mechanism.
- Once the CPU of the PLC detects an exception in the system, all outputs may be closed; however, when a fault occurs in the controller circuit, the output may not be under control. Therefore, it is necessary to design an appropriate external control circuit to ensure normal operation.
- If the PLC output units such as relays or transistors are damaged, the output may fail to switch between ON and OFF states according to the commands.
- The PLC is designed to be used in an indoor electrical environment (overvoltage category II). The power supply must have a system-level surge protector, assuring that overvoltage due to lightning shock cannot be applied to the PLC's power supply input terminals, signal input terminals and output terminals, preventing damage to the equipment.

## Installation



- Installation must be carried out by skilled personnel who have undergone specialized electrical training and possess comprehensive electrical expertise.
- Disconnect all external power supplies of the system before removing/installing the module. Failure to do so may result in electric shock, module fault or malfunction.
- Do not use the PLC in environments with dust, greasy smoke, conductive dust, corrosive or combustible gases, exposed to high temperature, condensation, wind & rain, or subject to vibration and shock. Electric shock, fire and malfunction may also result in damage or deterioration to the product.
- The PLC is open-type equipment that must be installed in a control cabinet with lock (IP rating of the control cabinet enclosure > IP20). Only qualified professionals who have undergone specialized electrical training and possess comprehensive electrical expertise can open the cabinet.



- Prevent metal filings and wire ends from dropping into ventilation holes of the PLC during installation. Failure to comply may result in fire, fault and malfunction.
- Ensure there are no foreign matters on ventilation surface. Failure to comply may result in poor ventilation, which may cause fire, fault and malfunction.
- Ensure the module is connected to the respective connector securely and hook the module firmly. Improper installation may result in malfunction, fault or fall-off.

### **During wiring**



- Wiring must be carried out by skilled personnel who have undergone specialized electrical training and possess comprehensive electrical expertise.
- Disconnect all external power supplies of the system before wiring. Failure to comply may result in electric shock, module fault or malfunction.
- Insulate the cable terminals properly to ensure the insulation distance between cables will not be shortened after cables are connected to the terminal block. Failure to comply may result in electric shock or damage to the equipment.



- To avoid electric shock, cut off the power supply before connecting the product to the power supply.
- The input power of the product must meet the specifications listed in this guide. If the power input does not meet the specifications, the equipment may be damaged. Thus, check regularly that the DC power provided by the switching-mode power supply unit is stable.

### **Operation and maintenance**



- Operation and maintenance must be carried out by skilled personnel who have undergone specialized electrical training and possess comprehensive electrical expertise.
- Do not touch the terminals while the power is on. Failure to comply may result in electric shock or malfunction.
- Disconnect all external power supplies of the system before cleaning the module. Failure to comply may result in electric shock.
- Disconnect all external power supplies of the system before assembling/disassembling the module or connecting/removing the communication cables. Failure to comply may result in electric shock or malfunction.

## Safety Recommendations

- In the position where the operator directly touches the machinery part, for example, where a machinery tool is loaded/unloaded, or where a machine runs automatically, the on-site manual operating devices and any other alternative means must be carefully arranged and designed so that they are independent of the programmable controller and can start or terminate the automatic running of the system.
- If you need to modify the program while the system is running, use the lock function or other protective measures. Ensure that only authorized personnel can make the necessary modifications.

## Disposal



- Treat the scrapped equipment as industrial waste. Dispose of the battery according to local laws and regulations.
- Recycle retired equipment in accordance with industry waste disposal standards to avoid environmental pollution.

# 1 Product Information


## 1.1 Naming Rules and Nameplate

GL 20 - 8 DA { I  
V


①      ②      ③      ④      ⑤

① <b>Product information</b> GL: Inovance general local module	④ <b>Module type</b> DA: Analog output
② <b>Series number</b> 20: 20 series module	<b>Output type</b> ⑤ ● I: Current ● V: Voltage
③ <b>Number of I/Os</b> 8: 8 channels	

- GL20-8DAI nameplate information:




- GL20-8DAV nameplate information:









The data for ordering the product is shown in the following table.

Model	Description	Material code	Applicable model
GL20-8DAI	GL20 series 8-channel analog output module - current type	01440622	It can be used together with AM300 and AM500 series products through GL20-RTU-ECT communication interface module.
GL20-8DAV	GL20 series 8-channel analog output module - voltage type	01440623	

## 1.2 Components



No.	Interface	Function			
①	Signal indicator	PR (POWER +RUN)	Power/Operation indicator	Yellow-green	ON when the module is in normal operation
		ERR	State machine error indicator	Red	ON when an error occurs in the state machine
②	User terminals	For details, see <a href="#">"3.2 Terminal Assignment" on page 24</a> .			

No.	Interface	Function	
③	Color identification	 Red: Digital output	 Orange: Analog output
		 Gray: Digital input	 Green: Analog input
		 White: Communication	 Blue: Other module

## 1.3 Technical Data

### ■ Basic

Item	Specification
IP rating	IP20
Dimensions (W x H x D)	12 mm x 100 mm x 75 mm
Weight	About 60 g

### ■ Power supply

Item	Specification
Rated voltage of bus output power supply	5 VDC (4.75 VDC to 5.25 VDC)
Rated bus output current	100 mA (typical@5 VDC)
Rated voltage of terminal output power supply	24 V (20.4 VDC to 28.8 VDC)
Rated current of terminal output power supply	100 mA (typical@24 V)
Rated voltage of terminal output power supply	None
Rated current of terminal output power supply	None

## ■ Output

Item		Specification
Output type		Analog output
Output mode		<ul style="list-style-type: none"> <li>● 8DAI (current output)</li> <li>● 8DAV (voltage output)</li> </ul>
Number of output channels		8
Resolution		16 bits
Conversion time		60 $\mu$ s/channel
8DAI	Current output range	0 mA to 20 mA, 4 mA to 20 mA
	Current output load	0 $\Omega$ to 200 $\Omega$
	Current output accuracy (25°C)	$\pm 0.1\%$ (full range)
	Current output accuracy (full temperature range)	$\pm 0.5\%$ (full range)
	Current output diagnosis	-
8DAV	Voltage output range	$\pm 10$ V, 0 V to 10 V, $\pm 5$ V, 0 V to 5 V, 1 V to 5 V
	Voltage output load	> 1 k $\Omega$
	Voltage output accuracy (25°C)	$\pm 0.1\%$ (full range)
	Voltage output accuracy (full temperature range)	$\pm 0.5\%$ (full range)
	Voltage output diagnosis	-
Isolation		No isolation among interface channels, isolation applied between the power supply and interface, also between the interface and the bus
Output indicator		-
Output derating		-

## ■ Software

Item	Specification
Independent channel enable configuration	Supported
Conversion mode configuration	<ul style="list-style-type: none"> <li>● 8DAI: 0 mA to 20 mA, 4 mA to 20 mA, 0 mA to 20 mA by default</li> <li>● 8DAV: <math>\pm 10</math> V, 0 V to 10 V, <math>\pm 5</math> V, 0 V to 5 V, 1 V to 5 V, <math>\pm 10</math> V by default</li> </ul>
Output status after stop	Output zero, output last value, output preset value
Output present value	Supported
Digital output range configuration	<ul style="list-style-type: none"> <li>● 8DAI: 0 to 20000, 0 to 32000, 0 to 27648</li> <li>● 8DAV: <math>\pm 20000</math>, <math>\pm 32000</math>, <math>\pm 27648</math></li> </ul>
Diagnosis report	Supports 24 V power supply detection and configuration data error detection.

## 1.4 Environmental Specifications

Item	Specification
Installation/application environment	Free from conductive dust, conductive fibers, explosive dust, flammable gases, water mist/greasy dirt, corrosive dusts/gases, strong vibration, and repetitive shock
Altitude	$\leq 2,000$ m
Pollution degree	2
Immunity	2 kV on power supply cable (compliant with IEC 61000-4-4)
Overvoltage category	I
EMC immunity level	Zone B, IEC61131-2
Anti-static rating	Contact discharge $\pm 6$ kV and air discharge $\pm 8$ kV
Vibration resistance	<ul style="list-style-type: none"> <li>● Application scenario: Tested according to IEC60068-2-6, 3.5 mm amplitude from 5 Hz to 8.4 Hz; 1 g acceleration from 8.4 Hz to 200 Hz; 10 cycles per axial direction</li> <li>● Transportation scenario: Tested according to IEC60068-2-64, 0.01 <math>g^2/Hz</math> power spectral density from 5 Hz to 100 Hz; 0.001 <math>g^2/Hz</math> power spectral density at 200 Hz; 1.14 g Grms</li> </ul>

Item	Specification
Shock resistance	Application/Transportation scenario: Tested according to IEC60068-2-27; 15 g peak acceleration, 11 ms pulse width, 18 cycles in total in X, Y and Z axial directions
Operating temperature/humidity	<ul style="list-style-type: none"> <li>● Temperature: -20°C to +55°C</li> <li>● Humidity: &lt; 95% RH (30°C), without condensation</li> </ul>
Storage temperature/humidity	<ul style="list-style-type: none"> <li>● Temperature: -20°C to +60°C</li> <li>● Humidity: &lt; 95% RH (30°C), without condensation</li> </ul>
Transportation temperature/humidity	<ul style="list-style-type: none"> <li>● Temperature: -40°C to +70°C</li> <li>● Humidity: &lt; 95% RH (40°C), without condensation</li> </ul>


## 2 Mechanical Installation

### 2.1 Requirements of Installation Position

The product can be installed horizontally (recommended), vertically, on top or at the bottom of the electric cabinet. Different installation positions require different operating temperatures, as shown below.

#### Installation position and limit of GL20-8DAI


- When installed horizontally:



#### Caution

When all the eight channels output 20 mA and the load impedance is lower than 50  $\Omega$ , it is recommended that the operating temperature be kept to 50°C or below. Otherwise, module overtemperature may occur.

- When installed non-horizontally:





## Caution


When all the eight channels output 20 mA and the load impedance is lower than 50  $\Omega$ , it is recommended that the operating temperature be kept to 40°C or below. Otherwise, module overtemperature may occur.

### Installation position and limit of GL20-8DAV

When GL20-8DAV module operates at the maximum operating temperature, the load impedance can be 1.5 k $\Omega$  to 1 M $\Omega$ .

#### ■ Optimal installation position

It is recommended to install the product horizontally. To ensure normal ventilation and heat dissipation and allow sufficient wiring space, reserve enough clearance around the product, as shown in the following figure.



---


## Note

If there is a high-temperature heating source (heater, transformer, large resistor and so on) around the product, keep the product away from the heating source by at least 100 mm.


---

### ■ Other installation positions


Other installation positions are shown below. The same clearance as the optimal installation position is also required.




Vertical mounting 1



Vertical mounting 2



Cabinet top mounting



Cabinet bottom mounting

Up



Down



## Caution

In case of vertical installation:

- If the module is mounted to the PLC, make sure the PLC is arranged below all I/O modules (see vertical mounting 1). The number of modules cannot exceed 6, and the type of modules is not limited.
- Hold the cables with a cable duct to prevent the weight of cables being applied to the lower end plate, which may result in disconnection of the product from the DIN rail.


## 2.2 Installation Precautions

- Before installing or removing the module, ensure that the module is powered off.
- Do not hot swap the modules. Otherwise, the modules may be damaged by overcurrent or overvoltage, and the communication interface module or PLC may be subject to restart, user data loss or corruption.
- Prevent the enclosure or terminals of the module from dropping or suffering from impact or shock.


## 2.3 Installation Dimensions

### ■ Module

The installation dimensions (in mm) are shown in the figure below.




## ■ Cable connection



## 2.4 Installation Method

The module is mounted onto a DIN rail according to IEC 60715 (width: 35 mm, thickness: 1 mm). The dimensions (in mm) are shown below.






## Caution

If the thickness of the DIN rail is not as required, the product cannot fit in or function properly as the DIN rail mounting hook does not work.


### ■ Side-by-side installation of modules

You can install multiple I/O modules with the help of top and bottom guide rails on the modules, as shown below.




### ■ Installing the module onto DIN rail

1. Align the module with the DIN rail and push the module in the direction indicated by the arrow until you hear a clicking sound, as shown below.



2. Make sure the DIN rail mounting hook of the module is locked. The locked and unlocked states of the mounting hook are shown below.



- If the mounting hook is pressed down, it is locked.
- If the mounting hook is lifted up, it is unlocked.

To lock the PLC to the DIN rail, press down the mounting hook.




## Caution

When the module is not installed on the DIN rail, keep the rail hook in locked state. A hook that kept in unlocked state for a long period of time may fail to function properly.


3. Mount a DIN rail end plate on both sides of the PLC or the module.

To mount the end plate, hook the bottom of it to the bottom of the DIN rail, rotate the end plate to hook the top of it to the top of the DIN rail, and then tighten the screw to lock the end plate in place.



## ■ Removing the module

Pry the DIN rail mounting hook upwards with a tool such as a slotted screwdriver, hold the protrusions and pull the module out straight forward (as shown by the arrow). Then, press down the top of the mounting hook.




# 3 Electrical Installation

## 3.1 Cable Selection

The cable lug and cable cross sectional area included in the following table are only for reference.

Material name	Applicable cross sectional area		KST		Suzhou Yuanli	
	mm <sup>2</sup>	AWG	Model	Crimping tool	Model	Crimping tool
Tubular lug	0.3	22	E0308	KST2000L	0308	YAC-5
	0.5	20	E0508		0508	
	0.75	18	E7508		7508	
	1.0	18	E1008		1008	
	1.5	16	E1508		1508	

To use other types of tubular lugs, crimp the lug to the cables according to the shape and dimension requirements shown below.



## 3.2 Terminal Assignment



- GL20-8DAI

Signal on the left side	Terminal on the left side	Terminal on the right side	Signal on the right side
I0+	A1	B1	I0-
I1+	A2	B2	I1-
I2+	A3	B3	I2-
I3+	A4	B4	I3-
I4+	A5	B5	I4-
I5+	A6	B6	I5-
I6+	A7	B7	I6-
I7+	A8	B8	I7-
24V	A9	B9	COM

- GL20-8DAV

Signal on the left side	Terminal on the left side	Terminal on the right side	Signal on the right side
V0+	A1	B1	V0-
V1+	A2	B2	V1-
V2+	A3	B3	V2-
V3+	A4	B4	V3-
V4+	A5	B5	V4-
V5+	A6	B6	V5-
V6+	A7	B7	V6-
V7+	A8	B8	V7-
24V	A9	B9	COM

### 3.3 Wiring of Terminals


Wiring precautions for GL20-8DAI and GL20-8DAV modules are shown below. Different wiring methods can be used and combined for different channels.

#### ■ Wiring precautions

- Do not bundle the expansion cable together with power cables (high voltage, large current) that produce strong interference signals; otherwise, it may be affected by noise, surge and induction. Separate it from other cables and avoid cabling in parallel.
- Select recommended cables and pinboards for connection. It is recommended that shielded cables be used as extension cables to enhance capacity of interference resistance.
- Apply single-point grounding for the shield of shielded cable and welded and sealed cable.


#### ■ Circuit block diagram and wiring diagram

- Two-wire wiring mode of the 8DAI module



## Note

- 1: If noise or ripple is generated in external wiring, connect a 25 V capacitor of  $0.1 \mu\text{F}$  to  $0.47 \mu\text{F}$  between terminals I+ and I-.
  - The power cable adopts two-conductor shielded twisted pair cable.
  - A2-B2,..., and A8-B8 are wired in the same way as A1-B1.
- 
- Two-wire wiring mode of the 8DAV module



## Note

- 1: If noise or ripple is generated in external wiring, connect a 25 V capacitor of 0.1  $\mu\text{F}$  to 0.47  $\mu\text{F}$  between terminals V+ and V-.
- A2-B2,..., and A8-B8 are wired in the same way as A1-B1.


# 4 Program Commissioning

## 4.1 Commissioning Example of InoProShop


### 4.1.1 Programming the 8DAI Module

Take AM600+GL20 (GL20S)-RTU-ECT32+GL20 (GL20S)-8DAI configuration as an example here.


1. Double-click "Network Configuration" in the "Device" navigation tree on the left and select "EtherCAT master" under "EtherCAT" to enable the EtherCAT master.
2. Right-click "ETHERCAT", select "Add Device" in the pop-up menu, and select Fieldbus > EtherCAT > Slave > I/O coupler > GL20(GL20S)-RTU-ECT32\_x.x.x.x in the "Add Device" dialog box. Click "Add Device" to add GL20 (GL20S)-RTU-ECT32, as shown in the following figure.



3. Right-click "GL20\_RTU\_ECT32" in the "Device" tree on the left, select "Add Device", and double-click "GL20 (GL20S)-8DAI" in the pop-up window to add the module, as shown in the following figure.



4. Double-click "GL20\_8DAI" in the "Device" tree on the left, select "Enable access" in the "Channels Config" interface, select "DigitalOutput", and configure other parameters as needed, as shown in the following figure.




Name	Description
Enable access	Check "Enable access" to activate this channel.
Conversion mode	Used to set the analog output conversion type. Conversion mode: 0 mA to 20 mA (0 to 20000) and 4 mA to 20 mA (0 to 20000)
Digital output	Used to set the analog output range to determine the range of output conversion value of this channel. Digital output range: -2000 to +20000, -32000 to +32000 and -27648 to +27648
Output status after stop	<ul style="list-style-type: none"> <li>● Output zero: After the module stops running, the output remains at 0.</li> <li>● Output last value: After the module stops running, the output remains at the last output value.</li> <li>● Output preset value: After the module stops running, the output remains at the preset value. The preset value can be set to an analog value or a digital value. The analog value corresponds to the digital value one by one. Modify one of them and the other also changes accordingly. The preset value range is related to the current conversion mode.</li> </ul>


5. Define variables "DA\_CH0", "DA\_CH1", "DA\_CH2", "DA\_CH3", "DA\_CH4", "DA\_CH5", "DA\_CH6", and "DA\_CH7" with the ST programming language, as shown below.

```

1 PROGRAM PLC_PRG
2 VAR
3     DA_CH0:INT;
4     DA_CH1:INT;
5     DA_CH2:INT;
6     DA_CH3:INT;
7     DA_CH4:INT;
8     DA_CH5:INT;
9     DA_CH6:INT;
10    DA_CH7:INT;
11 END_VAR

```

6. Double-click "GL20\_RTU\_ECT32" in the "Device" tree on the left. In the "EtherCAT I/O Mapping" screen, click  on the right of the variable column. In the "Input Assistant" dialog box, select the variable "DA\_CH0" and click "OK" to map the variable "DA\_CH0" defined in the program to channel 0 of the configuration module. Similarly, the map variables "DA\_CH1", "DA\_CH2", "DA\_CH3", "DA\_CH4", "DA\_CH5", "DA\_CH6" and "DA\_CH7" to the corresponding channels of the configuration module, as shown in the following figure.



Variable	Mapping	Channel	Address	Type	Default Value	Unit	Description
		Device control	%QW1	UINT			Device control
Application.PLC_FRG_DA_CH0		GL20_8DAI DA CH0	%QW2	INT			GL20_8DAI DA CH0
Application.PLC_FRG_DA_CH1		GL20_8DAI DA CH1	%QW3	INT			GL20_8DAI DA CH1
Application.PLC_FRG_DA_CH2		GL20_8DAI DA CH2	%QW4	INT			GL20_8DAI DA CH2
Application.PLC_FRG_DA_CH3		GL20_8DAI DA CH3	%QW5	INT			GL20_8DAI DA CH3
Application.PLC_FRG_DA_CH4		GL20_8DAI DA CH4	%QW6	INT			GL20_8DAI DA CH4
Application.PLC_FRG_DA_CH5		GL20_8DAI DA CH5	%QW7	INT			GL20_8DAI DA CH5
Application.PLC_FRG_DA_CH6		GL20_8DAI DA CH6	%QW8	INT			GL20_8DAI DA CH6
Application.PLC_FRG_DA_CH7		GL20_8DAI DA CH7	%QW9	INT			GL20_8DAI DA CH7
		LBUS status	%IW2	UINT			LBUS status
		Fault ID	%IW3	UINT			Fault ID
		ErrorSolt1	%ID2	UDINT			ErrorSolt1
		ErrorSolt2	%ID3	UDINT			ErrorSolt2

GL20\_8DAI DA CH7    Reset All Mapping Var    Always update variables    Enabled 2 (always in bus cycle task)

= Create new variable   
 = Map to existing variable


7. Check, compile, log in, download, and run the program.

- Click on the toolbar at the top of the interface to check whether the program is correct.
- After the program check is correct, click on the toolbar at the top of the interface to compile all the code into PLC executable code.
- After the compilation is correct, click on the toolbar at the top of the interface, and follow the interface prompts to log in to the PLC and download the program.
- After the program download is complete, click on the toolbar at the top of the interface to execute the program.


### 4.1.2 Programming the 8DAV Module

The AM600+GL20 (GL20S)-RTU-ECT32+GL20 (GL20S)-8DAV configuration is used as an example here.


- Double-click "Network Configuration" in the "Device" navigation tree on the left and select "EtherCAT master" under "EtherCAT" to enable the EtherCAT master.
- Right-click "ETHERCAT" in the Device tree on the left and select "Add Device" in the pop-up menu. In the "Add Device" dialog box, select Fieldbus > EtherCAT > Slave > I/O coupler > GL20(GL20S)-RTU-ECT32\_x.x.x.x and click "Add Device" to add GL20 (GL20S)-RTU-ECT32, as shown in the following figure.



3. In the "Device" tree on the left, right-click "GL20\_RTU\_ECT32", select "Add Device", and double-click "GL20 (GL20S)-8DAV" in the pop-up window to add the module, as shown in the following figure.



4. Double-click "GL20\_8DAV" in the "Device" tree on the left, check "Enable access" in the "Channels Config" interface, select "DigitalOutput", and configure other parameters as needed, as shown in the following figure.




Name	Description
Enable access	Check "Enable access" to activate this channel.
Conversion Mode	Used to set the analog output conversion type. This setting determines the output conversion type and conversion value range of this channel. Conversion mode: -10 V to +10 V (-20000 to +20000), 0 V to 10 V (0 to 20000), -5 V to +5 V (-20000 to +20000), 0 V to 5 V (0 to 20000), and 1 V to 5 V (0 to 20000)
Digital output	Used to set the analog output range to determine the range of output conversion values of this channel. Digital output range: -20000 to +20000, -32000 to +32000, and -27648 to +27648
Output status after stop	<ul style="list-style-type: none"> <li>● Output zero: After the module stops running, the output remains at 0.</li> <li>● Output last value: After the module stops running, the output remains at the last output value.</li> <li>● Output preset value: After the module stops running, the output is always set to a preset value. The preset value can be set to an analog value or a digital value. The analog value corresponds to the digital value one by one. Modify one of them and the other also changes accordingly. The preset value range is related to the current conversion mode.</li> </ul>

5. Define variables "DA\_CH0", "DA\_CH1", "DA\_CH2", "DA\_CH3", "DA\_CH4", "DA\_CH5", "DA\_CH6", and "DA\_CH7" with the ST programming language, as shown below.

```

1  PROGRAM PLC_PRG
2  VAR
3      DA_CH0: INT;
4      DA_CH1: INT;
5      DA_CH2: INT;
6      DA_CH3: INT;
7      DA_CH4: INT;
8      DA_CH5: INT;
9      DA_CH6: INT;
10     DA_CH7: INT;
11 END_VAR

```

6. Double-click "GL20\_RTU\_ECT32" in the "Device" tree on the left. In the "EtherCAT I/O Mapping" screen, click  on the right of the variable column. In the "Input Assistant" dialog box, select the variable "DA\_CH0" and click "OK" to map the variable "DA\_CH0" defined in the program to channel 0 of the configuration




module. Similarly, the map variables "DA\_CH1", "DA\_CH2", "DA\_CH3", "DA\_CH4", "DA\_CH5", "DA\_CH6" and "DA\_CH7" to the corresponding channels of the configuration module, as shown in the following figure.


The screenshot shows the SIMATIC Manager interface with the 'Network Configuration' window open. The 'Find' tab is active, displaying a table of variables and their mappings. The 'Input Assistant' dialog is also open, showing a list of variables.

Variable	Mapping	Channel	Address	Type	Default Value	Unit	Description
Device control		Device control	%QW1	UINT			Device control
Application.PLC_FRG.DA_CH0		GL20_8DAI DA CH0	%QW2	INT			GL20_8DAI DA CH0
Application.PLC_FRG.DA_CH1		GL20_8DAI DA CH1	%QW3	INT			GL20_8DAI DA CH1
Application.PLC_FRG.DA_CH2		GL20_8DAI DA CH2	%QW4	INT			GL20_8DAI DA CH2
Application.PLC_FRG.DA_CH3		GL20_8DAI DA CH3	%QW5	INT			GL20_8DAI DA CH3
Application.PLC_FRG.DA_CH4		GL20_8DAI DA CH4	%QW6	INT			GL20_8DAI DA CH4
Application.PLC_FRG.DA_CH5		GL20_8DAI DA CH5	%QW7	INT			GL20_8DAI DA CH5
Application.PLC_FRG.DA_CH6		GL20_8DAI DA CH6	%QW8	INT			GL20_8DAI DA CH6
Application.PLC_FRG.DA_CH7		GL20_8DAI DA CH7	%QW9	INT			GL20_8DAI DA CH7
lBus status		lBus status	%IW2	UINT			lBus status
Fault ID		Fault ID	%IW3	UINT			Fault ID
ErrorSoft1		ErrorSoft1	%D2	UDINT			ErrorSoft1
ErrorSoft2		ErrorSoft2	%D3	UDINT			ErrorSoft2

The 'Input Assistant' dialog shows a list of variables with the following columns: Name, Type, Address. The variables listed are: Application (Application), DA\_CH0 (BOOL), DA\_CH1 (BOOL), DA\_CH2 (BOOL), DA\_CH3 (BOOL), DA\_CH4 (BOOL), DA\_CH5 (BOOL), DA\_CH6 (BOOL), DA\_CH7 (BOOL), IsConfig\_S0006 (HW\_GLC06), IDElement (Library), and SW3 Basic (Library).

7. Check, compile, log in, download, and run the program.

- Click  on the toolbar at the top of the interface to check whether the program is correct.
- After the program check is correct, click  on the toolbar at the top of the interface to compile all the code into PLC executable code.
- After the compilation is correct, click  on the toolbar at the top of the interface, and follow the interface prompts to log in to the PLC and download the program.


- d. After the program download is complete, click  on the toolbar at the top of the interface to execute the program.

## 4.2 Commissioning Example of AutoShop


### 4.2.1 Programming the 8DAI Module

The Easy320+GL20 (GL20S)-8DAI configuration is used as an example here.


1. Create a project.
  - a. Double-click the AutoShop shortcut icon on the PC desktop to open the AutoShop programming software.
  - b. Select File > New Project in the menu bar to open the "New Project" dialog box.
  - c. Set the project name, project path, programming language, project description, series, and model. Click "OK", as shown in the following figure.




2. Right-click Config > Module Config in the "Project Manager" navigation tree to open the "Module Config" interface, as shown in the following figure.



3. Double-click Expansion Module > Local Module > GL20 (GL20S)-8DAI on the right of the "Toolbox" interface to add the GL20S-8DAI module, as shown in the following figure.



4. Double-click Config > Module Config > GL20 (GL20S)-8DAI in the "Project Manager" navigation tree, and select "Enable access" in the "Config" interface of "1(GL20 (GL20S)-8DAI)" interface. Select "Conversion mode" and "Output state after stop", as shown in the following figure.





Name	Description
Enable access	Check "Enable access" to activate this channel.
Conversion mode	Used to set the analog output conversion type. This setting determines the output conversion type and conversion value range of this channel. Conversion mode: 0 mA to 20 mA (0 to 20000) and 4 mA to 20 mA (0 to 20000)
Output status after stop	<ul style="list-style-type: none"> <li>● Output zero: After the module stops running, the output remains at 0.</li> <li>● Output last value: After the module stops running, the output remains at the last output value.</li> <li>● Output preset value: After the module stops running, the output is always set to a preset value. The preset value can be set to an analog value or a digital value. The analog value corresponds to the digital value one by one. Modify one of them and the other also changes accordingly. The preset value range is related to the current conversion mode.</li> </ul>


5. Select Global Variables > Variable Table\_1 to define variables "DA\_CH0", "DA\_CH1", "DA\_CH2", "DA\_CH3", "DA\_CH4", "DA\_CH5", "DA\_CH6", and "DA\_CH7".

NO.	Variable Name	Data Type	Initial Value	Power Down Hold	Network Public
1	DA_CH0	INT	0	Non Retained	Private
2	DA_CH1	INT	0	Non Retained	Private
3	DA_CH2	INT	0	Non Retained	Private
4	DA_CH3	INT	0	Non Retained	Private
5	DA_CH4	BOOL	OFF	Non Retained	Private
6	DA_CH5	BOOL	OFF	Non Retained	Private
7	DA_CH6	BOOL	OFF	Non Retained	Private
8	DA_CH7	BOOL	OFF	Non Retained	Private





6. Double-click "GL20\_RTU\_ECT32" in the "Device" tree on the left. In the "Slot Configuration" interface, click "GL20(GL20S)-8DAI", and select "Add/Change", as shown below.



7. Click "I/O Functional Mapping", select interface  ②, select "Variable Table\_1", and map variables "DA\_CH0", "DA\_CH1", "DA\_CH2", "DA\_CH3", "DA\_CH4", "DA\_CH5", "DA\_CH6", and "DA\_CH7" ④ to the corresponding channels of the configuration module, as shown in the following figure.



8. Check, compile, log in, download, and run the program.

- Click  on the toolbar at the top of the interface to check whether the program is correct.
- After the program check is correct, click  on the toolbar at the top of the interface to compile all the code into PLC executable code.
- After the compilation is correct, click  on the toolbar at the top of the interface, and follow the interface prompts to log in to the PLC and download the program.
- After the program download is complete, click  on the toolbar at the top of the interface to execute the program.


## 4.2.2 Programming the 8DAV Module

The configuration of Easy320 + GL20 (GL20S)-8DAV is used as an example here.


1. Create a project.

- Double-click the AutoShop shortcut icon on the PC desktop to open the AutoShop programming software.
- Select File > New Project in the menu bar to open the "New Project" dialog box.


- c. Set the project name, project path, programming language, project description, series, and model. Click "OK", as shown in the following figure.




2. Right-click Config > Module Config in the "Project Manager" navigation tree to open the "Module Config" interface, as shown in the following figure.



3. Double-click Expansion Module > Local Module > GL20 (GL20S)-8DAV on the right-hand side of the "Toolbox" interface to add the GL20S-8DAV module.



4. Double-click Config > Module Config > GL20 (GL20S)-8DAV in the "Project Manager" navigation tree, and select "Enable access" in the "Config" interface of "2(GL20 (GL20S)-8DAV)" interface. Select "Conversion mode" and "Output status after stop".





Name	Description
Enable access	Check "Enable access" to activate this channel.
Conversion mode	Used to set the analog output conversion type. This setting determines the output conversion type and conversion value range of this channel. Conversion mode: -10 V to +10 V (-20000 to +20000), 0 V to 10 V (0 to 20000), -5 V to +5 V (-20000 to +20000), 0 V to 5 V (0 to 20000), and 1 V to 5 V (0 to 20000)
Output status after stop	<ul style="list-style-type: none"> <li>● Output zero: After the module stops running, the output remains at 0.</li> <li>● Output last value: After the module stops running, the output remains at the last output value.</li> <li>● Output preset value: After the module stops running, the output remains at the preset value. The preset value can be set to an analog value or a digital value. The analog value corresponds to the digital value one by one. Modify one of them and the other also changes accordingly. The preset value range is related to the current conversion mode.</li> </ul>


5. Select Global Variables > Variable Table\_1 to define variables "DA\_CH0", "DA\_CH1", "DA\_CH2", "DA\_CH3", "DA\_CH4", "DA\_CH5", "DA\_CH6", and "DA\_CH7".

NO.	Variable Name	Data Type	Initial Value	Power Down Hold	Network Public
1	DA_CH0	INT	0	Non Retained	Private
2	DA_CH1	INT	0	Non Retained	Private
3	DA_CH2	INT	0	Non Retained	Private
4	DA_CH3	INT	0	Non Retained	Private
5	DA_CH4	BOOL	OFF	Non Retained	Private
6	DA_CH5	BOOL	OFF	Non Retained	Private
7	DA_CH6	BOOL	OFF	Non Retained	Private
8	DA_CH7	BOOL	OFF	Non Retained	Private





6. Double-click "GL20\_RTU\_ECT32" in the "Device" tree on the left. In the "Slot Configuration" interface, click "GL20(GL20S)-8DAV", and select "Add/Change", as shown below.



7. Click "I/O Functional Mapping", select interface  ②, select "Variable Table\_1", and map variables "DA\_CH0", "DA\_CH1", "DA\_CH2", "DA\_CH3", "DA\_CH4", "DA\_CH5", "DA\_CH6", and "DA\_CH7" ④ to the corresponding channels of the configuration module, as shown in the following figure.



8. Check, compile, log in, download, and run the program.

- Click  on the toolbar at the top of the interface to check whether the program is correct.
- After the program check is correct, click  on the toolbar at the top of the interface to compile all the code into PLC executable code.
- After the compilation is correct, click  on the toolbar at the top of the interface, and follow the interface prompts to log in to the PLC and download the program.
- After the program download is complete, click  on the toolbar at the top of the interface to execute the program.

# 5 Troubleshooting

## 5.1 8DAI Fault Diagnosis

When the ERR indicator is ON, it indicates that the module encounters a fault. The module reports an error code. You can get the error code information through the diagnostic data object dictionary value displayed on the "CoE Online" interface, as shown below.

The screenshot shows the CoE Online interface with the 'CoE Online' tab selected. The left sidebar contains navigation options: General, Process Data(PDO Setting), Startup parameters(SDO Setting), Online, CoE Online, Device Diagnosis, EtherCAT I/O Mapping, EtherCAT IEC Objects, Status, and Information. The main area displays a table of object dictionary entries. At the top, there are controls for 'Read this page', 'Auto Update', and radio buttons for 'Offline from ESI file' (selected) and 'Online from devi'. The table has columns for Index/Subindex, Name, Flags, Type, and Value. The entry for '8DAI module Diagnosis information' (Index: 16#A000:16#00) is highlighted in blue.

Index/Subindex	Name	Flags	Type	Value
16#3010:16#00	Port 0 error counter	RO	USINT	
16#3011:16#00	Port 1 error counter	RO	USINT	
16#3012:16#00	ESC error counter	RO	USINT	
16#3016:16#00	Station address	RO	USINT	
16#3020:16#00	Fpga soft version	RO	UDINT	
16#3021:16#00	Module software version	RO	USINT	
16#5000:16#00	Disable Slot Control	RW	USINT	
16#5001:16#00	Disable Function Control	RW	UINT	
16#7000:16#00	8DAI output	RO	USINT	
16#8000:16#00	8DAI module transform mode	RW	USINT	
16#8001:16#00	8DAI module Stopmode	RW	USINT	
16#8002:16#00	8DAI module Stopvalue	RW	USINT	
16#A000:16#00	8DAI module Diagnosis information	RO	USINT	
:16#01	8DAI Module Diagnosis information	RO	UINT	
:16#02	8DAI CH0 Diagnosis information	RO	UINT	
:16#03	8DAI CH1 Diagnosis information	RO	UINT	
:16#04	8DAI CH2 Diagnosis information	RO	UINT	
:16#05	8DAI CH3 Diagnosis information	RO	UINT	
:16#06	8DAI CH4 Diagnosis information	RO	UINT	
:16#07	8DAI CH5 Diagnosis information	RO	UINT	
:16#08	8DAI CH6 Diagnosis information	RO	UINT	
:16#09	8DAI CH7 Diagnosis information	RO	UINT	

### Mapping data

For the module installed in slot n (n=0-31), the object dictionary definition for index 0xA000+0x40\*n is shown in the table below.

Index	0xA000+0x40*n: 8DAI module diagnostic information				
Sub-index	Name	Data type	Access mode	Mapping	Default value
0	8DAI module fault code	USINT	RO	NO	9
1	8DAI module fault information	UINT	RO	NO	0
2	8DAI module channel 0 fault information	UINT	RO	NO	0
3	8DAI module channel 1 fault information	UINT	RO	NO	0
4	8DAI module channel 2 fault information	UINT	RO	NO	0
5	8DAI module channel 3 fault information	UINT	RO	NO	0
6	8DAI module channel 4 fault information	UINT	RO	NO	0
7	8DAI module channel 5 fault information	UINT	RO	NO	0
8	8DAI module channel 6 fault information	UINT	RO	NO	0
9	8DAI module channel 7 fault information	UINT	RO	NO	0

## ■ Module fault code

Fault code	Description	Solution
0x5003	External 24 V power failure	Check the isolated power supply of the module.

## ■ Module channel fault code

Fault code	Description	Solution	Remark
0x6009	Channel configuration parameter fault	Check whether the configuration parameters are properly transmitted.	Default detection

## 5.2 8DAV Fault Diagnosis

When the ERR indicator is ON, it indicates that the module encounters a fault. The module reports an error code. You can get the error code information through the diagnostic data object dictionary value displayed on the "CoE Online" interface, as shown below.

Read this page  Auto Update  Offline from ESI file  Online from

Index/Subindex	Name	Flags	Type	Value
* 16#3011:16#00	Port 1 error counter	RO	USINT	
* 16#3012:16#00	ESC error counter	RO	USINT	
* 16#3016:16#00	Station address	RO	USINT	
- 16#3020:16#00	Fpga soft version	RO	UDINT	
* 16#3021:16#00	Module software version	RO	USINT	
* 16#5000:16#00	Disable Slot Control	RW	USINT	
- 16#5001:16#00	Disable Function Control	RW	UINT	
* 16#7000:16#00	8DAV output	RO	USINT	
* 16#8000:16#00	8DAV module transform mode	RW	USINT	
- 16#8001:16#00	8DAV module Stopmode	RW	USINT	
* 16#8002:16#00	8DAV module Stopvalue	RW	USINT	
- 16#A000:16#00	8DAV module Diagnosis information	RO	USINT	
- :16#01	8DAV Module Diagnosis information	RO	UINT	
- :16#02	8DAV CH0 Diagnosis information	RO	UINT	
- :16#03	8DAV CH1 Diagnosis information	RO	UINT	
- :16#04	8DAV CH2 Diagnosis information	RO	UINT	
- :16#05	8DAV CH3 Diagnosis information	RO	UINT	
- :16#06	8DAV CH4 Diagnosis information	RO	UINT	
- :16#07	8DAV CH5 Diagnosis information	RO	UINT	
- :16#08	8DAV CH6 Diagnosis information	RO	UINT	
- :16#09	8DAV CH7 Diagnosis information	RO	UINT	

For the module installed in slot n (n=0-31), the object dictionary definition for index 0xA000+0x40\*n is shown in the table below.

Index	0xA000+0x40*n: 8DAV module diagnostic information				
Subindex	Name	Data type	Access mode	Mapping	Default value
0	8DAV fault code	USINT	RO	NO	9
1	8DAV module fault information	UINT	RO	NO	0
2	8DAV module channel 0 fault information	UINT	RO	NO	0
3	8DAV module channel 1 fault information	UINT	RO	NO	0
4	8DAV module channel 2 fault information	UINT	RO	NO	0
5	8DAV module channel 3 fault information	UINT	RO	NO	0
6	8DAV module channel 4 fault information	UINT	RO	NO	0
7	8DAV module channel 5 fault information	UINT	RO	NO	0

Index	0xA000+0x40*n: 8DAV module diagnostic information				
Subindex	Name	Data type	Access mode	Mapping	Default value
8	8DAV module channel 6 fault information	UINT	RO	NO	0
9	8DAV module channel 7 fault information	UINT	RO	NO	0

## ■ Module fault code

Fault code	Description	Solution
0x5003	External 24 V power failure	Check the isolated power supply of the module.

## ■ Module channel fault code

Fault code	Description	Solution	Remark
0x6009	Channel configuration parameter fault	Check whether the configuration parameters are properly transmitted.	Default detection

## 6 Appendix: Version Information

This product supports local and remote adaption to PLC through the communication interface module. The following table describes the version matching information.

### ■ Adapt to PLC locally

Product name	Board software	Logic software	Logic software/ Programming software
Local module	1.0.3.0 and later	0.2.2.0 and later	-
AM500 series	2.1.0.0 and later	-	InoProShop programming software: V1.9.0 and later
AM760 series	2.1.0.0 and later	-	InoProShop programming software: V1.9.0 and later

### ■ Adapt to PLC remotely

Product name	Board software	Logic software	Programming software/XML file
Local module	1.0.3.0 and later	0.2.2.0 and later	-
GL20-RTU-ECT communication interface module	2.5.9.0 and later	0.1.4.2 and later	AutoShop programming software: V4.10.2.0 and later InoProShop programming software: V1.9.0 and later XML file: 3.0.14.0 and later

Product name	Board software	Logic software	Programming software/XML file
GL20-RTU-ECT32 communication interface module	3.0.6.0 and later	0.1.4.2 and later	AutoShop programming software: V4.10.2.0 and later InoProShop programming software: V1.9.0 and later XML file: 3.0.14.0 and later
AM500 series	2.1.0.0 and later	-	InoProShop programming software: V1.9.0 and later
AM760 series	2.1.0.0 and later	-	InoProShop programming software: V1.9.0 and later

## Note

You can get the firmware of the module and the firmware of communication interface module from Inovance technical support, and download XML files and InoProShop from <https://www.inovance.com>.